



# USER MANUAL

## BeanDevice® 2.4GHz



### BeanDevice® 2.4GHz

#### AX-3D XRange

High Performance wireless IIOT vibration sensor | acceleration and Particle Velocity monitoring

#### INC

Wireless IIOT inclinometer sensor tilt, inclination, slope monitoring | low-cost version

#### HI-INC

Wireless IIOT inclinometer tilt, inclination, slope monitoring



#### AX-3DS

Wireless IIOT accelerometer sensor Shock and impact monitoring



#### AX-3D

High Performance wireless vibration sensor | acceleration and velocity monitoring



#### Hi-Inc XRange

High performance wireless IIOT inclinometer sensor | tilt, inclination, slope monitoring



## DOCUMENT

Document ID	UM_RF_01	Version	V4.1
External reference		Date	30/08/2022
Author	Fahd ESSID, Application/Support Engineer		
		Project Code	
Document's name	SmartSensor wireless accelerometer inclinometer and shock sensor user manual		

## VALIDATION

Function	Destination	For validation	For info
Writer	Youssef Shahine	✓	
Reader	Mohamed-Yosri Jaouadi	✓	
Validation	Antje Jacob		✓

## DIFFUSION

Function	Destination	For action	For info
Reader n°1	Antje Jacob, Production Manager	✓	
Reader n°2	Mohamed-Yosri Jaouadi., Embedded software engineer	✓	

## UPDATES

Version	Date	Auteur	Evolution & Status
2.1	26/06/2012	Christophe Dontegreuil	<ul style="list-style-type: none"> <li>BeanDevice® HI-INC accuracy considerations</li> <li>BeanDevice® mounting</li> </ul>
2.2	15/11/2012	Christophe Dontegreuil	<ul style="list-style-type: none"> <li>New version of the streaming mode</li> <li>Primary Cell replacement instructions and Calibration added</li> </ul>
2.3	10/03/2013	Christophe Dontegreuil	XRange version added
2.4	22/05/2014	Christophe Dontegreuil	Detailed information about log files creation & management
2.5	29/11/2014	Maxime Obr.	<ul style="list-style-type: none"> <li>TimeSync function description</li> <li>Log folder organization added</li> </ul>
2.6	06/02/2016	Maxime Obr.	<ul style="list-style-type: none"> <li>Sensor calibration section added</li> <li>More details about power supply wiring code for Xtend option</li> <li>Exporting a log file on excel added</li> </ul>

## UPDATES

2.7	21/03/2016	Rasha Friji	<ul style="list-style-type: none"> <li>• Standalone option</li> <li>• Battery level display</li> </ul>
2.8	27/09/2016	Salah Riahi	<ul style="list-style-type: none"> <li>• BeanDevice versions suppressed</li> <li>• Tx Power management suppressed</li> </ul>
2.9	22/12/2016	Salah Riahi	<ul style="list-style-type: none"> <li>• Exporting a log file to Excel video added</li> </ul>
2.10	12/03/2018	Aymen JEGHAM	<ul style="list-style-type: none"> <li>• New technical Videos added</li> <li>• System Maintenance (primary cell change &amp; calibration) suppressed</li> </ul>
2.11	3/05/2018	Aymen JEGHAM	<ul style="list-style-type: none"> <li>• Signal processing</li> <li>• Alarm threshold</li> <li>• Zeroing</li> <li>• S.E.T acquisition mode</li> </ul>
2.12	10/07/2018	Youssef Shahine	<ul style="list-style-type: none"> <li>• Technical features updated</li> <li>• Alarm Management description transferred from BeanScope® UM to BeanDevice® 2.4GHZ User Manual</li> <li>• Offline analysis tool description transferred from BeanScope® UM to BeanDevice® 2.4GHZ UM</li> </ul>
2.13	20/07/2018	Aymen JEGHAM	<ul style="list-style-type: none"> <li>• Dedicated section <b>Online data analysis tool</b></li> <li>• Diagram updated “Offline and online data analysis tool”</li> </ul>
2.14	30/07/2018	Aymen JEGHAM	<ul style="list-style-type: none"> <li>• Vocabulary update</li> <li>• Off. Graph and date conversion location update</li> </ul>
2.15	26/10/2018	Fahd ESSID	<ul style="list-style-type: none"> <li>• Screenshots update</li> <li>• LEDs Description update</li> <li>• Tab signal processing changed to Online Data analysis and updated</li> <li>• Sensor channel profile update</li> <li>• Data acquisition log file update</li> <li>• Offline graph update</li> <li>• Offline data analysis update</li> <li>• Online data analysis update</li> </ul>
2.16	03/12/2018	Fahd ESSID	<ul style="list-style-type: none"> <li>• Graphical Display updated</li> </ul>
2.3	21/02/2020	Seddik ATTIG	<ul style="list-style-type: none"> <li>• More info about Gmail and Hotmail emails configuration</li> </ul>

### UPDATES

2.17	11/01/2019	Fahd ESSID	<ul style="list-style-type: none"> <li>• Right click functionalities added</li> <li>• Alarm Management updated</li> <li>• Alarm Management Note added</li> <li>• DIN 4150-3 Configuration added</li> </ul>
2.18	20/03/2019	Fahd ESSID	<ul style="list-style-type: none"> <li>• DIN Display updated</li> <li>• Tab Sensor Config Added</li> </ul>
2.19	25/06/2019	Mohamed Bechir Besbes	<ul style="list-style-type: none"> <li>• Firewall exception for BeanScope</li> </ul>
3.0	02/07/2019	Fahd ESSID	<ul style="list-style-type: none"> <li>• Vocabulary update</li> <li>• Online/Offline Data Analysis update</li> </ul>
3.1	02/07/2019	YAHYA Bassem	<ul style="list-style-type: none"> <li>• IP version update</li> </ul>
3.3	29/06/2020	Seddik ATTIG	<ul style="list-style-type: none"> <li>• PPV Restrictions</li> </ul>
3.4	18/12/2020	Seddik ATTIG	<ul style="list-style-type: none"> <li>• New skin updated</li> <li>• Appendices updated</li> <li>• Add Tools tab options</li> </ul>
3.5	30/12/2020	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Update sensors specifications and screenshots</li> </ul>
3.6	08/03/2021	Seddik ATTIG	<ul style="list-style-type: none"> <li>• FTP Configuration</li> </ul>
3.7	26/03/2021	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Update the Battery saver mode section</li> </ul>
3.8	04/06/2021	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Update sensors specification</li> </ul>
3.9	16/07/2021	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Standard/Expert view updated</li> </ul>
3.9.1	15/11/2021	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Links updated</li> </ul>
4.0	17/06/2022	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Add Hi-Inc-SR features</li> </ul>
4.1	30/08/2022	Seddik ATTIG	<ul style="list-style-type: none"> <li>• Add AX-3D-SR features</li> </ul>



## *Disclaimer*

The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of Beanair GmbH, is strictly prohibited.

Beanair makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, Beanair does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

Beanair disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

Beanair reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document.

Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © Beanair GmbH 2022



# Contents

1. TECHNICAL SUPPORT .....	17
2. VISUAL SYMBOLS DEFINITION .....	18
3. ACRONYMS AND ABBREVIATIONS.....	19
4. RELATED DOCUMENTS & VIDEOS.....	20
4.1 White paper webpage.....	20
4.2 Featured videos.....	21
4.3 Technical videos .....	22
5. ACRONYMS AND ABBREVIATIONS.....	23
6. PRODUCT DESCRIPTION.....	24
6.1 About Smartsensor product line .....	24
6.2 BeanDevice® 2.4GHz AX-3D .....	25
6.2.1 Featured video.....	25
6.2.2 Main features .....	25
6.2.3 Applications .....	25
6.3 BeanDevice® 2.4GHz AX-3D-SR .....	26
6.3.1 Featured video.....	26
6.3.2 Main features .....	26
6.3.3 Applications .....	26
6.4 BeanDevice® 2.4GHz HI-INC - 2.4GHZ series (Wireless Inclinometer) .....	27
6.4.1 Main features .....	27
6.4.2 Applications .....	27
6.5 BeanDevice® 2.4GHz AX-3DS - 2.4GHz series (Wireless shock sensor).....	28
6.5.1 Main features .....	28
6.5.2 Applications .....	28
6.6 BeanDevice® 2.4GHz AX-3D XRange – 2.4GHz series (High Performance Wireless Accelerometer) .....	29
6.6.1 Main features .....	29
6.6.2 Applications .....	29
6.7 BeanDevice® HI-INC Xrange (High performance wireless inclinometer) .....	30
6.7.1 Main features .....	30
6.8 BeanDevice® 2.4GHz HI-INC-SR - 2.4GHZ series (Tri-axis Wireless Inclinometer) .....	31

6.8.1	Main features .....	31
6.8.2	Applications .....	31
6.9	Technical specifications.....	32
6.9.1	BeanDevice® 2.4GHz AX-3D.....	32
6.9.2	BeanDevice® AX-3D-SR.....	35
6.9.3	BeanDevice® AX-3DS .....	40
6.9.4	BeanDevice® INC .....	43
6.9.5	BeanDevice® HI-INC.....	47
6.9.6	BeanDevice® HI-INC-SR .....	51
6.9.7	BeanDevice® AX-3D XRange .....	56
6.9.8	BeanDevice® HI-INC Xrange .....	60
6.10	Product focus .....	64
6.10.1	Casing description .....	64
6.10.2	LEDs Description .....	66
6.10.3	Mechanical drawing for standard version.....	66
6.10.4	Mechanical drawing for Xrange version.....	67
6.10.5	Antenna diversity .....	67
6.10.6	Radome antenna .....	68
6.11	Mounting instructions.....	70
6.11.1	Adhesive mounting instructions (BeanDevice® INC, HI-INC, AX-3D, AX-3DS).....	70
6.11.2	Screw Mounting (BeanDevice® AX-3D Xrange & BeanDevice® HI-INC Xrange).....	75
6.11.3	Wireless inclinometer special instructions (BeanDevice® HI-INC, INC & HI-INC Xrange) .....	76
6.12	BeanDevice® 2.4GHz Power Supply .....	76
6.12.1	Integrated Lithium-ion Rechargeable battery (Xtend version excluded).....	76
6.12.2	External Primary cell (Xtend version only) .....	77
6.12.3	How to change the Primary cell on the BeanDevice® (Xtend version only).....	78
6.12.4	AC-To-DC power adapter (option).....	83
6.12.5	Power supply wiring code .....	83
6.13	Restoring Factory settings.....	85
7.	BEANDEVICE® SUPERVISION FROM THE BEANSCAPE® .....	86
7.1	Starting the BeanScape® .....	86
7.2	Displaying the BeanDevice® Information.....	88
7.2.1	Frame: Identity .....	88
7.2.2	Frame : Wireless Network Diagnostic .....	89
7.2.3	Frame: Power supply diagnostic .....	89
7.2.4	Frame : System .....	92
7.2.5	Frame : BeanDevice® .....	92
7.2.6	Frame: Product Version.....	93
7.2.7	Frame: Current Data Acquisition mode.....	93
7.2.8	Frame: Sensor Info .....	94

7.3	BeanDevice® configuration .....	97
7.3.1	Tab: Custom Display .....	98
7.3.2	Tab: Notes.....	99
7.3.3	Tab : Data Acquisition configuration .....	100
7.3.4	Tab: Sensor Config.....	103
7.3.5	Tab: Online Data Analysis .....	107
7.3.6	Tab: Datalogger .....	128
7.3.7	Tab: System config.....	130
7.3.8	Tab : Power mode management .....	130
7.3.9	Right Click functionalities .....	131
7.4	Sensor channel profile.....	132
7.4.1	Sensor channel status.....	133
7.4.2	Sensor channel configuration.....	134
7.4.3	Graphical display .....	146
7.5	Datalogger configuration .....	150
7.6	Options for Log file generation & folder organization .....	151
7.6.1	Log file system overview .....	151
7.6.2	Log file directory.....	151
7.6.3	Log folder.....	153
7.6.4	Log file size configuration.....	154
7.6.5	All sensor channels in one log file .....	155
7.6.6	Cache Data configuration (for Graph) .....	156
7.6.7	Data acquisition Log file .....	157
7.6.8	Log file related to Wireless Network diagnostic .....	159
8.	ALARM MANAGEMENT .....	165
8.1	Email Config.....	165
8.2	DAQ Alarm.....	167
8.3	SSD DAQ Mode.....	168
8.4	Alarm DAQ Mode .....	168
8.5	System Alarm .....	169
8.6	File Format .....	170
8.7	DIN 4150-30 Configuration .....	171
8.8	Crash Report.....	172
9.	TOOLS TAB.....	173
9.1	BeanScape® Configuration .....	173
9.1.1	Log file configuration.....	173
9.1.2	Keep Alive App.....	174
9.1.3	BeanGateway® Configuration via TCP/UDP .....	174
9.1.4	System Configuration .....	175

9.1.5	Data cache configuration.....	175
9.1.6	Data Logger configuration.....	176
9.1.7	Startup.....	176
9.1.8	Date & Time format.....	177
9.1.9	Language.....	177
9.1.10	Precision.....	178
9.2	Alarm Window.....	178
9.3	Import/Export User settings.....	179
9.3.1	Custom User Configuration.....	179
9.3.2	BeanScape® Configuration.....	182
9.4	Notification Management.....	183
9.5	Offline Graph.....	184
9.6	Date Conversion.....	186
9.7	Advanced settings.....	189
9.7.1	Firewall.....	190
9.7.2	SQL Server Report.....	190
9.7.3	MATLAB Function.....	191
9.8	BeanScape® Client management.....	192
9.9	FTP Configuration.....	193
10.	VIEW TAB.....	197
10.1	Standard View.....	197
10.1.1	Dashboard Management.....	198
10.2	Expert View.....	203
10.2.1	BeanGateway® profile.....	204
10.2.2	Data Acquisition configuration.....	207
10.2.3	Sensor Profile.....	208
10.2.4	Tools tab.....	209
10.2.5	Advanced Functions.....	213
11.	ONLINE AND OFFLINE DATA ANALYSIS TOOL.....	215
11.1	Offline data analysis tool.....	215
11.1.1	FFT (Fast Fourier Transform) waveform analysis module.....	215
11.1.2	Particle Velocity.....	222
11.2	Online data analysis tool.....	231
11.2.1	Online FFT.....	231
11.2.2	Online Velocity.....	239
11.2.3	IIR Software Filter.....	250
11.2.4	Number of Points (Streaming).....	250
11.2.5	Online Waveform Configuration.....	252
11.2.6	Unit of acceleration.....	252



11.2.7 S.E.T threshold.....	252
12. APPENDICES.....	253
12.1 Appendice 1: Installation procedures .....	253
12.1.1 Sealing .....	253
12.1.2 Coexistence With other Frequencies at 2.4 GHz.....	253
12.1.3 Temperature & Humidity .....	253
12.1.4 Reflections, Obstructions and Multipath .....	254
12.1.5 shock & Vibration resistance .....	254
12.1.6 Antenna .....	254
12.2 Appendice 2: Sensor Characteristics .....	255
12.2.1 BeanDevice® AX-3D & AX-3D Xrange .....	255
12.2.2 BeanDevice® HI-INC & HI-INC Xrange.....	260
12.2.3 Inclinometer Block Diagram (BeanDevice® version) .....	261
12.2.4 MEMS Inclinometer & differential output .....	261
12.2.5 5 <sup>th</sup> order Anti-aliasing filter .....	262
12.2.6 Analog to digital converter .....	262
12.2.7 Accuracy considerations.....	262
12.2.8 Offset & temperature dependencies .....	262
12.2.9 BeanDevice® AX-3DS .....	264
12.2.10 Sensor position inside the casing.....	265
12.3 Appendice 3: maintenance & supervision (for experienced user).....	266
12.3.1 Extending battery life .....	266
12.3.2 Over-the-air Configuration (OTAC) parameters backed up on Flash .....	268
12.3.3 Scrolling menu « BeanDevice » .....	272
12.4 Appendice 4: Troubleshooting.....	275
12.5 Appendix 5: Sensor calibration .....	277
12.5.1 Factory Calibration procedure.....	277
12.5.2 Re-calibration .....	277
12.6 Firewall exception for BeanScape® .....	277

## List of Tables

Table 1 : BeanDevice AX-3D/HI-INC/INC enclosure feature.....	67
Table 2 : M8-3P Plug Wiring code .....	84
Table 3 : M8-3P Plug Wiring code (Xtend version).....	84
Table 4: Frequency & Phase response curve cutoff frequency 1 KHz .....	257
Table 5 : BeanDevice® AX-3DS power consumption for a given sampling rate .....	265
Table 6: End-user OTAC parameters .....	269

## List of Figures

Figure 1 : White Paper webpage .....	20
Figure 2: Casing description.....	64
Figure 3: Mechanical drawing - BeanDevice® AX-3D/Hi-INC/INC .....	67
Figure 4 : Radome antenna performances .....	68
Figure 5: Antenna position on the BeanDevice AX-3D .....	69
Figure 6: BeanDevice® mounting reference angle .....	71
Figure 7: Xrange base plate overview .....	75
Figure 8: External Primary cell.....	77
Figure 9: Changing the External Primary cell.....	79
Figure 10: Changing the External Primary cell.....	79
Figure 11: Changing the External Primary cell (wrong practice) .....	80
Figure 12: Changing the External Primary cell (connecting the BeanDevice®) .....	81
Figure 13: Power supply diagnostic frame on BeanScape®) .....	82
Figure 14: M8-3P Wall Plug-in power supply .....	83
Figure 15: M8 socket Power supply Wiring code .....	83
Figure 16: M8 Plug Power supply Wiring code.....	84
Figure 17: Network Reed non-contact button .....	85
Figure 18: BeanDevice® display on BeanScape® .....	87
Figure 19: Overview: BeanDevice® System Profile on BeanScape® .....	88
Figure 20: BeanDevice® Identity.....	88
Figure 21: BeanDevice® network-link status .....	89
Figure 22: BeanDevice® Power Supply information .....	89
Figure 23: BeanDevice® Power modes .....	91
Figure 24: BeanDevice® Diagnostic cycle information .....	92
Figure 25: Frame BeanDevice® on BeanScape® .....	92
Figure 26: BeanDevice® Product version frame .....	93
Figure 27: Current data acquisition mode.....	93
Figure 28: BeanDevice® configuration frame.....	97
Figure 29: BeanDevice® custom display tab.....	98
Figure 30: Tab: Notes.....	99
Figure 31: Tab: Data acquisition configuration .....	100
Figure 32: Current data acquisition mode display.....	102
Figure 33: BeanDevice® AX 3D and AX 3D X-range Sensor Config tab .....	103
Figure 34: BeanDevice® AX-3D-SR Sensor Config Tab .....	103
Figure 35: BeanDevice® Hi-Inc and Hi-Inc X-range & Hi-Inc-SR Sensor Config tab.....	104
Figure 36: BeanDevice® Hi-Inc-SR Sensor Config Tab.....	105
Figure 37: BeanDevice® AX-3DS Sensor Config tab .....	106
Figure 38: Signal processing tab .....	107
<b>Figure 39: FFT Spectrum.....</b>	<b>108</b>
<b>Figure 40: Online FFT Configuration frame .....</b>	<b>108</b>
<b>Figure 41: FFT log files folder.....</b>	<b>109</b>
<b>Figure 42: Enabling Automatic FFT Report .....</b>	<b>109</b>
<b>Figure 43: Report Folder .....</b>	<b>109</b>
<b>Figure 44: FFT Report (S.E.T mode) .....</b>	<b>110</b>
<b>Figure 45: FFT Shift Spectrum .....</b>	<b>114</b>
<b>Figure 46: Online Velocity configuration tab .....</b>	<b>115</b>

<b>Figure 47: Velocity Graph</b> .....	116
<b>Figure 48: Velocity and FFT Graph, PPV and PVS</b> .....	117
<b>Figure 49: DIN 4150 Real Time Graph, PPV &amp; PVS</b> .....	117
<b>Figure 50: DIN 4150-3 Report email</b> .....	118
Figure 51: Velocity Log Folder/Files.....	120
Figure 52: PPV Log Folder/Files .....	120
Figure 53: Velocity Advanced Configuration .....	121
Figure 54: Datalogger Tab .....	128
Figure 55: System Configuration Tab .....	130
Figure 56: Power Mode Management Tab.....	131
Figure 57: Right Click on BeanDevice® Profile .....	132
Figure 58: Overview: Sensor channel profile.....	132
Figure 59: Sensor Channel General information frame.....	133
Figure 60: Measurement data frame .....	133
Figure 61: Sensor channel custom display tab .....	134
Figure 62: Hi-Inc sensor channel custom display tab .....	135
Figure 63: Unit Conversion Assistant.....	136
Figure 64: Sensor channel notes tab .....	137
Figure 65: Alarm configuration tab (BeanDevice® AX-3D) .....	137
Figure 66: Alarm configuration tab (BeanDevice® AX-3DS) .....	138
Figure 67: Shock detection configuration window.....	139
Figure 68: AX-3D Sensor calibration tab.....	143
Figure 69: AX-3D-SR sensor calibration 1.2g measurement range .....	143
Figure 70: AX-3D-SR sensor calibration 2.4g measurement range .....	144
Figure 71: Log configuration tab.....	144
Figure 72: Right Click on the Sensor's Channel.....	145
Figure 73: Overview: Channel acquisition graph visualization of the AX-3D .....	146
Figure 74: Real-time graph of the temperature channel on the AX-3D-SR.....	146
Figure 75: Sensor profile ON/OFF display button.....	147
Figure 76: Wide view of the graph .....	147
Figure 77: Example: Graph visualization .....	148
Figure 78: Graph measure mode: Frame Display .....	148
Figure 79: Graph measure mode: Frame Marks.....	149
Figure 80: BeanDevice® Datalogger tab .....	150
Figure 81: BeanScape® configuration menu.....	151
Figure 82: BeanScape® configuration window .....	152
Figure 83: BeanDevice® Custom Display tab .....	153
Figure 84: BeanDevice® custom display settings.....	153
Figure 85: Logfile settings.....	154
Figure 86: Log file generation options.....	155
Figure 87: Example of Log file.....	155
Figure 88: Data cache configuration options .....	156
Figure 89: Overview: Log Config tab on BeanScape® .....	157
Figure 90: Log config tab .....	157
Figure 91: Log file example (Streaming mode).....	159
Figure 92: Wireless Network Info log file .....	160
Figure 93: Calibration log file.....	164
Figure 94: Alarm management menu.....	165
Figure 95: Alarm management window .....	166
Figure 96: Frame: Email alarm for S.E.T mode .....	167

Figure 97: Frame: Sound config.....	167
Figure 98: Email alarm for Shock detection.....	168
Figure 99: Alarm Mailing SMTP Test.....	168
Figure 100: Email alarm for Alarm mode.....	168
Figure 101: Alarm Mailing SMTP Test.....	169
Figure 102: BeanDevice® Health Status management .....	169
Figure 103: System Alarm Settings .....	170
Figure 104: Enable/Disable Notif/mail for Diagnostic and Datalogger .....	170
Figure 105: File Format settings .....	170
Figure 106: Alarm Note settings.....	171
Figure 107: DIN 4150-3 Configuration.....	171
Figure 108: Building type & Pipeline Material on the DIN Report .....	172
Figure 109: Building type & Pipeline Material on the Velocity Log file .....	172
Figure 110: Crash Report settings .....	172
Figure 111: Tools tab main menu .....	173
Figure 112: Log file configuration.....	173
Figure 113: Keep Alive app .....	174
Figure 114: TCP/UDP configuration.....	174
Figure 115: System Config .....	175
Figure 116: Data Cache configuration .....	175
Figure 117: Data logger configuration .....	176
Figure 118: BeanScape® startup.....	176
Figure 119: Date & time settings .....	177
Figure 120: BeanScape® language.....	177
Figure 121: Alarm Window .....	178
Figure 122: Alarm window display .....	179
Figure 123: Import/Export feature .....	179
Figure 124: Custom user configuration section.....	180
Figure 125: user export settings.....	180
Figure 126: Custom_DB example .....	181
Figure 127: Custom user configuration window .....	181
Figure 128: Custom user configuration (merge) .....	182
Figure 129: Export window for BeanScape Config .....	182
Figure 130: BeanScape Config exportation .....	183
Figure 131: Import function for BeanScape Config .....	183
Figure 132: Notification Management Window.....	184
Figure 133: Offline graph menu on BeanScape® .....	184
Figure 134: Offline graph window .....	185
Figure 135: Grid display of graphs.....	185
Figure 136: Overlaid (frequency)display of FFT graphs .....	185
Figure 137: Data conversion example .....	186
Figure 138: Data Conversion menu on BeanScape® .....	187
Figure 139:Data Conversion window .....	187
Figure 140: Data Conversion main options .....	187
Figure 141: Importing files into Data Conversion tool .....	188
Figure 142: Overview of the selected files on Data Conversion window.....	188
Figure 143: Overview: Converted File Folder .....	189
Figure 144: Advanced settings.....	189
Figure 145: Advanced settings.....	189
Figure 146: Add BeanScape to Firewall .....	190



Figure 147: Notification message .....	190
Figure 148: SQL Server installation.....	190
Figure 149: installation notification for SQL Server Report.....	190
Figure 150: SQL Server Report Installation.....	191
Figure 151: Check MATLAB extension .....	191
Figure 152: Notification message .....	191
Figure 153: Download MATLAB extension .....	191
Figure 154: Client management .....	192
Figure 155: Client/Server Management .....	192
Figure 156: FTP Configuration .....	193
Figure 157: FTP configuration window.....	193
Figure 158: FTP Server settings .....	194
Figure 159: Failure details .....	195
Figure 160: the available type of files.....	195
Figure 161: Files stored on the FTP server .....	196
Figure 162: View tab.....	197
Figure 163: Standard View dashboard .....	197
Figure 164: BeanGateway® PAN ID .....	198
Figure 165: BeanGateway® profile .....	198
Figure 166: Expert View.....	203
Figure 167: Serial Key .....	203
Figure 168: Expert view dashboard .....	204
Figure 169: Tools options list on the expert view .....	209
<b>Figure 170: FFT offline data analysis on BeanScape® top menu .....</b>	<b>215</b>
<b>Figure 171: FFT tool window.....</b>	<b>215</b>
<b>Figure 172: FFT tool options .....</b>	<b>216</b>
<b>Figure 173: Browsing TX files on FFT tool .....</b>	<b>216</b>
<b>Figure 174: Overview: FFT window .....</b>	<b>217</b>
<b>Figure 175: FFT generation .....</b>	<b>217</b>
<b>Figure 176: FFT generated View .....</b>	<b>217</b>
<b>Figure 177: Generated FFT Log files .....</b>	<b>218</b>
<b>Figure 178: Graph display (Offline Data Analysis).....</b>	<b>218</b>
<b>Figure 179: Selecting a graph to display .....</b>	<b>219</b>
<b>Figure 180: Selected graph display.....</b>	<b>219</b>
<b>Figure 181: FFT invalid files .....</b>	<b>220</b>
<b>Figure 182: FFT Shift activation .....</b>	<b>220</b>
<b>Figure 183: Gird of FFT Shift spectra .....</b>	<b>221</b>
<b>Figure 184: DIN on BeanScape® top menu.....</b>	<b>222</b>
<b>Figure 185: Particle Velocity window .....</b>	<b>222</b>
<b>Figure 186: Browsing TX files into Particle Velocity tool .....</b>	<b>227</b>
<b>Figure 187: Particle Velocity result generation.....</b>	<b>228</b>
<b>Figure 188: Particle Velocity Display Window .....</b>	<b>228</b>
<b>Figure 189: VPPV &amp; DIN buttons .....</b>	<b>229</b>
<b>Figure 190: VPPV Report.....</b>	<b>229</b>
<b>Figure 191: DIN Report .....</b>	<b>229</b>
<b>Figure 192: Online FFT Configuration frame .....</b>	<b>231</b>
<b>Figure 193: FFT Spectrum.....</b>	<b>232</b>
<b>Figure 194: Online FFT Configuration frame .....</b>	<b>232</b>
<b>Figure 195: FFT log files folder.....</b>	<b>232</b>
<b>Figure 196: Enabling Automatic FFT Report .....</b>	<b>233</b>

<b>Figure 197: Report Folder</b> .....	233
<b>Figure 198: FFT Report (S.E.T mode)</b> .....	234
<b>Figure 199: FFT Shift Spectrum</b> .....	238
<b>Figure 200: Online Velocity configuration tab</b> .....	239
<b>Figure 201: Velocity Graph</b> .....	240
<b>Figure 202: Velocity and FFT Graph, PPV and PVS</b> .....	241
<b>Figure 203: DIN 4150 Real Time Graph, PPV &amp; PVS</b> .....	241
<b>Figure 204: DIN 4150-3 Report email</b> .....	242
Figure 205: Velocity Log Folder/Files.....	244
Figure 206: PPV Log Folder/Files .....	244
Figure 207: Velocity Advanced Configuration .....	245
Figure 208: Sensor design.....	255
Figure 209: Inclinometer Block Diagram (BeanDevice® HI-INC $\pm 30^\circ$ and $\pm 15^\circ$ versions).....	260
Figure 210: Inclinometer Block Diagram (BeanDevice® version) .....	261
Figure 211: BeanDevice® AX-3DS mems Sensor architecture.....	264
Figure 212: Overview: MEMS Accelerometer in BeanDevice® AX-3D.....	266
Figure 213: Network reed non-contact button .....	269
Figure 214: BeanDevice® health status option.....	270
Figure 215: BeanDevice® health status window .....	271
Figure 216: BeanDevice® Scrolling menu .....	272
Figure 217: BeanSensor: Enable/Disable Log .....	273
Figure 218: BeanSensor: Buffer Reset option .....	274
Figure 219: Buffer Reset .....	274
Figure 220: BeanSensor: Open the graph in a new window .....	274
Figure 221: Graphs opened in separated windows.....	275
Figure 222 :Windows search for firewall screenshot .....	278
Figure 223: allowed apps window .....	279
Figure 224: Firewall auto exception .....	279

## 1. TECHNICAL SUPPORT

---

For general contact, technical support, to report documentation errors and to order manuals, contact *Beanair Technical Support Center* (BTSC) at:

[tech-support@Beanair.com](mailto:tech-support@Beanair.com)

For detailed information about where you can buy the Beanair equipment/software or for recommendations on accessories and components visit:

[www.Beanair.com](http://www.Beanair.com)




To register for product news and announcements or for product questions contact Beanair's Technical Support Center (BTSC).

Our aim is to make this user manual as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Beanair appreciates feedback from the users of our information.

## 2. VISUAL SYMBOLS DEFINITION

---

<i>Symbols</i>	<i>Definition</i>
	<i><u>Caution or Warning</u> – Alerts the user with important information about Beanair wireless sensor networks (WSN), if this information is not followed, the equipment /software may fail or malfunction.</i>
	<i><u>Danger</u> – This information <b>MUST</b> be followed if not you may damage the equipment permanently or bodily injury may occur.</i>
	<i><u>Tip or Information</u> – Provides advice and suggestions that may be useful when installing Beanair Wireless Sensor Networks.</i>

### 3. ACRONYMS AND ABBREVIATIONS

---

<i>AES</i>	Advanced Encryption Standard
<i>CCA</i>	Clear Channel Assessment
<i>CSMA/CA</i>	Carrier Sense Multiple Access/Collision Avoidance
<i>GTS</i>	Guaranteed Time-Slot
<i>kSps</i>	Kilo samples per second
<i>LLC</i>	Logical Link Control
<i>LQI</i>	Link quality indicator
<i>LDCDA</i>	Low duty cycle data acquisition
<i>MAC</i>	Media Access Control
<i>PAN</i>	Personal Area Network
<i>PER</i>	Packet error rate
<i>RF</i>	Radio Frequency
<i>SD</i>	Secure Digital
<i>WSN</i>	Wireless sensor Network



## 4. RELATED DOCUMENTS & VIDEOS

### 4.1 WHITE PAPER WEBPAGE

Application notes, technical notes and user guides are available on our White Paper webpage:

[Click here](#)

Home	Products	Applications	Success Stories	Support	News & Events	Videos	About	Contact
Reference Number	Document Name	Related product	Description					
AN_RF_002	<a href="#">Structural Health Monitoring on bridges</a>	All BeanAir products	The aim of this document is to overview BeanAir® products suited for bridge monitoring, their deployment, as well as their capacity and limits by overviewing various data acquisition modes available on each BeanDevice®					
AN_RF_003	<a href="#">IEEE 802.15.4 2.4 GHz Vs 868 MHz</a>	All BeanAir products	Comparison between 868 MHz frequency band and a 2.4 GHz frequency band					
AN_RF_005	<a href="#">BeanGateway &amp; Data Terminal Equipment Interface</a>	BeanGateway®	DTE interface Architecture on the BeanGateway®					
AN_RF_006	<a href="#">How to extend your wireless range</a>	All BeanAir products	A guideline very useful for extending your wireless range					
AN_RF_007	<a href="#">BeanAir WSN Deployment</a>	All BeanAir products	Wireless sensor networks deployment guidelines					

Technical Notes			
Reference Number	Document Name	Related product	Description
TN-RF-001	<a href="#">Wireless range benchmarking</a>	BeanDevice® 2.4GHz Sensor series	Wireless range tests results of BeanDevice® 2.4GHz inside (N.L.O.S.) and outside a Building (L.O.S.)
TN-RF-002	<a href="#">Current consumption in active &amp; sleeping mode</a>	BeanDevice® 2.4GHz Sensor series	Current consumption estimation in active and sleeping mode.
TN-RF-003	<a href="#">Aggregation capacity of Wireless Network</a>	BeanDevice® 2.4GHz Sensor series	Overview of aggregation capacity of wireless sensor networks in streaming mode
TN-RF-004	<a href="#">MQTT Communication Protocol</a>	BeanDevice® Willow® sensor series	MQTT Communication Protocol for a seamless integration into a third-party IOT software

***[Figure 1 : White Paper webpage](#)***

## 4.2 FEATURED VIDEOS



*All the videos are available on our YouTube channel*

<i>Beanair video link (YouTube)</i>	<i>Related products</i>
<a href="#">First step into Beanair Wireless Sensor Networks</a>	<i>All</i>
<a href="#">Wireless Sensor Networks</a>	<i>All</i>
<a href="#">Wireless Sensor Networks dedicated to Structural Health Monitoring</a>	<i>All</i>
<a href="#">BeanGateway® - Ethernet Outdoor version introduction</a>	<i>BeanGateway® - Ethernet Outdoor version introduction</i>
<a href="#">BeanGateway® – Ethernet Indoor version presentation</a>	<i>BeanGateway® Ethernet Indoor version</i>
<a href="#">BeanDevice® AN-XX wireless range demonstration</a>	<i>BeanDevice® AN-V/AN-420/AN-mV Standard and Extender</i>
<a href="#">BeanDevice® AN-XX presentation</a>	
<a href="#">Self-powered data logger</a>	<i>BeanDevice® AN-V/AN-420/AN-mV Xtender</i>
<a href="#">BeanDevice® AX-3D presentation</a>	<i>BeanDevice® AX-3D</i>
<a href="#">BeanDevice® HI-INC presentation</a>	<i>BeanDevice® HI-INC</i>
<a href="#">Wireless inclinometer with integrated datalogger</a>	
<a href="#">BeanDevice® AX-3DS presentation</a>	<i>BeanDevice® AX-3DS</i>
<a href="#">Wireless Accelerometer dedicated to shock detection</a>	
<a href="#">High performance wireless accelerometer</a>	<i>BeanDevice® AX-3D Xrange</i>
<a href="#">Wireless temperature and humidity sensor with integrated data logger</a>	<i>BeanDevice® ONE-TH</i>
<a href="#">High performance wireless inclinometer</a>	<i>BeanDevice® HI-INC Xrange</i>
<a href="#">High Grade and affordable wireless sensor networks for environmental monitoring</a>	<i>Ecosensor products</i>

### 4.3 TECHNICAL VIDEOS

---



*All the videos are available on our YouTube channel!*

<i>Beanair video link (Youtube)</i>	<i>Related products</i>
<a href="#">How to launch the BeanScape® software</a>	<i>BeanScape®</i>
<a href="#">BeanGateway® Ethernet/LAN Configuration, directly connected to the Laptop/PC</a>	<i>BeanGateway®</i>
<a href="#">How to remove a BeanDevice® from your Network</a>	<i>BeanDevice®</i>
<a href="#">Energy Scan</a>	<i>BeanGateway®</i>
<a href="#">Synchronous Multicasting process</a>	<i>BeanGateway®</i>
<a href="#">Manual channel selection</a>	<i>BeanGateway®</i>
<a href="#">Automatic Channel selection</a>	<i>BeanGateway®</i>
<a href="#">Authorized Channels</a>	<i>BeanGateway®</i>
<a href="#">Fast Fourier Transform waveform analysis module</a>	<i>BeanScape®</i>

## 5. ACRONYMS AND ABBREVIATIONS

---

### BeanDevice® product overview

- Details the BeanDevice® product presentation

### Data acquisition mode description

- Details the data acquisition mode available on the BeanDevice®
- **Related Technical Note:** TN\_RF\_008 - "Data acquisition mode available on the BeanDevice®"

### BeanDevice® installation guidelines

- Details the installation guidelines of the BeanDevice®
- **Related Technical Note:** TN\_RF\_010 - "Beandevic® Power Management "
- **Related Technical Note:** TN\_RF\_007- "Beandevic® DataLogger user Guide"
- **Related Technical Note:** TN\_RF\_006- "Beandevic® wireless network association"

### BeanDevice® supervision from the Beanscape®

- Details the BeanDevice® supervision from the Beanscape®

### BeanDevice® maintenance & supervision (for experienced user)

- Details the BeanDevice® maintenance (for experienced user)

### Troubleshooting

- Frequently asked questions

### Installation procedures

- Details the installation procedures

## 6. PRODUCT DESCRIPTION

---



- ✓ ***It is highly recommended to read all the user manual related to Beanair software & equipment (BeanScape® 2.4GHz, BeanGateway® 2.4GHz, BeanDevice® 2.4GHz) before getting start your BeanDevice® 2.4GHz.***
- ✓ ***Use only accessories supplied by Beanair (batteries, power supply unit, and antenna). Use of other materials may damage the BeanDevice® 2.4GHz;***
- ✓ ***Only Beanair is qualified to make changes on the BeanDevice® 2.4GHz;***
- ✓ ***Don't try to remove the adhesive label on the product; it contains important information such as the MAC address or sensor measurement range***

### 6.1 ABOUT SMARTSENSOR PRODUCT LINE

---

Smart Sensor product line was initially designed for Structural Health monitoring (SHM), Condition Maintenance Monitoring (CMS) and Testbed applications.

It comes with different types of sensors for dynamic measurements:

- Wireless accelerometer for vibration measurement
- Wireless inclinometer for tilt/slope measurement
- Wireless shock sensor for shock monitoring



## 6.2 BEANDEVICE® 2.4GHZ AX-3D

### 6.2.1 Featured video



[Click here](#)

### 6.2.2 Main features

#### Main Features

- Wireless Tri-axis accelerometer based on MEMS Technology
- Measurement range:  $\pm 2g$ ,  $\pm 10g$
- Very Low noise Density:
- $45 \mu g/\sqrt{Hz}$  ( $\pm 2g$  version),  $100 \mu g/\sqrt{Hz}$  ( $\pm 10g$  version),
- Excellent radio link thanks to the radio antenna diversity developed by Beanair®
- Maximum sampling rate: 3 KSPS
- **TimeSync function:** Time Synchronization through wireless sensor network
- Maximum Radio Range: 500 m (L.O.S)
- Ultra-Power Radio Technology IEEE 802.15.4
- Current consumption in idle mode: **< 30 uA**
- Embedded logger: up to **1 million** data points (with events dating)
- Entirely autonomous system with an integrated Lithium-Ion battery charger
- Anti-aliasing Butterworth filter (**5<sup>th</sup> order**) with a cut-off frequency of **1 Hz to 2 KHz** (remotely programmable from the BeanScape®)
- Watertight Aluminum AL6061 & Waterproof casing IP67 (dimensions LxLxh : 100x55x36 mm - weight 155g rechargeable battery included) - suitable for Harsh Industrial Environment



### 6.2.3 Applications

This BeanDevice® AX-3D is suitable for the following applications:

- [Ground vibration Monitoring on construction site](#)
- [Dynamic measurement on rolling stock](#)
- [Condition monitoring](#)
- [Structural Health Monitoring \(SHM\)](#)
- [Vibration analysis](#)

## 6.3 BEANDEVICE® 2.4GHZ AX-3D-SR

### 6.3.1 Featured video



[Wireless and low noise IOT vibration sensor](#)

### 6.3.2 Main features

#### Main Features

- Wireless Tri-axis accelerometer based on MEMS Technology
- Measurement range:  $\pm 1.2g/\pm 2.4g$
- Very Low noise Density:
- $20 \mu g/\sqrt{Hz}$  ( $\pm 1.2g$  measurement range),  $32 \mu g/\sqrt{Hz}$  ( $\pm 2.4g$  measurement range),
- Excellent radio link thanks to the radio antenna diversity developed by Beanair®
- Maximum sampling rate: 800 SPS for  $\pm 2.4g$  (static range)  
400 SPS for  $\pm 1.2g$  (static and auto range), for  $\pm 2.4g$  (Auto range).
- **TimeSync function:** Time Synchronization through wireless sensor network
- Maximum Radio Range: 500 m (L.O.S)
- Ultra-Power Radio Technology IEEE 802.15.4
- Current consumption in idle mode: **< 30 uA**
- Embedded logger: up to **1 million** data points (with events dating)
- Entirely autonomous system with an integrated Lithium-Ion battery charger
- Anti-aliasing Butterworth filter (**5<sup>th</sup> order**) with a cut-off frequency of **1 Hz to 2 KHz** (remotely programmable from the BeanScape®)
- Watertight Aluminum AL6061 & Waterproof casing IP67 (dimensions Lxlxh : 100x55x36 mm - weight 155g rechargeable battery included) - suitable for Harsh Industrial Environment



### 6.3.3 Applications


This BeanDevice® AX-3D is suitable for the following applications:

- [Ground vibration Monitoring on construction site](#)
- [Dynamic measurement on rolling stock](#)

- Condition monitoring
- Structural Health Monitoring (SHM)
- Vibration analysis

## 6.4 BEANDEVICE® 2.4GHZ HI-INC - 2.4GHZ SERIES (WIRELESS INCLINOMETER)

### 6.4.1 Main features

BeanDevice® HI-INC: Wireless Inclinator	Main Features	
	<ul style="list-style-type: none"> <li>• Wireless Inclinator based on MEMS Technology</li> <li>• Measurement range:               <ul style="list-style-type: none"> <li>○ bi-axis <math>\pm 30^\circ</math></li> </ul> </li> <li>• Excellent resolution:               <ul style="list-style-type: none"> <li>○ 0,001°</li> </ul> </li> <li>• <b>TimeSync function:</b> Time Synchronization through wireless sensor network</li> <li>• Excellent radio link thanks to the antenna diversity developed by Beanair®</li> <li>• Streaming mode: 200 SPS on each channel</li> <li>• Maximum Radio Range: 500 m (L.O.S)</li> <li>• Ultra-Power Radio Technology IEEE 802.15.4</li> <li>• Current consumption in idle mode: &lt; 30 uA</li> <li>• Embedded logger: up to 1 000 000 data acquisition records (with events dating)</li> <li>• Entirely autonomous system with an integrated Lithium-Ion battery charger</li> <li>• Anti-aliasing Butterworth filter (5<sup>th</sup> order) with a cut-off frequency of 1 Hz to 100 Hz (remotely programmable from the BeanScope®)</li> <li>• Watertight Aluminum enclosure IP67</li> <li>• Dimensions LxWxH : 100x55x36 mm—weight 155g (rechargeable battery included) -suitable for Harsh Industrial Environment</li> </ul>	

### 6.4.2 Applications

- ✓ Platform Leveling and stabilization
- ✓ Laser level rotation
- ✓ Slope measurement (Building, infrastructure & construction)

- ✓ Oil drilling
- ✓ Axial rotor measurement

## 6.5 BEANDEVICE® 2.4GHZ AX-3DS - 2.4GHZ SERIES (WIRELESS SHOCK SENSOR)

### 6.5.1 Main features

#### Main Features

- Wireless tri-axis accelerometer
- Scalable measurement range (two versions) :  
 **$\pm 6g/\pm 12g/\pm 24g$  or  $\pm 2g/\pm 4g/\pm 8g$**
- Excellent radio link thanks to the antenna diversity developed by Beanair®
- Advanced and smart shock detection
- Non-contact actuation for faster installation
- Maximum sampling rate: 3 KSPS (maximum)
- Maximum radio range: 500 m (L.O.S)
- Ultra-Low Power Radio Technology IEEE 802.15.4
- Current consumption during deep sleeping mode: < 28 uA
- **Embedded Data Logger:** up to **1 million** data points
- Entirely autonomous system with an integrated Lithium-Ion battery charger
- **Watertight aluminum enclosure IP67** (dimensions LxWxH: 100x55x36mm)—weight 155g (rechargeable battery included) -suitable for Harsh Industrial Environment



### 6.5.2 Applications

- ✓ Health and usage monitoring systems (HUMS)
- ✓ Shock measurement on vehicles & trains
- ✓ Transportation Monitoring
- ✓ Drop testing
- ✓ Crash and impact testing
- ✓ Ride Quality Measurement

## 6.6 BEANDEVICE® 2.4GHZ AX-3D XRANGE – 2.4GHZ SERIES (HIGH PERFORMANCE WIRELESS ACCELEROMETER)

### 6.6.1 Main features

#### Main Features

- Wireless Tri-axis accelerometer based on MEMS Technology
- Measurement range (2 versions):  $\pm 2g$  &  $\pm 10g$
- Very Low noise Density:
  - $45 \mu g/VHz$  ( $\pm 2g$  version)
  - $100 \mu g/VHz$  ( $\pm 10g$  version)
- **TimeSync function:** Time Synchronization through wireless sensor network
- Watertight IP67 aluminum enclosure coming with a rugged base plate and three-point-mounting
- Excellent radio link relying on the radio antenna diversity developed by Beanair®
- Non-contact actuation for quick mounting
- Maximum sampling rate: 3 KSPS
- Maximum Radio Range: 500 m (L.O.S)
- Ultra-Power radio technology IEEE 802.15.4
- Current consumption in sleeping mode:  $< 30 \mu A$
- Embedded data logger: up to **8 million** data points
- OPC server allowing real time access from your IT system to the BeanScope® (available on [BeanScope® Premium+](#))
- Entirely autonomous system with an integrated Lithium-Ion battery charger
- Anti-aliasing Butterworth filter (5<sup>th</sup> order) with a cut-off frequency of 1 Hz to 2 KHz (remotely programmable from the BeanScope®)
- Fully calibrated sensor



### 6.6.2 Applications

This BeanDevice® AX-3D Xrange is suitable for the following applications:

- [Ground vibration Monitoring on construction site](#)
- [Dynamic measurement on rolling stock](#)
- [Condition monitoring](#)
- [Structural Health Monitoring \(SHM\)](#)
- [Vibration analysis](#)

## 6.7 BEANDEVICE® HI-INC XRANGE (HIGH PERFORMANCE WIRELESS INCLINOMETER)

### 6.7.1 Main features


#### Main Features

- Wireless Inclinator based on MEMS Technology
- Measurement range:  $\pm 30^\circ$  (bi-axis)
- Excellent resolution ( $0.001^\circ$ ) & accuracy ( $\pm 0.05^\circ$ )
- Temperature compensated sensor
- Excellent radio link thanks to the antenna diversity developed by Beanair®
- Non-contact actuation for quick mounting
- Maximum sampling rate: 200 SPS
- Maximum radio range: 500 m (L.O.S)
- Ultra-Power Radio Technology IEEE 802.15.4
- Current consumption in sleeping mode:  $< 30 \mu\text{A}$
- Embedded data Logger: up to **8 million** data points
- OPC server allowing real time access from your IT system to the BeanScape® (available on [BeanScape® Premium+](#))
- Entirely autonomous system with an integrated Lithium-Ion battery charger
- Watertight IP67 aluminum enclosure coming with a rugged base plate and three-point-mounting
- Anti-aliasing Butterworth filter (5<sup>th</sup> order) with a cut-off frequency of 1 Hz to 100Hz (remotely programmable from the BeanScape®)
- Fully calibrated sensor



## 6.8 BEANDEVICE® 2.4GHZ HI-INC-SR - 2.4GHZ SERIES (TRI-AXIS WIRELESS INCLINOMETER)

### 6.8.1 Main features

BeanDevice® HI-INC-SR: Tri-axis Wireless Inclinometer	Main Features	
	<ul style="list-style-type: none"> <li>• Wireless Tri Axis Inclinometer based on MEMS Technology</li> <li>• Measurement range:               <ul style="list-style-type: none"> <li>○ 10T: Tri-axis <math>\pm 10^\circ / \pm 90^\circ</math></li> </ul> </li> <li>• Excellent resolution:               <ul style="list-style-type: none"> <li>○ 0,0055°</li> </ul> </li> <li>• <b>TimeSync function:</b> Time Synchronization through wireless sensor network</li> <li>• Excellent radio link thanks to the antenna diversity developed by Beanair®</li> <li>• Streaming mode:               <ul style="list-style-type: none"> <li>○ 20 SPS on each channel, for <math>\pm 10^\circ</math> measurement range</li> <li>○ 80 SPS on each channel, for <math>\pm 90^\circ</math> measurement range</li> </ul> </li> <li>• Maximum Radio Range: 500 m (L.O.S)</li> <li>• Ultra-Power Radio Technology IEEE 802.15.4</li> <li>• Current consumption in idle mode: <b>&lt; 30 uA</b></li> <li>• Embedded logger: up to 8 million data acquisition records (with events dating)</li> <li>• Entirely autonomous system with an integrated Lithium-Ion battery charger</li> <li>• Anti-aliasing Butterworth filter (5<sup>th</sup> order) with a cut-off frequency of 1 Hz to 100 Hz (remotely programmable from the BeanScape®)</li> <li>• Aluminum AL6061 enclosure IP67   Nema 6</li> <li>• Dimensions LxWxH : 80x55x36 mm—weight 155g (rechargeable battery included) -suitable for Harsh Industrial Environment</li> </ul>	

### 6.8.2 Applications

- ✓ Land Survey
- ✓ Structural Health Monitoring (SHM)
- ✓ Test & Measurement
- ✓ Railway sleepers monitoring

## 6.9 TECHNICAL SPECIFICATIONS

### 6.9.1 BeanDevice® 2.4GHz AX-3D

<i>Product reference</i>
BND-2.4GHZ-AX3D-MRG-RB
<b>MR – Measurement Range (1g = 9806.65 mm/s<sup>2</sup>)</b>
<b>2:</b> ±2g measurement range
<b>10:</b> ±10g measurement range
<b>Example:</b> <i>BND-2.4GHZ-AX3D-10G-RB, Wireless Accelerometer with 10g measurement range</i>

	Accelerometer Specifications
Accelerometer technology	Accurate and low power MEMS technology
Sensitivity	±2g Version: 61 µg/digit ±10g version: 305 µg/digit
Typical non-linearity (Full scale, @ 25°C)	±0.1%
Analog to Digital converter	16-bit, SAR architecture (Successive Approximation Register) with temperature compensation
Sensor frequency response (-3 dB)	DC to 800 Hz
Noise spectral density	±2g Version: 45 µg/√Hz ±10g version: 100 µg/√Hz
Zero-g Offset Variation from RT over Temp	±2g Version: ±0.2 mg/°C ±10g version: ±0.1 mg/°C
Sensitivity Variation from RT over Temp	±2g Version: ±0.01 %/°C (XY), ±0.02 %/°C (Z) ±10g version: ±0.01 %/°C
Offset Ratiometric Error	±2g Version: 4mg ±10g version: ±0.2% (XY), ±0.1% (Z)
Sensitivity Ratiometric Error	±2g Version : ±1.25 % (X-Y), ±0.2 % (Z) ±10g Version : ±1.6% (X-Y) , ±0.2 % (Z)
Cross Axis Sensitivity	2%
Anti-aliasing Hardware filter	Butterworth 5 <sup>th</sup> order filter – cut-off frequency: 1 Hz to 2000 Hz remotely programmable (BeanScope®)



Configurable settings from the BeanScope® 2.4GHz software	
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) Mode Measurement heartbeat 1s to 24 hour  Dynamic data acquisition: Streaming and S.E.T. ( Streaming with Event Trigger)
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 10 SPS Maximum: 3 kSPS per axis (one axis enabled) 1.5 kSPS per axis (2-axis enabled) 1 kSPS per axis (3-axis enabled)
Programmable Cut-off frequency (Anti-aliasing filter)	1– 2000 Hz
Power Mode	Battery saver mode & Active power mode

RF Specifications	
Wireless Technology	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

Embedded Data logger	
Storage capacity	up to 1 million data points
Wireless data downloading	3 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm

Environmental and Mechanical	
Casing	Aluminum AL6061 & Waterproof casing Dimensions in mm (LxWxH): 100x55x36 mm Weight : 155g

IP   NEMA Rating	IP67   Nema 6
Shock resistance	100g during 50 ms
Operating Temperature	-40 °C to +60 °C
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul> ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @ 3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 20 to 30 mA</li> <li>· During Radio transmission : 70 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 30 µA</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable Lithium-Polymer battery	Capacity 1.25 Ah

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V
M8 extension cable for external power supply	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
Calibration certificate	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.9.2 BeanDevice® AX-3D-SR

<i>Product reference</i>
BND-2.4GHZ-AX-3D-SR- <i>MR-PS-MO</i>
<b>MR– Measurement Range:</b> <b>1.2T:</b> tri-axis Low noise vibration sensor $\pm 1.2g/\pm 2.4g$
<b>PS - Power supply:</b> <b>RB:</b> Internal rechargeable battery
<b>MO - Mounting Option</b> SCM - Screw Mounting Lid MM - Magnetic Mounting Lid
<b>Example 1:</b> <i>BND-2.4GHZ-AX-3D-SR-1.2T-RB-SCM</i> , Low Noise wireless Vibration sensor with $\pm 1.2G/\pm 2.4G$ measurement range, internal rechargeable battery, Screw mounting <b>Example 2:</b> <i>BND-2.4GHZ-AX-3D-SR-1.2T-RB-MM</i> , Low Noise wireless Vibration sensor with $\pm 1.2G/\pm 2.4G$ measurement range, internal rechargeable battery, Magnetic Mounting

	Accelerometer sensor
Inclinometer Technology	Accurate and low power MEMS technology
Scalable Measuring Range	user-selectable range $\pm 1.2g$ or $\pm 2.4g$ , with automatic range adjustment depending on the application
Sensor resolution	0.17mg
Noise density	20 $\mu g/\sqrt{Hz}$ for $\pm 1.2G$ measurement range 32 $\mu g/\sqrt{Hz}$ for $\pm 2.4G$ measurement range
Sensor precision (full scale, @ 25°C @1HZ sampling rate)	$\pm 1mg$ for $\pm 1.2G$ measurement range $\pm 2mg$ for $\pm 2.4G$ measurement range
Sensitivity temperature dependency (temperature range -25°C to +85°C)	$\pm 0.3\%$
Offset LifeTime Drift (@25°C)	$\pm 4mg$
Sensor frequency Response (-3 dB)	DC to 40 Hz for $\pm 1.2g$ measurement range DC to 70 Hz for $\pm 1.2g$ measurement range

Calibrations	<p>Factory calibrated for both ranges <math>\pm 1.2g</math> and <math>\pm 2.4g</math> with calibration settings backed up on the sensor Flash memory.</p> <p>Calibration method used: Back-to-back calibrated with a reference sensor. Sensors can be re-calibrated by the user.</p>
--------------	--

Integrated Temperature sensor	
Temperature Range	-40°C to +75°C
Measurement resolution	$\pm 0.06^\circ\text{C}$
Sensor Precision	$\pm 1^\circ\text{C}$

Configurable settings from the BeanScope® 2.4GHz software	
Data Acquisition mode (SPS = sample per second)	<p>Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) and Alarm Mode (based on alarm thresholds). Measurement heartbeat 1s to 24 hour</p> <p>Dynamic data acquisition (not available on devices with ref. extension XT): Streaming and S.E.T. (Streaming with Event Trigger) Mode</p>
Sampling Rate (in streaming and S.E.T. mode)	<p>Minimum: 10 SPS</p> <p>Maximum: 20 SPS on each axis, for <math>\pm 1.2g</math> measurement range (Static and Auto Range), for <math>\pm 2.4g</math> measurement range (Auto Range) , Maximum: 800 SPS on each axis , for <math>\pm 2.4g</math> measurement range (Static Range)</p>
Alarm Threshold	Three-level alarms: Alert < Action < Alarm
Scalable Measurement Range	$\pm 1.2g$ , $\pm 2.4g$ and automatic $\pm 1.2g/\pm 2.4g$
Power Mode	Battery saver mode & Active power mode (Active Power Mode is not available on -XT version)

RF Specifications	
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm

Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional random antenna with antenna diversity Gain: 3 dBi Waterproof IP67

Embedded data logger	
Storage capacity	up to 8 million data points
Wireless data downloading	20 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	$\pm 2.5$ ms (at 25°C)
Crystal specifications	Tolerance $\pm 10$ ppm, stability $\pm 10$ ppm

Environmental and Mechanical	
Casing	Aluminum AL6061 & Waterproof casing  · Dimensions in mm (LxWxH): 100 x 71 x 38 (without Radome antennas, with mounting eyelet) · Weight (with internal battery) : 225g (screw mounting) 252g (magnetic mounting)
IP   NEMA Rating	IP67   Nema 6
Base plate	· Aluminum black anodized AL 7075 with rugged three-point-mounting · Screw Mounting Option: the device should be mounted on a flat and smooth surface with 3 screws, dimension M5. Mounting torque $5 \pm 1$ Nm · Magnetic Mounting Option: the device should be mounted on a steel surface.
Shock resistance	150g during 50 ms

Operating Temperature	<b>RB : Internal rechargeable battery</b> -40°C to +60°C <b>XT : External Power Supply</b> -40°C to +75°C during battery discharge
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul>
	ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring: <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition: 30 to 40 mA</li> <li>· During Radio transmission: 55 mA @ 18 dBm</li> <li>· During Battery Saver Mode: &lt; 30 µA</li> </ul>
External power supply	8-28VDC with reverse polarity protection IEC-61000-4-2: ESD 30kV (Air), 30kV (Contact) Surge protection > 28VDC (600W during 10us max)
Rechargeable battery	2 Ah, Lithium-Polymer battery

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V

Standalone Solar System	<p>High efficiency solar panel with <b><u>with Solar charging controller and Lead-acid battery</u></b></p> <p>Ref.: X-SOL-7AH-20W-4V-5M for XT version  Ref.: X-SOL-7AH-20W-12V-5M for RB version  Ref: X-SOL-14AH-20W-4CH-4V-5M for XT version  Ref: X-SOL-14AH-20W-4CH-12V-5M for RB version  Ref: X-SOL-14AH-80W-4CH-4V-5M for XT version  Ref: X-SOL-14AH-80W-4CH-12V-5M for RB version</p> <p>More options and references are available on X-SOLAR datasheet</p>
Bracket Mounting	<p>90° Bracket for BeanDevice (Xrange smartsensor) with 4 x M5 screws + Locknut</p> <p>Ref: SMART-BRACK-MNT</p>
M8 extension cable for external power supply	<p>Molded cable with M8-3pins male plug</p> <p>Material: PVC with shield protection</p> <p>IP Rating : IP67   Nema 6</p> <p>Cable length: 2 meters , Ref: CBL-M8-2M</p> <p>Cable length : 5 meters, Ref: CBL-M8-5M</p> <p>Cable length: 10 meters, Ref: CBL-M8-10M</p>
Calibration certificate	<p>Calibration certificate provided by Beanair GmbH</p> <p>A static calibration method is used on a granite surface plate DIN876</p> <p>Ref: CERT-CAL-SMART</p>

## 6.9.3 BeanDevice® AX-3DS

<i>Product reference</i>
BND-2.4GHZ-AX3DS -MR-RB-MO
<b>MR – Measurement Range (1g = 9806.65 mm/s<sup>2</sup>)</b> <b>24G:</b> ±6/12/24g measurement range <b>8G:</b> ±2/4/8g measurement range
<b>PS - Power supply :</b> <b>RB :</b> Rechargeable battery
MO - Mounting Option SCM - Screw Mounting Lid MM - Magnet Mounting Lid Leave it empty if there is no mounting option
<b>Example 1:</b> BND-2.4GHZ-AX3DS-24G-RB—Wireless Accelerometer with ±6/12/24g measurement range, rechargeable battery <b>Example 2:</b> BND-2.4GHZ-AX3DS-8G-RB-SCM—Wireless Accelerometer with ±2/4/8g measurement range, rechargeable battery, screw mounting option

	Sensor specifications
Accelerometer Technology	Low power MEMS technology
Scalable measurement range	<b>24G Version:</b> ±6g / ±12g / ±24g <b>8G Version:</b> ±2g / ±4g / ±8g
Measurement resolution	<b>24G Version:</b> 3 mg/digit @±6g , 6 mg/digit @±12g , 12 mg/digit @±24g <b>8G Version:</b> 1mg/digit @±2g , 2 mg/digit @±4g , 3.9 mg/digit @±8g
Typical non-linearity (Full scale, @ 25°C)	±0,15% for the version BND-2.4GHZ-AX3DS-8G-RB ±0,19% for the version BND-2.4GHZ-AX3DS-24G-RB
Sensitivity change Vs temperature	±0,01% /°C
Zero-g level change vs temperature (max delta from 25°C)	<b>24G Version:</b> ±0,4 mg/°C <b>8G Version:</b> ±0,1 mg/°C
Typical zero-g level offset accuracy	<b>24G Version:</b> ±70 mg <b>8G Version:</b> ±20 mg
Analog to Digital converter	12-bit with temperature compensation
Noise spectral density @ BW 10Hz	<b>24G Version:</b> 650 µg/√Hz <b>8G Version:</b> 218 µg/√Hz
Anti-aliasing filter	Butterworth 2th order filter



	Configurable settings from the BeanScope® 2.4GHz software
Data Acquisition mode (SPS = sample per second)	Dynamic data acquisition: Streaming and SSD ( Smart Shock Detection)
Shock detection function	<ul style="list-style-type: none"> <li>· Shock threshold in mg</li> <li>· Data acquisition sample rate in sleeping mode</li> <li>· Data acquisition sample rate after the shock detection</li> <li>· Shock detection hysteresis</li> </ul>
Sampling Rate (in streaming mode)	Minimum: 1 SPS Maximum: 3 kSPS per axis (one axis enabled) 1.5 kSPS per axis (2-axis enabled) 1 kSPS per axis (3-axis enabled)
Power Mode	Battery saver mode & Active power mode

	RF Specifications
Wireless Technology	Ultra-Low-Power and license-free 2.4GHz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

	Embedded Data logger
Storage capacity	up to 1 million data points
Wireless data downloading	3 minutes to download the full memory (average time)

	Environmental and Mechanical
Casing	Aluminum AL6061 & Waterproof casing Dimensions in mm (LxWxH): 100x55x36 mm Weight : 155g
IP   NEMA Rating	IP67   Nema 6
Shock resistance	100g during 50 ms

Operating Temperature	-40 °C to +60 °C
Norms	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul> ROHS - Directive 2002/95/EC

	Power Supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 20 to 30 mA</li> <li>· During Radio transmission : 60 mA @ 18 dBm</li> <li>· During sleeping mode: 68uA</li> <li>· During Battery Saver mode : 28 uA</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable battery	Capacity 1.25 Ah

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V
M8 extension cable for external power supply	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
Calibration certificate	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.9.4 BeanDevice® INC

Product reference
BND-2.4GHZ-INC- <b>MR-PS</b>
<b>MR- Measurement Range:</b> <b>30B</b> : bi-axial $\pm 30^\circ$ <b>90B</b> : bi-axial $\pm 90^\circ$
<b>PS - Power supply :</b> <b>RB</b> : Internal rechargeable battery <b>XT</b> : External Power Supply
<b>Example 1:</b> BND-2.4GHZ-INC-30B-RB-wireless bi-axial inclinometer with $\pm 30^\circ$ measurement range, internal rechargeable battery <b>Example 2:</b> BND-2.4GHZ-INC-90B-XT-wireless bi-axial inclinometer with $\pm 90^\circ$ measurement range, external primary cell

	Sensor specifications
Inclinometer Technology	Accurate and low power MEMS technology
Measurement resolution (Bandwidth 10 Hz)	0.0025°
Noise density	0.0008 °/√Hz
Measurement Repeatability (full scale, @ 25°C, Static Measurement Mode every 2s)	±0.04° for bi-axis $\pm 30^\circ$ version ±0.08° for bi-axis $\pm 90^\circ$ version
Offset temperature dependency	±0.008 °/°C
Sensitivity temperature dependency	±0.008 %/°C
Long term stability (@23°C)	< 0.014 °
Analog to Digital converter	16-bits, SAR architecture (Successive Approximation Register) with temperature compensation
Sensor frequency Response (-3 dB)	DC to 28 Hz
Noise spectral density DC to 100 Hz	0.0008 °/√Hz
Anti-aliasing Hardware filter	Butterworth 5 <sup>th</sup> order filter – cut-off frequency : 1 Hz to 100 Hz remotely programmable (BeanScape®)

Configurable settings from the BeanScope® 2.4GHz software	
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) and Alarm Mode (based on alarm thresholds). Measurement heartbeat 1s to 24 hours  Dynamic data acquisition (not available on devices with ref. extension XT): Streaming and S.E.T. (Streaming with Event Trigger) Mode
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 1 SPS Maximum: 100 SPS on each axis
Alarm Threshold	Three-level alarms: Alert < Action < Alarm
Programmable cut-off frequency (Anti-aliasing filter)	1– 100 Hz
Power Mode	Battery saver mode & Active power mode (not available on XT version, External power supply)

RF Specifications	
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional random antenna with antenna diversity Gain : 3 dBi Waterproof IP67

Embedded Data logger	
Storage capacity	up to 1 million data points
Wireless data downloading	3 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm

	Environmental and Mechanical
Casing	Aluminum AL6061 & Waterproof casing
	Dimensions in mm (LxWxH): 100x55x36 mm Weight : 155g
IP   NEMA Rating	IP67   Nema 6
Shock resistance	100g during 50 ms
Operating Temperature	<b>RB : Internal rechargeable battery</b> -40 °C to +60 °C <b>XT : External Power Supply</b> -40 °C to +75 °C during battery discharge
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul> ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 30 to 40 mA</li> <li>· During Radio transmission : 80 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 38 µA</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable battery	High density Lithium-Ion rechargeable battery with a capacity of 950 mAh

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V

<b>Solar Panel Kit (compatible with External Power Supply version only)</b>	High efficiency solar panel with with Solar charging controller and Lead-acid battery Ref: X-SOL-5W-M8-2M
<b>External Primary Cell in a Waterproof IP67 Casing</b>	Waterproof IP67 battery box for long-term monitoring applications IP67 Battery Holder Battery Pack with 3 x C size primary cell, Li-SOCL2 Lithium Primary cell 3.6VDC Type Ref: PRIM-XTENDER
<b>M8 extension cable for external power supply</b>	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
<b>Calibration certificate</b>	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.9.5 BeanDevice® HI-INC

Product reference	
BND-2.4GHZ-HI-INC- <i>MR-PS</i>	
<b>MR– Measurement Range:</b> 30B : bi-axis $\pm 30^\circ$	<b>PS - Power supply :</b> <b>RB</b> : Internal rechargeable battery <b>XT</b> : External power supply
<p><b>Example 1:</b> BND-2.4GHZ-HI-INC-30B-RB-wireless bi-axial inclinometer with <math>\pm 30^\circ</math> measurement range, internal rechargeable battery</p> <p><b>Example 2:</b> BND-2.4GHZ-HI-INC-30B-XT-wireless <b>bi-axial</b> inclinometer with <math>\pm 30^\circ</math> measurement range, external primary cell</p>	

	Sensor specifications
Inclinometer Technology	Accurate and low power MEMS technology
Measurement resolution (Bandwidth 10 Hz)	0.001°
Noise density	0.0004 °/VHz
Measurement Repeatability (full scale, @ 25°C, Static Measurement Mode every 2s)	$\pm 0.006^\circ$
Offset temperature dependency	$\pm 0.002^\circ/\text{C}$
Sensitivity temperature dependency	$\pm 0.005\%/\text{C}$
Long term stability (@23°C)	< 0.004 °
Analog to Digital converter	16-bits, SAR architecture (Successive Approximation Register) with temperature compensation
Sensor frequency Response (-3 dB)	DC to 28 Hz
Noise spectral density DC to 100 Hz	0.0004 °/ VHz
Anti-aliasing Hardware filter	Butterworth 5 <sup>th</sup> order filter – cut-off frequency : 1 Hz to 100 Hz remotely programmable (BeanScape®)

Configurable settings from the BeanScope® 2.4GHz software	
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) and Alarm Mode (based on alarm thresholds) . Measurement heartbeat 1s to 24 hour  Dynamic data acquisition(not available on devices with ref. extension XT ): Streaming and S.E.T. (Streaming with Event Trigger) Mode
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 1 SPS Maximum: 100 SPS on each axis
Alarm Threshold	Three-level alarms : Alert < Action < Alarm
Programmable cut-off frequency (Anti-aliasing filter)	1– 100 Hz
Power Mode	Battery saver mode & Active power mode (not available on XT version, External power supply)

RF Specifications	
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

Embedded Data logger	
Storage capacity	up to 1 million data points
Wireless data downloading	3 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm



	Environmental and Mechanical
Casing	Aluminum AL6061 & Waterproof casing Dimensions in mm (LxWxH): 100x55x36 mm Weight : 155g
IP   NEMA Rating	IP67   Nema 6
Shock resistance	100g during 50 ms
Operating Temperature	<b>RB : Internal rechargeable battery</b> -40 °C to +60 °C <b>XT : External Power Supply</b> -40 °C to +75 °C during battery discharge
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul> ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 30 to 40 mA</li> <li>· During Radio transmission : 80 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 38 µA</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable battery	High density Lithium-Ion rechargeable battery with a capacity of 950 mAh

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V

<b>Solar Panel Kit (compatible with External Power Supply version only)</b>	High efficiency solar panel with with Solar charging controller and Lead-acid battery Ref: X-SOL-5W-M8-2M
<b>External Primary Cell in a Waterproof IP67 Casing</b>	Waterproof IP67 battery box for long-term monitoring applications IP67 Battery Holder Battery Pack with 3 x C size primary cell, Li-SOCL2 Lithium Primary cell 3.6VDC Type Ref: PRIM-XTENDER
<b>M8 extension cable for external power supply</b>	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
<b>Calibration certificate</b>	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

### 6.9.6 BeanDevice® HI-INC-SR

<i>Product reference</i>
BND-2.4GHZ-HI-INC-SR- <i>MR-PS-MO</i>
<b>MR– Measurement Range:</b> 10T :tri-axis $\pm 10^\circ/\pm 90^\circ$
<b>PS - Power supply :</b> <b>RB :</b> Internal rechargeable battery <b>XT :</b> External power supply 4VDC (Compatible with X-SOLAR-4VDC and External Primary Cell)
<b>MO - Mounting Option</b> SCM - Screw Mounting Lid MM - Magnetic Mounting Lid
<b>Example 1:</b> <i>BND-2.4GHZ-HI-INC-SR-10T-SCM</i> , High performance wireless Tri-axis inclinometer with $\pm 10^\circ/\pm 90^\circ$ measurement range, internal rechargeable battery, Screw mounting <b>Example 2:</b> <i>BND-2.4GHZ-HI-INC-SR-10T-XT-MM</i> , High performance wireless Tri-axis inclinometer with $\pm 10^\circ/\pm 90^\circ$ measurement range, external power supply, Magnetic Mounting

	Inclinometer sensor
Inclinometer Technology	Accurate and low power MEMS technology
Scalable Measuring Range	$\pm 10^\circ$ or $\pm 90^\circ$ , with automatic range adjustment depending on the application
Sensor resolution	0.0055°
Noise density	for $\pm 10^\circ$ range: 0.0009 °/√Hz on Y Axis, 0.0012 °/√Hz on X, Z Axis for $\pm 90^\circ$ range: 0.0018 °/√Hz on all axis
Sensor precision (full scale, @ 25°C, Static Measurement Mode every 2s)	$\pm 0.01^\circ$ for $\pm 10^\circ$ measurement range $\pm 0.02^\circ$ for $\pm 90^\circ$ measurement range
Offset temperature dependency (temperature range -25°C to +85°C)	$\pm 0.002^\circ/\text{°C}$
Sensitivity temperature dependency (temperature range -25°C to +85°C)	$\pm 0.3\%$
Offset LifeTime Drift (@25°C)	$\pm 0.23^\circ$
Sensor frequency Response (-3 dB)	DC to 10 Hz for $\pm 10^\circ$ measurement range DC to 40 Hz for $\pm 90^\circ$ measurement range (Automatic Range) DC to 70 Hz for $\pm 90^\circ$ measurement range

	Integrated Temperature sensor
Temperature Range	-40°C to +75°C
Measurement resolution	±0.06°C
Sensor Precision	±1°C

	Configurable settings from the BeanScope® 2.4GHz software
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) and Alarm Mode (based on alarm thresholds) . Measurement heartbeat 1s to 24 hour
	Dynamic data acquisition(not available on devices with ref. extension XT ): Streaming and S.E.T. (Streaming with Event Trigger) Mode
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 1 SPS Maximum: 20 SPS on each axis , for ±10° measurement range Maximum: 80 SPS on each axis , for ±90° measurement range
Alarm Threshold	Three-level alarms : Alert < Action < Alarm
Scalable Measurement Range	±10° , ±90° and automatic ±10°/±90°
Power Mode	Battery saver mode & Active power mode (Active Power Mode is not available on -XT version)

	RF Specifications
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

Embedded data logger	
Storage capacity	up to 8 millions data points
Wireless data downloading	20 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm

Environmental and Mechanical	
Casing	<p>Aluminum AL6061 &amp; Waterproof casing</p> <ul style="list-style-type: none"> <li>· Dimensions in mm (LxWxH): 100 x 71 x 38 (without Radome antennas, with mounting eyelet)</li> <li>· Weight (with internal battery) : 225g (screw mounting) 252g (magnetic mounting)</li> </ul>
IP   NEMA Rating	IP67   Nema 6
Base plate	<ul style="list-style-type: none"> <li>· Aluminum black anodized AL 7075 with rugged three-point-mounting</li> <li>· Screw Mounting Option: the device should be mounted on a flat and smooth surface with 3 screws, dimension M5. Mounting torque <math>5 \pm 1\text{Nm}</math></li> <li>· Magnetic Mounting Option: the device should be mounted on a steel surface.</li> </ul>
Shock resistance	150g during 50 ms
Operating Temperature	<p><b>RB : Internal rechargeable battery</b> -40°C to +60°C</p> <p><b>XT : External Power Supply</b> -40°C to +75°C during battery discharge</p>
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul>
	ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	<p>Integrated Lithium-ion battery charger with high precision battery monitoring:</p> <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 30 to 40 mA</li> <li>· During Radio transmission : 55 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 30 <math>\mu</math>A</li> </ul>
External power supply	<p>8-28VDC with reverse polarity protection IEC-61000-4-2: ESD 30kV(Air), 30kV (Contact) Surge protection &gt; 28VDC (600W during 10us max)</p>
Rechargeable battery	2.2 Ah, Lithium-Polymer battery

	Included accessories
	<p>1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply</p>

	Optional Accessories and Services
External Power Supply	<p>Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V</p>
Solar Panel Kit	<p>High efficiency solar panel with <b><u>Solar charging controller and Lead-acid battery</u></b> Ref.: X-SOL-7AH-20W-1CH-4V-5M for XT version Ref.: X-SOL-7AH-20W-1CH-12V-5M for RB version Ref: X-SOL-14AH-20W-4CH-4V-5M for XT version Ref: X-SOL-14AH-20W-4CH-12V-5M for RB version Ref: X-SOL-14AH-80W-4CH-4V-5M for XT version Ref: X-SOL-14AH-80W-4CH-12V-5M for RB version</p>
Bracket Mounting	<p>90° Bracket for BeanDevice (Xrange smartsensor) with 4 x M5 screws + Locknut Ref: SMART-BRACK-MNT</p>

<b>External Primary Cell in a Waterproof IP67 Casing</b>	Waterproof IP67 battery box for long-term monitoring applications IP67 Battery Holder + Battery Pack with 3 x 6500mAh Li-SOCL2 Lithium Primary cell (Capacity 3x 6.5Ah) <b>Ref: PRIM-XTENDER</b>  Compatible with : BND-2.4GHZ-HI-INC-SR-10T- <b>XT</b> -MM & BND-2.4GHZ-HI-INC-SR-10T- <b>XT</b> -SCM
<b>M8 extension cable for external power supply</b>	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating: IP67   Nema 6 Cable length: 2 meters, Ref: CBL-M8-2M Cable length: 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
<b>Calibration certificate</b>	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.9.7 BeanDevice® AX-3D XRange

Product reference
BND-2.4GHZ-AX-3D-MR-XR-PS-MO
<b>MR – Measurement Range (1g = 9806.65 mm/s<sup>2</sup>)</b> <b>2:</b> ±2g measurement range <b>10 :</b> ±10g measurement range
<b>PS - Power Supply</b> <b>RB :</b> Built-in rechargeable Lithium-Polymer battery 2Ah
<b>MO - Mounting Option</b> <b>SCM</b> - Screw Mounting Lid <b>MM</b> - Magnetic Mounting Lid
<b>Example n°1:</b> <b>BND-2.4GHZ-AX-3D-10G-XR-RB-SCM</b> , High performance wireless accelerometer with 10g measurement range, built-in rechargeable battery, screw mounting <b>Example n°2:</b> <b>BND-2.4GHZ-AX-3D-2G-XR-RB-MM</b> , High performance wireless accelerometer with 2g measurement range, built-in rechargeable battery, Magnet Mounting

	Accelerometer Specifications
Accelerometer technology	Accurate and low power MEMS technology
Sensitivity	±2g Version : 61 µg/digit ±10g version: 305 µg/digit
Typical non-linearity (Full scale, @ 25°C)	±0.1%
Analog to Digital converter	16-bit, SAR architecture (Successive Approximation Register) with temperature compensation
Sensor frequency response (-3 dB)	DC to 800 Hz
Noise spectral density	±2g Version : 45 µg/√Hz ±10g version: 100 µg/√Hz
Zero-g Offset Variation from RT over Temp	±2g Version : ±0.2 mg/°C ±10g version: ±0.1 mg/°C
Sensitivity Variation from RT over Temp	±2g Version : ±0.01 %/°C (XY) , ±0.02 %/°C (Z) ±10g version: ±0.01 %/°C
Offset Ratiometric Error	±2g Version : 4mg ±10g version: ±0.2% (XY) , ±0.1% (Z)
Sensitivity Ratiometric Error	±2g Version : ±1.25 % (X-Y) , ±0.2 % (Z) ±10g Version : ±1.6% (X-Y) , ±0.2 % (Z)



Cross Axis Sensitivity	0.02
Anti-aliasing Hardware filter	Butterworth 5th order filter – cut-off frequency : 1 Hz to 2000 Hz remotely programmable (BeanScape®)

	Configurable settings from the BeanScape® software
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) Mode Measurement heartbeat 1s to 24 hour
	Dynamic data acquisition: Streaming and S.E.T. ( Streaming with Event Trigger)
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 10 SPS Maximum: 3 kSPS per axis (one axis enabled) 1,5 kSPS per axis (2-axis enabled) 1 kSPS per axis (3-axis enabled)
Sampling Rate (in streaming mode with data logger only)	Minimum: 1 SPS Maximum: 4 kSPS maximum per axis (one or two axis enabled) 3,5 kSPS per axis (3-axis enabled)
Programmable Cut-off frequency (Anti-aliasing filter)	1– 2000 Hz
Power Mode	Battery saver mode & Active power mode

	RF Specifications
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

	Embedded data logger
Storage capacity	up to 8 millions data points
Wireless data downloading	20 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm

	Environmental and Mechanical
Casing	Aluminum AL6061 & Waterproof casing <ul style="list-style-type: none"> <li>· Dimensions in mm (LxWxH): 100 x 71 x 38 (without Radome antennas, with mounting eyelet)</li> <li>· Weight (with internal battery) :            225g (screw mounting)            252g (magnetic mounting)</li> </ul>
IP   NEMA Rating	IP67   Nema 6
Base plate	<ul style="list-style-type: none"> <li>· Aluminum black anodized AL 7075 with rugged three-point-mounting</li> <li>· Screw Mounting Option: the device should be mounted on a flat and smooth surface with 3 screws, dimension M5. Mounting torque 5 ±1Nm</li> <li>· Magnetic Mounting Option: the device should be mounted on a steel surface.</li> </ul>
Shock resistance	150g during 50 ms
Operating Temperature	-40 °C to +60 °C
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul>
	ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>· Overvoltage Protection, Overcurrent/Short-Circuit Protection, Undervoltage Protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @ 3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 20 to 30 mA</li> <li>· During Radio transmission : 40 mA @ 0dBm , 80 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 30 <math>\mu</math>A</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable battery	High density Lithium-Ion rechargeable battery with a capacity of 2.2Ah with polyswitch protection

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply

	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V
Bracket Mounting	90° Bracket for BeanDevice ( Xrange smartsensor) with 4 x M5 screws + Locknut Ref: SMART-BRACK-MNT
M8 extension cable for external power supply	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
Calibration certificate	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.9.8 BeanDevice® HI-INC Xrange

<i>Product reference</i>
BND-2.4GHZ-HI-INC- <i>MR</i> -XR- <i>PS</i> - <i>MO</i>
<b>MR– Measurement Range:</b> <b>15B</b> : bi-axis $\pm 15^\circ$ <b>30B</b> : bi-axis $\pm 30^\circ$
<b>PS - Power supply :</b> <b>RB</b> : Internal rechargeable battery <b>XT</b> : External power supply
MO - Mounting Option SCM - Screw Mounting Lid MM - Magnetic Mounting Lid
<b>Example 1:</b> <i>BND-2.4GHZ-HI-INC-15B-XR-RB-SCM</i> , High performance wireless Bi-axis inclinometer with $\pm 15^\circ$ measurement range, internal rechargeable battery, Screw mounting <b>Example 2:</b> <i>BND-2.4GHZ-HI-INC-30B-XR-XT-MM</i> , High performance wireless Bi-axis inclinometer with $\pm 30^\circ$ measurement range, external power supply, Magnet Mounting

	Sensor specifications
Inclinometer Technology	Accurate and low power MEMS technology
Measurement resolution (Bandwidth 10 Hz)	0.001°
Noise density	0.0004 °/√Hz
Measurement Repeatability (full scale, @ 25°C, Static Measurement Mode every 2s)	$\pm 0.005^\circ$ for bi-axis $\pm 15^\circ$ version $\pm 0.006^\circ$ for bi-axis $\pm 15^\circ$ version
Offset temperature dependency (temperature range -25°C to +85°C)	$\pm 0.002^\circ/\text{°C}$
Sensitivity temperature dependency (temperature range -25°C to +85°C)	$\pm 0.005\%/^\circ\text{C}$ with temperature compensation
Long term stability (@23°C)	< 0.004 °
Analog to Digital converter	16-bits, SAR architecture (Successive Approximation Register) with temperature compensation
Sensor frequency Response (-3 dB)	DC to 28 Hz
Noise spectral density DC to 100 Hz	0.0004 °/√Hz

Anti-aliasing Hardware filter	Butterworth 5 <sup>th</sup> order filter – cut-off frequency : 1 Hz to 100 Hz remotely programmable (BeanScape®)
-------------------------------	--

Configurable settings from the BeanScape® 2.4GHz software	
Data Acquisition mode (SPS = sample per second)	Static Data Acquisition: Low Duty Cycle Data Acquisition (LDCDA) and Alarm Mode (based on alarm thresholds) . Measurement heartbeat 1s to 24 hour
	Dynamic data acquisition(not available on devices with ref. extension XT ): Streaming and S.E.T. (Streaming with Event Trigger) Mode
Sampling Rate (in streaming and S.E.T. mode)	Minimum: 1 SPS Maximum: 100 SPS on each axis
Alarm Threshold	Three-level alarms : Alert < Action < Alarm
Programmable cut-off frequency (Anti-aliasing filter)	1– 100 Hz
Power Mode	Battery saver mode & Active power mode (Active Power Mode is not available on -XT version)

RF Specifications	
Wireless Protocol Stack	Ultra-Low-Power and license-free 2.4Ghz radio technology (IEEE 802.15.4E)
WSN Topology	Point-to-Point / Star
Data rate	250 Kbits/s
RF Characteristics	ISM 2.4GHz – 16 Channels. Antenna diversity designed by Beanair®
TX Power	+18 dBm
Receiver Sensitivity	-104dBm
Maximum Radio Range	500 m in Line-Of-Sight 30-100 m in Non-Line-of-Sight
Antenna	Omnidirectional radome antenna with antenna diversity Gain : 3 dBi Waterproof IP67

Embedded data logger	
Storage capacity	up to 8 millions data points
Wireless data downloading	20 minutes to download the full memory (average time)

TimeSync function : Clock synchronization over the Wireless IOT Sensor	
Clock synchronization accuracy	±2.5 ms (at 25°C)
Crystal specifications	Tolerance ±10ppm, stability ±10ppm

	Environmental and Mechanical
Casing	<p>Aluminum AL6061 &amp; Waterproof casing</p> <ul style="list-style-type: none"> <li>· Dimensions in mm (LxWxH): 100 x 71 x 38 (without Radome antennas, with mounting eyelet)</li> <li>· Weight (with internal battery) : 225g (screw mounting) 252g (magnetic mounting)</li> </ul>
IP   NEMA Rating	IP67   Nema 6
Base plate	<ul style="list-style-type: none"> <li>· Aluminum black anodized AL 7075 with rugged three-point-mounting</li> <li>· Screw Mounting Option: the device should be mounted on a flat and smooth surface with 3 screws, dimension M5. Mounting torque <math>5 \pm 1</math>Nm</li> <li>· Magnetic Mounting Option: the device should be mounted on a steel surface.</li> </ul>
Shock resistance	150g during 50 ms
Operating Temperature	<p><b>RB : Internal rechargeable battery</b> -40°C to +60°C</p> <p><b>XT : External Power Supply</b> -40°C to +75°C during battery discharge</p>
Norms & Radio certifications	<ul style="list-style-type: none"> <li>· CE Labelling Directive R&amp;TTE (Radio) ETSI EN 300 328</li> <li>· FCC (North America)</li> <li>· ARIB STD-T66 Ver 3.6</li> </ul>
	ROHS - Directive 2002/95/EC

	Power supply
Integrated battery charger	<p>Integrated Lithium-ion battery charger with high precision battery monitoring :</p> <ul style="list-style-type: none"> <li>· Overvoltage/Overcurrent/Short-Circuit/Undervoltage protection</li> <li>· Battery Temperature monitoring</li> </ul>
Current consumption @3,3V	<ul style="list-style-type: none"> <li>· During data acquisition : 30 to 40 mA</li> <li>· During Radio transmission : 80 mA @ 18 dBm</li> <li>· During Battery Saver Mode : &lt; 30 <math>\mu</math>A</li> </ul>
External power supply	8-28VDC with reverse polarity protection
Rechargeable battery	High density Lithium-Ion rechargeable battery with a capacity of 2.2Ah with polyswitch protection

	Included accessories
	1x Magnet to Power ON/Power OFF the device 1x M8 Cap for Power Supply


	Optional Accessories and Services
External Power Supply	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67/Nema 6) Ref: M8-PWR-12V
Solar Panel Kit (compatible with External Power Supply version only)	High efficiency solar panel with with Solar charging controller and Lead-acid battery <b>Ref: X-SOL-5W-M8-2M</b>
Bracket Mounting	90° Bracket for BeanDevice (Xrange smartsensor) with 4 x M5 screws + Locknut Ref: SMART-BRACK-MNT
External Primary Cell in a Waterproof IP67 Casing	Waterproof IP67 battery box for long-term monitoring applications IP67 Battery Holder Battery Pack with 3 x C size primary cell, Li-SOCL2 Lithium Primary cell 3.6VDC Type <b>Ref: PRIM-XTENDER</b>
M8 extension cable for external power supply	Molded cable with M8-3pins male plug Material: PVC with shield protection IP Rating : IP67   Nema 6 Cable length: 2 meters , Ref: CBL-M8-2M Cable length : 5 meters, Ref: CBL-M8-5M Cable length: 10 meters, Ref: CBL-M8-10M
Calibration certificate	Calibration certificate provided by Beanair GmbH A static calibration method is used on a granite surface plate DIN876 Ref: CERT-CAL-SMART

## 6.10 PRODUCT FOCUS

### 6.10.1 Casing description



Power On





Network Reset



Power Off

**Figure 2: Casing description**



Number	Function	Description
1	M8-3 Contacts Socket for power supply input	<p><b>DC 8-28 volts</b> power supply. The socket sealing is assured with a screw cap.</p>  <p><b><i>If you don't use the external power supply, don't forget to protect the M8-3 pins socket with a M8 protection cap.</i></b></p>
2	Random antenna	Waterproof IP67 Radom antenna
3	MAC ID Label	<p>Unique identifier assigned to the BeanDevice® (64-bytes)</p>  <p><b><i>Every wireless network product which is based on the IEEE 802.15.4 standard must have a 64-bit MAC address that allows unique identification of the device within a global network.</i></b></p>
4	BeanDevice® product version label	<p>Three label version are available:</p> <ul style="list-style-type: none"> <li>✓ <b><i>BeanDevice® AX-3D</i></b>: measurement range and the three axis are indicated on the Label</li> <li>✓ <b><i>BeanDevice® HI-INC</i></b>: measurement range and the three axis are indicated on the Label</li> <li>✓ <b><i>BeanDevice® AX-3DS</i></b>: measurement range and the three axis are indicated on the Label</li> </ul>
5	Acceleration/inclination axis	Indicates acceleration/inclination on X/Y/Z axis
6	“ <b>Network</b> ” non-contact button	<p>“<b>Network context</b>” non-contact button restores the factory settings on the BeanDevice®.</p> <p>Point the pole of the Neodymium magnet that was provided with your BeanDevice® towards the “Network” label circle. Hold the magnet for approximately <b>2s</b></p> <p><b><i>Please read the following section for more information</i></b> <a href="#">“click here”</a></p>
7	“Network LED”	<p>This bi-color <b>GREEN / RED</b> Led represents the BeanDevice® :</p> <p>Cf. table below for led description</p>
8	ON/OFF Non- contact button	<p>Allows to power up/power off the BeanDevice®.</p> <p>Point the pole of the Neodymium magnet that was provided with your BeanDevice towards the “ON/OFF” label circle (refer fig. 3) (<b>V1R2 only</b>).Hold the magnet for approximately 2s</p>

9

Battery charge indicator LED

This bi-color **GREEN** / **RED Led** indicates battery charge status:  
Cf. table below for led description

### 6.10.2 LEDs Description


Operating status	Network LED	Battery Charge LED
The BeanDevice® is power off	LED OFF	<b>No external power supply is connected:</b> LED OFF
The BeanDevice® is power on with wireless TX/RX activity	<b>Green</b> LED: Wireless Network Activity <b>Red</b> LED: Wireless transmission failure	<b>External power supply is connected:</b>
The BeanDevice® is power on	<b>Green</b> led blinks twice	<b>Green</b> LED ON: Battery charged
The BeanDevice® is power off (was power on before)	<b>Red</b> LED ON during 2s	<b>Red</b> LED ON: Battery not charged
The BeanDevice® is power on & a network Reset is performed	<b>Red</b> LED ON during 2s then <b>Green</b> LED ON during 2s then <b>Green</b> LED blinks Repeated until connecting to <b>BeanGateway®</b>	
The BeanDevice® is power on & waits for a network activity	<b>Green</b> LED blinks	

### 6.10.3 Mechanical drawing for standard version

The *BeanDevice® AX-3DS/AX-3D/HI-INC/INC* products use the same sensor housing.

#### Enclosure Features

<b>Material</b>	Aluminum
<b>Protection</b>	IP67
<b>Dimensions</b>	(L/l/h: 80x55x36 mm)
<b>Weight</b>	155g battery included



**Figure 3: Mechanical drawing - BeanDevice® AX-3D/HI-INC/INC**

**6.10.4 Mechanical drawing for Xrange version**

The BeanDevice® AX-3D/HI-INC Xrange products use the same sensor housing.

**Enclosure Features**

Material	Aluminum
Protection	IP67
Dimensions	(L/l/h: 100x71x38 mm)
Weight	225g battery included


**Table 1 : BeanDevice AX-3D/HI-INC/INC enclosure feature**

**6.10.5 Antenna diversity**

Antenna diversity is a technique that maximizes the performance of an antenna system. It allows the radio to switch between two antennas that have very low correlation between their received signals. Typically, this is achieved by spacing two antennas around 0.25 wavelengths apart or by using two orthogonal polarizations. So, if

a packet is transmitted and no acknowledgement is received, the radio system can switch to the other antenna for the retry, with a different probability of success.


The diagram below provides information on the radome antenna performance:




**Figure 4 : Radome antenna performances**

The radome antenna radio used on BeanDevice® product is a tamper resistant and unobtrusive.

#### 6.10.6 Radome antenna

<b>Electrical specifications</b>	
<b>Picture</b>	
<b>Center Frequency</b>	<b>2,45 GHz</b>
<b>Gain</b>	<b>3 dBi</b>
<b>Wavelength</b>	<b>¼ -wave</b>
<b>VSWR</b>	<b>&lt;1.9 typ. at center</b>
<b>Impedance</b>	<b>50 Ω</b>
<b>Size</b>	<b>Diameter: 27mm</b> <b>Height: 11 mm</b>



***Figure 5: Antenna position on the BeanDevice AX-3D***





***Never try to change the antenna integrated on the BeanDevice®. This action may void the product warranty.***

## 6.11 MOUNTING INSTRUCTIONS

### 6.11.1 Adhesive mounting instructions (BeanDevice® INC, HI-INC, AX-3D, AX-3DS)

Characteristics	SmartSensor
Mounting techniques	Adhesive mounting
Flatness	0,1 mm
Surface Roughness	0,1 mm
Surface treatment	Satin black textured polyester powder paint
Material	AL 6061

#### 6.11.1.1 Components needed for a non-permanent mounting

<p><b>Aluminum Foil Tape</b></p>	<p>Use an aluminum foil offering a good breaking load &amp; water resistant for outdoor use.</p> <p><b>Example:</b> Advance Tapes – Ref: 196074</p> <ul style="list-style-type: none"> <li>- Thickness 0,09mm</li> <li>- Breaking load: 35 N/cm</li> <li>- Adhesion: 4 N/cm</li> <li>- Water resistant</li> </ul>	
<p><b>High strength Epoxy Glue</b></p>	<p>High Strength Epoxy Adhesive – Resin</p> <p><b>Example:</b> Radio spares 159-3957</p>	

### 6.11.1.2 Reference edge

The BeanDevice® has a mounting reference angle (red line) for an optimal mounting of the product, which is parallel to the Y-axis. This reference edge must be placed exactly parallel to the object to be measured to prevent or minimize any mechanical offset/cross sensitivity.





**Figure 6: BeanDevice® mounting reference angle**

### 6.11.1.3 Mounting instructions for non-permanent mounting


For a non-permanent mounting we recommend to use the following process:

**Step 1:** Fix the aluminum foil tape on the back side of your BeanDevice® casing. Surface should be clean, dry and free from Grease.






**Step 2:** Mount the aluminum foil tape on the equipment where you wanted to mount the BeanDevice®. Surface should be clean, dry and free from Grease.



**Step 3:** Mix equal amount s of resin and hardener for 1 minute. Mixture should be used within 15-20 minutes. Apply the mixture on your BeanDevice®





**Step 4:** Clamp the two surface together until adhesive has cured (depending of the type of epoxy glue that you use, it can take 1 hour to 1 day). Your BeanDevice® is ready to be used for indoor and outdoor application.




**Step 5:** You can unmount the BeanDevice® very easily. Use a knife or a sharp object to unmount the BeanDevice®. Your BeanDevice® is clean and ready to be used on another application.



### 6.11.2 Screw Mounting (BeanDevice® AX-3D Xrange & BeanDevice® HI-INC Xrange)

Characteristics	SmartSensor Xrange
Mounting techniques	Screw mounting Three M5 drilled flanges
Flatness	38,1 µm
Surface Roughness	RA 1.6 (µm)
Surface treatment	Black anodized (Corrosion-proof)
Material	AL 7075 (twice harder than AL6061)



*Figure 7: Xrange base plate overview*

- ✓ For vibration measurement, the mass of the wireless accelerometer must be <math><1/10</math> of the mass of the object under study.
- ✓ Mounting surfaces need to be clean, free of any residue from epoxies, waxes, paint or other foreign materials.
- ✓ Mounting surface should be flat.

- ✓ The mounting hole must be checked to ensure it is longer than the mounting screw so as to prevent "bottoming out".
- ✓ Use a torque wrench for tightening screws to the manufacturer's specifications. Do not use electric tools as their frequencies may damage the accelerometer.
- ✓ Spread mating surface with a light coating of silicone grease, heavy machine oil or bees wax to ensure contact is secure thereby maximizing the usable frequency range.
- ✓ Secure the cable using clamps, O-rings, tape or other materials most suited to the application. Ensure that you have sufficient slack to allow for free movement of the sensor.
- ✓ Inspect mounting holes and remove any debris, burrs or other foreign materials.

### 6.11.3 Wireless inclinometer special instructions (BeanDevice® HI-INC, INC & HI-INC Xrange)

The BeanDevice® HI-INC is designed for a horizontal mounting, i.e. the base plate of the inclinometer needs to be placed on the horizontal plane of the object to be measured.

Avoid shock and vibration during measurement, as these could corrupt the measurement results. Inclination sensors that base on a fluidic measurement principle are optimal for static measurements and suitable to only a limited extent of dynamic measurement.

## 6.12 BEANDEVICE® 2.4GHZ POWER SUPPLY

### 6.12.1 Integrated Lithium-ion Rechargeable battery (Xtend version excluded)

The BeanDevice® 2.4GHz from SmartSensor product lines integrates a Lithium-Ion rechargeable battery (except XTend version):

<i>BeanDevice® version</i>	<i>Battery Capacity @25°C</i>	<i>Nominal Voltage @25°C</i>	<i>Charge/Discharge cycle @25°C</i>
BeanDevice® 2.4GHz AX-3D	2200 mAh	4,2V	370
BeanDevice® 2.4GHz AX-3DS			
BeanDevice® 2.4GHz HI-INC	2200 mAh		
BeanDevice® 2.4GHz HI-INC-SR			



*The rechargeable battery can be used as an UPS (uninterruptible power supply) battery on your BeanDevice®. It provides an emergency power when the external power source, typically the utility mains, fails.*



***Do not try to change the integrated battery. This action may void the product warranty.***

### 6.12.2 External Primary cell (Xtend version only)

The battery life can be increased by using an external primary cell with a capacity of 6500 mAh. The primary cell is integrated in a watertight (IP65) enclosure.



*Figure 8: External Primary cell*



*there is no battery charger on this production version*

#### 6.12.2.1 Primary cell specifications

The Primary lithium-thionyl chloride cell (*Li-SoCl<sub>2</sub>*) provides the following features:

Primary Cell Capacity	Size	Nominal Voltage	Operating temperature range	Maximum recommended continuous current	Pulse Capability
6500 mAh	C-size spiral cell	3,6 V	- 55°C/+ 80°C	1.5A	2.5 A during 0.1s



***A Primary Cell is not a rechargeable battery; do not try to recharge it. You will damage your primary cell and your BeanDevice®***

We recommend you the following primary cell provider:

<i>Provider</i>	<i>Model</i>
<b>SAFT</b>	<b>LSH14</b>
<b>Europa Batteries</b>	<b>ER26500M</b>
<b>EVE</b>	
<b>Able Battery</b>	

#### 6.12.2.2 Main advantages of primary cell

These are the main advantages of using a primary cell:

- ✓ The operating temperature of your BeanDevice® is extended: -55°C to +80°C instead of -20°C to +75°C;
- ✓ The self-discharge of a primary cell is **2%/year** instead of 12%/year for a rechargeable battery;
- ✓ The capacity of a primary cell is 6000 mAh instead of 1250 mAh,



*Please read the following section for more information about the primary cell replacement and calibration: "[click here](#)"*


#### 6.12.3 How to change the Primary cell on the BeanDevice® (Xtend version only)

This section concerns the BeanDevice® provided with an external primary cell power supply.

All the BeanDevice® HI-INC/AX-3D/AX-3DS provided with an internal rechargeable battery are not concerned by this section.

##### **Step 1 : Open the screw cap**

- Open the screw cap on the battery holder
- The primary cell (C Size) is inside the battery holder



***Figure 9: Changing the External Primary cell***

Step 2 :  
Change the  
primary Cell

- Change the primary cell
- Check the battery polarity: pole + is on the screw cap side;



***Figure 10: Changing the External Primary cell***



Step 3 : Close  
the screw cap

- Close properly the screw cap
- Don't forget the Gasket, it's very important to maintain a watertight seal on your device



*Do not invert the battery polarity, your BeanDevice® will not work.*



***Figure 11: Changing the External Primary cell (wrong practice)***



Step 4: Connect your primary cell enclosure to your BeanDevice®

- Screw the M8 Plug on the M8 socket of your BeanDevice®
- Make sure that your M8 plug is correctly connected to your M8 socket, otherwise the sealing between the enclosures is not maintained;



***Figure 12: Changing the External Primary cell (connecting the BeanDevice®)***



***Check the Power mode of you BeanDevice®***


***Example: If your BeanDevice® is operating in “Sleeping” power mode. You should Power off then power on your BeanDevice®, the new configuration parameter is loaded during the cold start of your BeanDevice®.***



***For further information about Power mode management, please read the technical note [TN\\_RF\\_010 – « BeanDevice® Power Management »](#)***

**Step 5: Check your battery charge level**

- Check the battery charge level which is displayed in the "**Power Supply Diagnostic frame**", battery charge level should be Good



**Figure 13: Power supply diagnostic frame on BeanScape®)**



**The nominal voltage of a primary cell is 3,6 Volts instead of 4,2 volts for a rechargeable battery. This value is correct.**



**Make sure that the power mode configured on your BeanDevice® is in "sleep power mode". If the power mode is configured in active, the battery autonomy of your BeanDevice® will be dramatically reduced.**

### 6.12.4 AC-To-DC power adapter (option)

The BeanDevice® can also be powered by an AC-to-DC adapter **8-28Volts**. The power adapter can be used for recharging Lithium-Ion battery or to power supply continuously the BeanDevice®.

A M8-3Pins standard plug is used for connecting the power adapter to the BeanDevice®.

If battery charge is very low, connect the power adapter in order to recharge your internal battery.




**Figure 14: M8-3P Wall Plug-in power supply**



*Only the M8 plug is fully sealed, the power adapter is not sealed.*

### 6.12.5 Power supply wiring code



#### M8 Socket (A-Coding) - Pin Assignment



Interface Name	M8 assignation	Pin	Wire (A-coding)	Color
Power Supply 8-28VDC	PIN3		Blue	
Power Supply 4VDC (available on Xtend version only)	PIN2		Black	
Ground	PIN1		Brown	

**Figure 15: M8 socket Power supply Wiring code**

### M8 Plug (A –Coding) - Pin Assignment



Interface Name	M8 assignation	Pin	Wire (A-coding)	Color
Power Supply 8-28VDC	PIN3		Blue	
Power Supply 4VDC (available on Xtend version only)	PIN2		Black	
Ground	PIN1		Brown	

Figure 16: M8 Plug Power supply Wiring code

If a M8 plug with a molded cable is used, the wiring code comes as follow:

Pin Number	Description	Color code
PIN3	Pwr+ : Power supply 8-28VDC	Blue
PIN1	Ground	Brown

Table 2 : M8-3P Plug Wiring code

If a M8 plug with a molded cable is used, the wiring code comes as follow:

Pin Number	Description	Color code
PIN3	Pwr+ : Power supply 8-28VDC	Blue
PIN2	PM_Primary cell power supply (4V Maximum)	Black
PIN1	Ground	Brown

Table 3 : M8-3P Plug Wiring code (Xtend version)

### 6.13 RESTORING FACTORY SETTINGS

If desired, the user can perform a Network context deletion. It allows restoring default parameters on the BeanDevice®:

Parameter	BeanDevice® version		
	AX-3D – standard and Xrange version	AX-3DS	HI-INC – Standard, Xrange & SR versions
Power Mode	Active		
Data Acquisition duty cycle	10s		
Acquisition duration time	OK		
Sampling rate	OK		
Data Acquisition mode	LowDutyCycle		
Anti-aliasing Filter cut-off frequency	100 Hz	/	100 Hz

To restore these default parameters, you must perform a *Network context deletion*. The “Network” non-contact button is outside the product. Hold the magnet on the button network (“Network”) for more than 2 seconds.



**Figure 17: Network Reed non-contact button**

## 7. BEANDEVICE® SUPERVISION FROM THE BEANSCAPE®

---



*For more information about the BeanScape®, please read the BeanScape® User Manual.*



*It is recommended to install MatLab MCR to ensure running the Online/Offline Data analysis*

### **MatLab MCR 64 bits download link**

[http://ssd.mathworks.com/supportfiles/downloads/R2015a/deployment\\_files/R2015a/installers/win64/MCR\\_R2015a\\_win64\\_installer.exe](http://ssd.mathworks.com/supportfiles/downloads/R2015a/deployment_files/R2015a/installers/win64/MCR_R2015a_win64_installer.exe)



### **MatLab MCR 32 bits download link**


[http://ssd.mathworks.com/supportfiles/downloads/R2015a/deployment\\_files/R2015a/installers/win32/MCR\\_R2015a\\_win32\\_installer.exe](http://ssd.mathworks.com/supportfiles/downloads/R2015a/deployment_files/R2015a/installers/win32/MCR_R2015a_win32_installer.exe)

### 7.1 STARTING THE BEANSCAPE®

---

The BeanScape® is a supervision software monitor fully dedicated to Beanair WSN (Wireless Sensor Networks):

1. *Start the BeanScape® by double-clicking on the BeanScape® icon* 
2. *Click on the button « start »* 
3. *All the BeanDevice® connected to the WSN will appear on your left window*
4. *Select the BeanDevice® you want to configure. You can configure your BeanDevice® and its attached sensors.*




**Figure 18: BeanDevice® display on BeanScape®**

**The user interface is organized as follow:**

- White on blue background is displaying information



- Black on white background and white on blue background are customizable field;



You can configure your BeanDevice® from the page "**BeanDevice® System Profile**". This page is composed of two parts:

- ✓ BeanDevice® information display
- ✓ BeanDevice® configuration




Figure 19: Overview: BeanDevice® System Profile on BeanScope®

## 7.2 DISPLAYING THE BEANDEVICE® INFORMATION

You will find below a description of the data information fields making up for each frame.

### 7.2.1 Frame: Identity




Figure 20: BeanDevice® Identity






**How the PAN ID is assigned ?**

The BeanGateway® starts the WSN, assigning a PAN ID (Personal Area Network identifier) to the network. The PAN ID is pre-determined and cannot be modified. If you use several WSN, before deploying your BeanDevice® check to which WSN is assigned your BeanDevice®.

**7.2.2 Frame : Wireless Network Diagnostic**




**Figure 21: BeanDevice® network-link status**

$PER = \text{Number of lost packet} / \text{Total of packet transmitted}$

Number of bars	Color	Link quality indicator
5 to 6 bars	Green	Very good
4 bars	Green	Good
3 bars	Red	medium
to 2 bars	Red	bad

**7.2.3 Frame: Power supply diagnostic**



**Figure 22: BeanDevice® Power Supply information**



*The BeanDevice® incorporates an internal temperature sensor:*

- ✓ *Battery temperature monitoring during charging ;*
- ✓ *Temperature compensation of the analog conditioning chain ;*
- ✓ *An alarm notification is send to the BeanGateway® if the internal temperature is anormally high ;*

*When you plug the BeanDevice® on an external power supply, the power supply status is automatically detected.*

*If your primary cell charge level is low, it is highly recommended to recharge your battery. Your BeanDevice® from SmartSensor product lines integrates a battery charger.*



*For further information about Power mode management, please read the technical note [TN RF 010 – « BeanDevice® Power Management »](#)*



*When using the Streaming mode or the S.E.T mode, BeanScape® stops to display the full Battery health status information on the Power Supply Diagnostic frame until stopping the acquisition.*





Figure 23: BeanDevice® Power modes

### 7.2.4 Frame : System



**Figure 24: BeanDevice® Diagnostic cycle information**

\* The diagnostic cycle is a regular period during which the system collects information about the BeanDevice® (battery charge status, internal temperature, LQI, PER ..).



#### How to convert dBm to mW

*Zero dBm equals one milliwatt. A 3dB increase represents roughly doubling the power, which means that 3 dBm equals roughly 2 mW. For a 3 dB decrease, the power is reduced by about one half, making -3 dBm equal to about 0.5 milliwatt. To express an arbitrary power  $P$  as  $x$  dBm, or go in the other direction, the following equations may be used:*

$$x = 10 \log_{10}(1000P) \text{ Or, } x = 10 \log_{10} P + 30$$


And

$$P = 10^{(x/10)}/1000 \text{ Or, } P = 10^{(x-30)/10}$$

Where  $P$  is the power in W and  $x$  is the power ratio in dBm.

### 7.2.5 Frame : BeanDevice®

According to the BeanDevice® version, the information displayed in the frame will not be the same. For example, for the BeanDevice® AX-3D Xrange:



**Figure 25: Frame BeanDevice® on BeanScope®**

7.2.6 Frame: Product Version



Figure 26: BeanDevice® Product version frame

**V (version)** related to a major modification of the embedded software.

**R (Release)** related to a minor modification of the embedded software



*These ID versions should be transmitted to our technical support center when you encountered a material or software dysfunction.*

7.2.7 Frame: Current Data Acquisition mode

This frame displays all the information returned by the BeanDevice® on its actual data acquisition mode:




Figure 27: Current data acquisition mode


### 7.2.8 Frame: Sensor Info

All the information related to the sensor itself will be displayed in this frame.

- For the AX3D and AX3D Xrange



- For the AX3DS



- For the AX-3D-SR

There are 3 tabs information available inside the sensor info frame of the BeanDevice Hi-Inc-SR


- **Acceleration Tab:**



- ✓ **Measurement range:** 4 different measurement range available on the AX-3D-SR,  $\pm 1.2g$  /  $\pm 2.4g$  / Auto  $\pm 1.2g$  / Auto  $\pm 2.4g$
- ✓ **Max SR:** Maximum sampling rate depending on the BeanDevice Measurement range (if it's Auto  $\pm 1.2g$  the maximum sampling rate in dynamic DAQ modes is 400 Hz, if it's Auto  $\pm 2.4g$  the maximum sampling rate is 800 Hz).

- **Hyst. Tilt**

Displays the threshold levels to auto scale the BeanDevice measurement range.



- ✓ **Dynamic DAQ:** threshold level related to dynamic measurement DAQ modes (streaming + SET), if 2000 successive values are lower/higher than the BeanDevice measurement range, the device change automatically its measurement range.
- ✓ **Static DAQ:** threshold level related to static measurement DAQ modes (Low Duty Cycle + Alarm).


- **Temp.**

This information is related to the temperature sensor



- ✓ **Min Temp:** Minimum temperature that can be measured by the temperature sensor
- ✓ **Max Temp:** Maximum temperature that can be measured by the temperature sensor


➤ For the Hi-Inc & Hi-Inc Xrange



➤ For the Hi-Inc-SR

There are 3 tabs information available inside the sensor info frame of the BeanDevice Hi-Inc-SR


- **Tilt Tab:**



- ✓ **Measurement range:** 4 different measurement range available on the Hi-Inc-SR,  $\pm 10^\circ$  /  $\pm 90^\circ$  / Auto  $\pm 10^\circ$  / Auto  $\pm 90^\circ$
- ✓ **Sensitivity:** BeanDevice sensitivity
- ✓ **Max SR:** Maximum sampling rate depending on the BeanDevice Measurement range (if it's Auto  $\pm 10^\circ$  the maximum sampling rate in dynamic DAQ modes is 20 Hz, if it's Auto  $\pm 90^\circ$  the maximum sampling rate is 80 Hz).

- **Hyst. Tilt**

Displays the threshold levels to auto scale the BeanDevice measurement range.




- ✓ **Dynamic DAQ:** threshold level related to dynamic measurement DAQ modes (streaming + SET), if 2000 successive values are lower/higher than the BeanDevice measurement range, the device change automatically its measurement range.
- ✓ **Static DAQ:** threshold level related to static measurement DAQ modes (Low Duty Cycle + Alarm).

- **Temp.**


This information is related to the temperature sensor





- ✓ **Min Temp:** Minimum temperature that can be measured by the temperature sensor
- ✓ **Max Temp:** Maximum temperature that can be measured by the temperature sensor

### 7.3 BEANDEVICE® CONFIGURATION



**Figure 28: BeanDevice® configuration frame**

This frame is composed of several Tabs and includes BeanDevice® OTAC (Over the Air Configuration) Parameters:

<i>Tab</i>	<i>Description</i>
<b>Custom Display</b>	Customize the BeanDevice® label
<b>Notes</b>	This area contains the notes related to the BeanDevice®.
<b>Data Acquisition configuration</b>	Configure the Data acquisition mode on your BeanDevice®, set the acquisition cycle or the sampling rate, enable/disable the datalogger function.
<b>Datalogger</b>	Manage the Datalogger function on the BeanDevice®
<b>System configuration</b>	Configure the diagnostic cycle and the TX Power
<b>Power Mode Management</b>	Configure the Power mode on your BeanDevice® (Active mode, Sleep power mode)
<b>Sensor Config</b>	Enable the available filters
<b>Online Data Analysis</b>	Enable FFT/PPV and available filter depending on the BeanDevice platform

### 7.3.1 Tab: Custom Display

The screenshot displays the 'Custom Display' tab interface. At the top, there is a navigation bar with the following tabs: Datalogger, System config., Power mode managt, Online Data Analysis, Custum display (highlighted in blue), Notes, Data Acq. config., and Sensor Config. Below the navigation bar, the main content area contains three input fields:

- Location :
- Label:
- Log folder:


At the bottom center of the form, there is a  button.

*Figure 29: BeanDevice® custom display tab*


<i>Parameter</i>	<i>Description</i>
<b>Location</b>	You can enter here your BeanDevice® location
<b>Label</b>	You can assign any sort of Label to your BeanDevice®. Therefore, the user can easily associate the BeanDevice® with its equipment (example: Room_N521_Second_Floor)
<b>Log Folder</b>	You can customize a name for your log folder where the measurement data will be saved in

Click on “**Validate**” if you want to validate your configuration.

### 7.3.2 Tab: Notes



**Figure 30: Tab: Notes**

This field contains your notes concerning the BeanDevice®. To change this field, enter your text and click on « **Validate** » button. To back up your text, press the icon 

**Example:** Machine failure n°XX, requested intervention.

7.3.3 Tab : Data Acquisition configuration




Figure 31: Tab: Data acquisition configuration

Parameter		Description
Data Acquisition mode	<i>Low duty cycle Data Acquisition (LDCDA)</i>	Low duty cycle data acquisition is adapted for static measurement (tilt, pressure, temperature) requiring a low power consumption on your BeanDevice®. The duty cycle can be configured between 1 data acquisition & transmission per second to 1 data acquisition & transmission per day.
	<i>Alarm</i>	Survey mode is a mix between the LDCDA mode and Alarm mode. A data acquisition is transmitted <ul style="list-style-type: none"> <li>▪ Whenever an alarm threshold (fixed by the user) is reached (4 alarm threshold levels High/Low).</li> <li>▪ A transmission cycle is reached, the transmission cycle is configurable through the BeanScape® 1s to 24h</li> </ul>
	<i>Streaming</i>	Streaming is more suitable for users requiring a high data sampling rate (maximum 1 KHz).
	<i>Shock Detection</i>	When the Shock detection mode is activated (only available for the BeanDevice AX-3DS) the BeanDevice will wake up if a shock is detected. During the sleeping mode of the BeanDevice®, the sensor will continue to track a shock event.
	<i>S.E.T</i>	The streaming with event trigger mode allows user to receive notification via email when the measurement reaches the preconfigured thresholds, the measurement is in streaming mode with high sampling rates (up to 1Ksps)

Data acquisition Cycle	<p>Select the Data acquisition cycle between 1s and 24hours.</p> <p>The format is: Day: Hour: Minute: Second</p>
Sampling rate	<p>Select the sampling rate of your BeanDevice® between 1 sample per second and 3000 Samples per second maximum. The resolution is 1 sample per second.</p> <p>If Datalogger is selected, the maximum sampling rate is 3000 samples per second.</p> <p>This field is available in streaming:</p> <p>Choose carefully the Sampling rate value:</p> <ul style="list-style-type: none"> <li>✓ The PER (Packet Error Rate) can increase if the Sampling rate is high on your BeanDevice®. For further information read the technical note <a href="#">TN RF 003 - "Wireless Network capacity"</a></li> <li>✓ Power consumption increases with the sampling rate of your BeanDevice®</li> </ul>
Data acquisition duration	<p>Data acquisition duration in streaming mode.</p> <p>The format is Day: Hour: Minute: Second</p> <p>The Data acquisition duration value can be higher than Data acquisition cycle.</p>
Options	<p><b>TX only:</b> The BeanDevice® transmits the data acquisition without Datalogging</p> <p><b>Log only:</b> The BeanDevice® logs the data acquisition without wireless transmission</p> <p><b>Tx &amp; Log:</b> The BeanDevice® transmits and logs the data acquisition;</p> <p>For further information about the Datalogger feature, read the technical note TN_RF_007 – “BeanDevice® Datalogger User Guide”</p>



For further information about the Datalogger, please read the technical note [TN RF 007 – “BeanDevice® Datalogger User Guide”](#)

All the modifications are displayed on “**Current data acquisition mode**” frame:




Figure 32: Current data acquisition mode display




For further information, please read the technical note [TN\\_RF\\_008 – “Data acquisition modes available on the BeanDevice®”](#)

### 7.3.4 Tab: Sensor Config

Sensor Config tab offers different functionalities according the nature of the BeanDevice®.


#### 7.3.4.1 BeanDevice® AX-3D and AX-3D X-range Sensor config Tab



*Figure 33: BeanDevice® AX 3D and AX 3D X-range Sensor Config tab*

When using the BeanDevice® Ax-3D or AX-3D Xrange, the Sensor Config Tab will be used to set the Sensor AAF-Cut frequency.

#### 7.3.4.2 BeanDevice® AX-3D-SR Sensor Config Tab



*Figure 34: BeanDevice® AX-3D-SR Sensor Config Tab*

- **Temperature Unit:** Change the temperature unit for the temperature sensor which is used to detect Object temperature and it's not designed to measure the ambient temperature, you can choose between (Degree Celsius (C°), Fahrenheit (F°), Kelvin (K°)).
- **Tilt range:** gives you the possibility to change the BeanDevice measurement range, you can choose a static measurement range  $\pm 1.2g$  or  $\pm 2.4g$  or a dynamic measurement range Auto  $\pm 1.2g$ , Auto  $\pm 2.4g$ .

- **Hysteresis acceleration configuration:** from this spot you can specify the threshold level from which the BeanDevice will automatically change its measurement range scale.
  - ✓ **Dynamic DAQ:** threshold level related to dynamic measurement DAQ modes (streaming + SET), if 2000 successive values are lower/higher than the BeanDevice measurement range, the device change automatically its measurement range.
  - ✓ **Static DAQ:** threshold level related to static measurement DAQ modes (Low Duty Cycle + Alarm).

#### 7.3.4.3 BeanDevice® Hi-Inc Sensor and Hi-Inc X-range Config Tab

**Figure 35: BeanDevice® Hi-Inc and Hi-Inc X-range & Hi-Inc-SR Sensor Config tab**

When using the BeanDevice® Hi-Inc or Hi-Inc X-range, user can have access to these functionalities:

- **AAF-Cutoff Frequency:** Used to set the Cutoff frequency
- **Tare Inclinometer:** Used to calibrate the Zero Degree during the calibration process.



#### 7.3.4.4 BeanDevice® Hi-Inc-SR Sensor Config Tab

**Figure 36: BeanDevice® Hi-Inc-SR Sensor Config Tab**

- **Temperature Unit:** Change the temperature unit for the temperature sensor, you can choose between (Degree Celsius (C°), Fahrenheit (F°), Kelvin (K°)).
- **Tare Inclinator:** Used to calibrate the Zero Degree during the calibration process.
- **Tilt range:** gives you the possibility to change the BeanDevice measurement range, you can choose a fixed measurement range  $\pm 10^\circ$  or  $\pm 90^\circ$  or a dynamic measurement range Auto  $\pm 10^\circ$  or Auto  $\pm 90^\circ$ .
- **Hysteresis tilt configuration:** from this spot you can specify the threshold level from which the BeanDevice will automatically change its measurement range scale.
  - ✓ **Dynamic DAQ:** threshold level related to dynamic measurement DAQ modes (streaming + SET), if 2000 successive values are lower/higher than the BeanDevice measurement range, the device change automatically its measurement range.
  - ✓ **Static DAQ:** threshold level related to static measurement DAQ modes (Low Duty Cycle + Alarm).

#### 7.3.4.5 BeanDevice® AX-3DS Sensor Config Tab

Datalogger	System config.	Power Mode config.
Custom display	Notes	Data Acq. config.
<b>Sensor Config</b>		
Measurement Unit :	<input type="text" value="g"/>	<input type="text" value="g"/> <input type="button" value="Validate"/>
Meas.Range:(g)	<input type="text" value="-2 / +2"/>	<input type="button" value="Validate"/>

*Figure 37: BeanDevice® AX-3DS Sensor Config tab*

When using the BeanDevice® AX-3DS, user can have access to these functionalities:

- **IIR Filter:** Enable/Disable IIR Filter
- **Meas. Range:** Used to set Measurement Range according to the Sensor measurement unit.
- **Sensor measurement Unit:** Used can select between g or mm/s<sup>2</sup>

### 7.3.5 Tab: Online Data Analysis



*Online data analysis is only available on the following hardware platforms:*

- *BeanDevice® AX-3D*
- *BeanDevice® AX-3D Xrange.*


Custum display	Notes	Data Acq. config.	Sensor Config
Datalogger	System config.	Power mode managt	Online Data Analysis
<b>Online FFT Configuration</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> Enable Online FFT </li> <li><input type="checkbox"/> Automatic FFT Report(S.E.T)</li> <li><input type="checkbox"/> Enable FFT Log file</li> </ul>		<b>Online Velocity configuration</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> Enable Online Velocity </li> <li><input type="checkbox"/> Automatic DIN Report(S.E.T)</li> <li><input type="checkbox"/> Enable Velocity Log file</li> <li><input type="checkbox"/> Enable PPV Log file</li> </ul>	
<b>Number of Points (Streaming)</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> Manual <input type="text" value="SR/0.1"/> </li> <li>Current Points Number: <input type="text" value="SR/0.1"/></li> </ul>			
<b>Online waveform configuration</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> Automatic waveforms Report(S.E.T)</li> <li><input type="checkbox"/> Enable waveforms Log file(S.E.T)</li> </ul>		Unit of acceleration <input type="text" value="g"/>	
<b>Software Filters</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> Enable IIR Filter</li> </ul>		S.E.T threshold <input type="text" value="Acceleration"/>	
		<input type="button" value="Validate"/>	

**Figure 38: Signal processing tab**


Signal processing tab is composed of six different fields:

- *Online FFT Configuration*
- *Online Velocity configuration*
- *Online waveform config*
- *Software filters*
- *Unit of acceleration*
- *S.E.T threshold*

7.3.5.1 Online FFT Configuration




1: Check **Enable Online FFT** to view the display of FFT graph in the sensor profile




**Figure 39: FFT Spectrum**

2: Check **Enable FFT Log file** to generate log files in the log\_beanscape directory.




**Figure 40: Online FFT Configuration frame**

The log files will be generated in a folder called “FFT” under the BeanDevice® repertory.




**Figure 41: FFT log files folder**

**3: Enabling Automatic Report:** This functionality is available only in S.E.T mode. To activate automatic reports generation, check the option on Online FFT configuration frame



**Figure 42: Enabling Automatic FFT Report**

The Reports will be generated in your log\_beanscape directory, under “Report Folder” repertory.



**Figure 43: Report Folder**



For further information about the configuration of Online FFT please refer to section [7.3.4](#) of this user manual

After enabling Real time FFT and setting SMTP configuration ([more information on section 8](#)), this is an example of an FFT report emailed to concerned recipients.




Figure 44: FFT Report (S.E.T mode)

1	Logo of your company, you can upload it from the alarm management configuration window. Tools→Alarm management
2	General information about the Measurement, Date, duration sampling rate ,pre-trigger duration, IIR filter status and triggered axis
3	Information related to monitoring site: user, location and monitoring sites (can be configured from the Alarm tool window). This field can be configured be from the alarm management configuration window Tools→Alarm management
4	BeanDevice® Information: Type, MAC ID and label, measurement range, and Alarm Type : Acceleration or Velocity
5	Alarm thresholds value on each Axis, the three levels of alarms are displayed Action-Alert-Alarm
6	FFT Report with Max Frequency for each Axis, VPPV (Vector Peak Particle Velocity) value and Max amplitude
7	Graph Area – 3 Axis are displayed on the same graph




*For further information about managing your notification and reports email please refer to section [8: Alarm management.](#)*




- **FFT Advanced Configuration**

The FFT configuration allows the user to activate the FFT Shift and to go for manual settings related to FFT.



- Auto/Manual



- Window type:

Rectangular
Hamming
Hann
Blackman
Blackman Harris
Gaussian
Kaiser
Taylor
Triangular
Flattop
Bartlett
Bartlett-Hann



When the number of periods in the acquisition is not an integer, the endpoints are discontinuous. These artificial discontinuities show up in the FFT as high-frequency components as not present in the original signal. These frequencies can be much higher than the Nyquist frequency and are aliased between 0 and half of your sampling rate. This phenomenon is known as spectral leakage.

You can minimize these effects by using a technique called windowing.

Windowing reduces the amplitude of the discontinuities at the boundaries of each finite sequence acquired by the digitizer. Windowing consists of multiplying the time record by a finite-length window with an amplitude that varies smoothly and gradually toward zero at the edges. This makes the endpoints of the waveform meet and, therefore, results in a continuous waveform without sharp transitions. This technique is also referred to as applying a window.

There are several different types of window functions that you can apply depending on the signal. To understand how a given window affects the frequency spectrum, you need to understand more about the frequency characteristics of windows.

Selecting a window function is not a simple task. Each window function has its own characteristics and suitability for different applications. To choose a window function, you must estimate the frequency content of the signal.

- If the signal contains strong interfering frequency components distant from the frequency of interest, choose a smoothing window with a high side lobe roll-off rate.
- If the signal contains strong interfering signals near the frequency of interest, choose a window function with a low maximum side lobe level.
- If the frequency of interest contains two or more signals very near to each other, spectral resolution is important. In this case, it is best to choose a smoothing window with a very narrow main lobe.
- If the amplitude accuracy of a single frequency component is more important than the exact location of the component in a given frequency bin, choose a window with a wide main lobe.
- If the signal spectrum is rather flat or broadband in frequency content, use the uniform window, or no window.


In general, the Hanning (Hann) window is satisfactory in 95 percent of cases. It has good frequency resolution and reduced spectral leakage. If you do not know the nature of the signal but you want to apply a smoothing window, start with the Hann window.

- Algorithm

<b>Estimate</b>	Determine a best-guess transform algorithm based on the size of problem.
<b>Measure</b>	Find a better algorithm by computing multiple transforms and measuring the run times.
<b>Patient</b>	Run a wider range of testing compared to 'measure', resulting in a better transform algorithm, but at the expense of higher computational cost to determine the parameters.
<b>Hybrid</b>	Use a combination of 'measure' for transforms with dimension length (number of points) 8192 or smaller and 'estimate' for transforms with dimension length (number of points) larger than 8192.

- Zero Padding: The use of zero padding enables you to estimate the amplitudes of frequencies correctly.
- FFT Shift: Check to enable real time FFT Shift processing for BeanDevice AX-3D on streaming mode and the FFT spectrum will appear shifted below the Streaming graph in the sensor profile.

FFT Configuration



**Figure 45: FFT Shift Spectrum**

### 7.3.5.2 Online Velocity configuration



In order to use Real time PPV, you should use high sampling rate to provide good PPV values.



You need to sample at 200Hz at least to provide good PPV values.




By using SET mode, you need to choose the highest sampling rate which is 200Hz and don't forget to enter a DAQ duration higher than 10s.



For Streaming mode, choose at least 500Hz and above with a minimum DAQ duration of 10s, to provide good PPV measurement.



Real time observation of velocity available for BeanDevice AX-3D only with Streaming and S.E.T acquisition modes and is enabled from the signal processing tab in the Configuration panel.



**Figure 46: Online Velocity configuration tab**

- **Enable online Velocity:** check to enable real time Velocity processing, PPV and PVS, the velocity graph will be displayed.

On the Graph side a real time DIN 4150 graph will be displayed on the right side of the screen.

Under the DIN 4150 Graph, the PPV and the PVS values will be displayed in real time.

On the PPV frame, BeanScape will display PPV in mm/s, ZC Frequency in Hz, Peak Acceleration in g and Peak Displacement in mm.




**It is important to notice that the PVS calculation required 3 active channels to be generated.**

**PPV:** is a measurement of maximum ground particle movement speed, it is in millimeters per second (mm/sec), PPV is a "vector" quantity (i.e. it has both a value and an associated direction).

**Peak Vector Sum (PVS):** is simply the square root of the sum of the squares of the individual PPV values. PVS is a "scalar" quantity, i.e. one with only a value, which is always larger than the individual PPV vector values.

Scientific studies have shown that the PPV correlates best with damage potential of all the tested characterizations of ground movement (e.g. acceleration, displacement, or strain). Most, though not all, ground vibration standards are quoted in PPV values, although the "acceptable" values of PPV differ with the standard applied and with the frequency of the vibration components.



**Figure 47: Velocity Graph**




Figure 48: Velocity and FFT Graph, PPV and PVS




Figure 49: DIN 4150 Real Time Graph, PPV & PVS

- **Automatic DIN Report (S.E.T):** check to enable DIN4150-3 report automatic generation when threshold is reached, or an acquisition cycle is reached on the S.E.T acquisition mode.

An automatic Report will be sent to the email addresses configured on Alarm Management Option.

<b>BeanAir</b>		06-Feb-19 12:07:37
BeanDevice MAC_ID : F4B85E00A14B0000		Sensor Label : Ch_Z

### DIN 4150-3 REPORT


Building Type	Commercial
Pipeline Material	Steel
Velocity Average(mm/s)	0.0177327272727272
Sampling Rate(hz)	100
Analyze Duration(hh:mm:ss)	00:00:01.1000000
LTVEE	OK
LTEBP	OK
Velocity Frequency(hz)	0
PCPV(mm/s)	2.4892
STEBP	OK
STVEE	NOK

KeyWord	Meaning
LTVEE	Long Term Vibration Evaluation Effect
LTEBP	Long Term Effect on Buired Pipework
STEBP	Short Term Effect on Buired Pipework
STVEE	Short Term Effect Evaluation
PCPV	Peak Component Particle Velocity

**Figure 50: DIN 4150-3 Report email**


INFORMATION	DETAILS
Building type	User configurable
Pipeline Material	User Configurable
Velocity Average	Get the average of the signal after transforming the acceleration signal into velocity signal
Sampling Rate	In Hz
Analyse duration	BeanScape property
Long term vibration evaluation effect	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Long term Effect on buried pipework	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Velocity Frequency	Get the signal frequency (FFT + windowing)
Maximum velocity (mm/s)	BeanScape Property
Short term Effect on buried pipework	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Short term vibration effect evaluation	<ol style="list-style-type: none"> <li>1-find the maximum velocity value over the time.</li> <li>2-Determine the significant frequency (use the FFT + windowing).</li> <li>3-compare the maximum velocity to the guideline value described on the Norm DIN 4150</li> <li>5-Display if the result is OK or not (guideline respected or not)</li> </ol>

- **Enable Velocity Log file:** check to enable Velocity data to be stored in the log folder.





**Figure 51: Velocity Log Folder/Files**

- **Enable PPV Log file**



**Figure 52: PPV Log Folder/Files**




 : Velocity Advanced Configuration


**Figure 53: Velocity Advanced Configuration**

By default, the Velocity is configured “By Zero Crossing”, to edit the Velocity settings user must select “By FFT” or “By Filter”.




- **By FFT:** By selecting this option, the user will setup the Velocity basing on customized FFT settings.
  - o Auto: If Auto is selected, The Velocity calculation will activate FFT Auto mode Settings




- Manual: Once switched to Manual, the user must configure the FFT settings manually (Window Type, Algorithm & Zero Padding).

By clicking on Import the Configuration will import the FFT current settings, already configured on the FFT frame.




**To save all settings Press Validate. The new settings should be displayed on the Left side of the Window.**



- **By Filter:** By selecting this option, the user will setup the Velocity basing on the Software Filter.



**The Software filter is available for Streaming and S.E.T Mode.**



- Auto: If Auto is selected, Velocity Automatic filter will be configured

By Filter

Streaming Mode SET Mode

Auto Filters Profile: [dropdown] [check] [trash] [eraser] [download] [upload]

**Response Type**

Highpass  
 Bandpass

**Design Method**

IIR Chebyshev\_type\_I [dropdown]  
 FIR Equiripple [dropdown]

**Filter Order**

Minimum Order  
 Specify Order [input]

**Frequency Specification**

Units: Hz  
Fs: 2000 [dropdown]  
Fstop1: 0.1 [input]  
Fpass1: 2.5 [input]  
Fpass2: 800 [input]  
Fstop2: 999 [input]

**Magnitude Specification**

Units: dB  
Astop1: 60 [input]  
Wpass: 0.1 [input]  
Wstop2: 60 [input]

File name: [input] [save]

**Filter Specification**

Close Validate

- Manual: Once switched to Manual, the user must configure manually the Filter settings.
- ❖ Response Type: User should specify if the Response is **Highpass** or **Bandpass**

Response Type


Highpass  
 Bandpass


- ❖ Design Method: User should Select the nature of the Filter between **IIR** or **FIR**  
From the List of every filter, user have to specify the method of the Filter:  
IIR: Chebyshev\_type\_I, Chebyshev\_type\_II or Butterworth  
FIR: Equiripple, Generalized\_Equiripple or Kaiser\_Window



***The Frequency Specification and The Magnitude Specification will be modified according the selected Design Method***


- ❖ Filter Order: If the user is using IIR Design Method, Minimum Order will be selected automatically.  
If the FIR Design Method is selected, user must Specify Order.
- ❖ Frequency Specification: Is a customizable frame according to the Design Method.
- ❖ Magnitude Specification: Is a customizable frame according to the Design Method.
- ❖ Filter Profile: User can save a specific Configuration and re-use it later.

File name :  




The screenshot shows a control panel titled "By Filter". At the top, there are two modes: "Streaming Mode" and "SET Mode". Below that, there is a "Manual" toggle switch and a "Filters Profile" dropdown menu. To the right of the dropdown are several icons: a checkmark, a trash can, a filter icon, a download icon, and an upload icon. Callout boxes point to these elements: "Import Filter" points to the upload icon; "Export Filter" points to the download icon; "Saved filters list" points to the "Filters Profile" dropdown; "Validate the chosen filter" points to the checkmark icon; "Delete the selected filter" points to the trash can icon; and "Delete all saved filters" points to the filter icon.


- ❖ Filter Specification: Is a Graphical Display of the Filter Specification depends on the user settings.



**To save all settings Press Validate. The new settings should be displayed on the Left side of the Window.**



7.3.5.3 Online waveform configuration




- **Automatic Wave Report (S.E.T):** Check to enable waveform reports, this is only available for S.E.T mode
- **Enable Wave Log file:** check to enable logging wave form for real-time data (only S.E.T mode)

7.3.5.4 Software filters

- **Enable IIR Filter:** Check to enable IIR filter

7.3.5.5 Unit of acceleration


Select which unit to be used for acceleration measurement.



### 7.3.5.6 S.E.T threshold

In so many cases the threshold is needed to be set in mm/s and not in g or mm/s<sup>2</sup>, you need to configure your S.E.T threshold parameters before starting.

To configure the threshold to be set in mm/s, you need to go to Online Data Analysis and change S.E.T threshold from acceleration to Velocity.



### 7.3.6 Tab: Datalogger



For further information about the Datalogger, please read the technical note [TN RF 007 – “BeanDevice® Datalogger User Guide”](#)

Custum display	Notes	Data Acq. config.	Sensor Config
Datalogger	System config.	Power mode managt	Online Data Analysis

**DataLogger status**

DataLogger status: Ready

Download progress:  NA

Download status: NA

**DataLogger manager**

**Download manager**

**DataLogger memory configuration**

"Stop DAQ" recording   
  "Stop at end" recording  
 "Stop DAQ DE" recording


***Figure 54: Datalogger Tab***

Data logger tab is composed of five different fields:

- ***Datalogger Status***
- ***Datalogger manager***
- ***Download manager***
- ***Acquisition information***
- ***Datalogger memory configuration***



### 7.3.6.1 Datalogger status




- **Datalogger status:** Displays logger status, four status are available:
  - **Ready:** the Datalogger is ready to register data
  - **NotInit:** the Datalogger is not initialized;
  - **Active logs only:** Data acquisition is logged only;
  - **Active TX and Log:** Data acquisition is logged & transmitted by Radio;
  - **Stopped:** Datalogger is stopped;
- **Download process:** Displays the download process 0 to 100%. If 100%, all the data logs are successfully downloaded on your PC.
- **Download status:** Displays the download status, two types of status are available:
  - **Processing:** Data logs download is under process;
  - **Completed:** Data Logs are completely downloaded on your PC;

### 7.3.6.2 Datalogger manager




- **Stop:** Stops Data Logging process
- **Erase:** Stops & Erases all the logs on flash memory

### 7.3.6.3 Download manager



- **Download:** Starts to download all the logs on the flash memory
- **Download then erase:** downloads all the logs and the erase them.
- **Cancel:** Stops the download process
- **Stop DAQ, download then erase.**

### 7.3.7 Tab: System config.



*Figure 55: System Configuration Tab*

Parameter	Description
<b>Diagnostic cycle</b>	You can set the BeanDevice® diagnostic cycle (Battery status, LQI, PER ...). The Diagnostic cycle is a ratio of the data acquisition cycle. <b>Ex:</b> If you try to set the diagnostic cycle ratio at 2 while the data acquisition cycle is set at 5s, the diagnostic cycle will be settled to 10s ;
<b>Restart Device</b>	You can restart your BeanDevice® from BeanScope®.

### 7.3.8 Tab : Power mode management



For further information about Power mode management, please read the technical note [TN\\_RF\\_010 – « BeanDevice® Power Management »](#)

This Tab is composed of three options:

- ✓ **Battery Saver Power mode configuration:** Configure the Power mode on your BeanDevice® (active / Battery saver mode)
- ✓ **BeanDevice Listening Ratio:** Configuration settings for Battery Saver power mode with network listening
- ✓ **Delete Pending OTAC frame:** Delete the last performed OTAC

The screenshot shows the 'Power Mode Management Tab' with the following configuration options:

- Battery Saver :** Enable (dropdown menu)
- BeanDevice Listening Ratio :** 5 (spinner)
- Listening Cycle :** 00:00:05 (time picker)
- Validate** (button)
- Delete pending OTAC frame** (button)
- Validate** (button)

*Figure 56: Power Mode Management Tab*

Parameter	Description
<b>Battery Saver configuration</b>	<p><b>Enable:</b> Battery Saver power mode is enabled. The BeanDevice® operates on Saver battery power mode to decrease the power consumption.</p> <p><b>Disable:</b> Battery Saver power mode is disabled, the BeanDevice® works in active power mode.</p> <p><b>Ratio:</b> Fix the Ratio of the listening cycle. This ratio depends on the data acquisition low duty cycle.</p> <p><b>Example:</b> If the data acquisition is 30 seconds and the ratio is set to 5, the Listening cycle will be 150 seconds (5*30).</p>
<b>Delete pending OTAC frame</b>	By clicking on “validate”, the pending OTAC frame is deleted



[How to enable battery saver power mode](#)

### 7.3.9 Right Click functionalities

BeanScape® offers access to quick functionalities in relation with BeanDevices®. By using the mouse, Right Click on the BeanDevice® profile then you can quickly

- [Change the Device Label](#)
- [Restart the Device](#)
- [Remove the Device](#)




Figure 57: Right Click on BeanDevice® Profile

## 7.4 SENSOR CHANNEL PROFILE

The screen « *Sensor channel profile* » consists of three parts:


- 1 **General information on the measurement channel;**
- 2 **Measurement channel configuration;**
- 3 **A graph which displays in real-time sensor signals during data acquisition;**



Figure 58: Overview: Sensor channel profile


## 7.4.1 Sensor channel status

### 7.4.1.1 Frame: General information



**Figure 59: Sensor Channel General information frame**

### 7.4.1.2 Frame: Measurement data



**Figure 60: Measurement data frame**

By default, sensor unit format is

- G or mm/s<sup>2</sup> for the BeanDevice AX-3D & AX-3DS
- deg for the BeanDevice HI-INC

## 7.4.2 Sensor channel configuration

This frame contains a set of 5 tabs:

Custom Display	<ul style="list-style-type: none"> <li>Allows the end user to customize the sensor</li> </ul>
Notes	<ul style="list-style-type: none"> <li>Contains notes relating to the BeanDevice® sensor</li> </ul>
Alarm Config	<ul style="list-style-type: none"> <li>Sensor configuration interface. The user can configure the alarm thresholds related to the sensor</li> <li>Depending on the BeanDevice® version which is used, other configuration parameters are available</li> </ul>
Sensor calibration	<ul style="list-style-type: none"> <li>Sensor channel calibration</li> </ul>
Log config	<ul style="list-style-type: none"> <li>Logs configuration on the BeanScope®</li> </ul>

### 7.4.2.1 Tab: Custom display on the BeanDevice® AX-3D/AX-3D-SR

These parameters allow the user to customize his sensor:

The screenshot shows the 'Sensor Config' window with the 'Custom display' tab selected. The 'Label' field contains 'Ch\_Z', 'Unit' is 'g', 'Ratio' is '1', and 'Offset' is '0'. There is a 'Validate' button below the 'Label' field. The 'Zeroing sensor channel' section has an 'Apply' button.

**Figure 61: Sensor channel custom display tab**

- ✓ **Label:** Give a name to your sensor. (**ex:** Sensor on Stator Machine 1, sensor in Room 2 Floor 3)
- ✓ **Zeroing sensor channel:** Center the signal graph in the 0 value (cancel the gravity value)

### Zeroing



In order to secure accurate and precise Velocity and FFT measurements on axis that's mounted toward the earth gravity you should Apply zeroing to cancel earth gravity.

Zeroing sensor channel:

#### 7.4.2.2 Tab: Custom display on the BeanDevice® Hi-Inc & Hi-Inc-SR

The screenshot shows a 'Sensor Config' window with several tabs: 'Custom display', 'Notes', 'Alarm level Config', 'Sensor calibration', and 'Log config.'. The 'Custom display' tab is active, showing a 'Label' field with 'Ch\_Y', a 'Unit' field with 'deg', a 'Ratio' field with '1', and an 'Offset' field with '0'. There are 'Validate' and 'Conversion' buttons at the bottom.

*Figure 62: Hi-Inc sensor channel custom display tab*

- ✓ **Type:** Describe the sensor type (ex: load cell, pressure, Strain gage +/- 2 Mv/v, LVDT,)
- ✓ **Unit:** customer sensor unit (bar, °C, l/h....)
- ✓ **Ratio:** Sensor Ratio coefficient (**RAT**);
- ✓ **Offset:** Sensor Offset coefficient (**OFF**);

#### **Measurement conversion formula:**

$$\text{Converted Measurement} = \text{Measurement} \times \text{RAT} + \text{OFF}$$

**Example with a temperature sensor:** By default, the temperature unit is in degree Celsius. The user wants to convert the unit in degree Fahrenheit.


$$\text{Converted Measurement [°F]} = \text{Measurement[°C]} \times \text{RAT} + \text{OFF}$$

With **RAT** = 1.8 and **OFF** = 32

#### **Conversion assistant**

To avoid conversion error, a conversion assistant is available to help you to setup quickly your measurement channel of your BeanDevice®.


Click on conversion assistant from the tab "**Custom display**", a window will open allowing you to do a linear conversion.



The screenshot shows the 'Sensor Config' window with several tabs: 'Custum display', 'Notes', 'Alarm level Config', 'Sensor calibration', and 'Log config.'. The 'Custum display' tab is active. It contains input fields for 'Label' (Ch\_Y), 'Unit' (deg), 'Ratio' (1), and 'Offset' (0). A 'Validate' button is located below the 'Label' field. A 'Conversion' button is highlighted with a red rectangle at the bottom center of the window.

On the left column, the user can enter the non-converted measurement data. On the right column, the user can enter the converted measurement values with the desired unit.

The ratio and offset values are calculated automatically by the conversion assistant.



The 'Unit Conversion Assistant' dialog box is titled 'Linear Conversion'. It features a table with two columns: 'Input' and 'Output'. The 'Input' column has two rows: 'Value 1' with a value of -18.21 and unit 'deg', and 'Value 2' with a value of 18.21 and unit 'deg'. The 'Output' column has two rows: '0' and '1', both with the text 'not defined'. Below the table, there is a 'Target Unit:' label and a dropdown menu showing options: °C, °K, bar, and N/cm².

	Input	Output
Value 1	-18.21 deg	0 not defined
Value 2	18.21 deg	1 not defined

**Figure 63: Unit Conversion Assistant**




### 7.4.2.3 Tab : Notes

**Figure 64: Sensor channel notes tab**

This field contains notes relating to the BeanDevice® sensor. To change this field, enter a value or free text and click the “Validate” button.

A new window opens; accept your modifications by clicking on “OK”.



To back up your text click on the icon “Backup your Database”



### 7.4.2.4 Tab: Alarms Config - BeanDevice® AX-3D/Hi-Inc/AN-XX

**Figure 65: Alarm configuration tab (BeanDevice® AX-3D)**

Parameter	Description
<p><b>Alarm threshold configuration for S.E.T mode</b></p>	<p>The S.E.T mode (Streaming with event triggering) the threshold is based on AAA(Alert/Action/Alarm) with:</p> <p style="text-align: center;">Alert values &lt; Action value &lt; Alarm value.</p> <p>Measurement exceeding each threshold will results in notification sent with the appropriate reports and info via email and audio notification on the computer will take place.</p>




For further information about the alarm thresholds configuration, please read the technical note [TN RF 008 – “Data acquisition modes available on the BeanDevice®”](#)

7.4.2.5 Tab: Alarms Config Configuration - BeanDevice® AX-3DS



For further information about the SSD (Smart Shock Detection) measurement mode, read the technical note [TN RF 008 – “Data acquisition modes available on the BeanDevice®”](#)



*Figure 66: Alarm configuration tab (BeanDevice® AX-3DS)*

Parameter	Description
Alarm threshold	<p>You can configure threshold high values (High level alarm, High level alert) and low values (Low level alarm, Low level alert). In alarm mode, when a higher low threshold value is reached, an alarm notification is transmitted to the BeanGateway ;</p> <p>If the sensor value is higher than High level alarm/High level alert, notification is send to the BeanGateway/BeanScape;</p> <p>If the sensor value is lower than Low level alarm/Low level alert, notification is send to the BeanGateway/BeanScape.</p> <p>Threshold values must be organized in this manner:                      High level alarm &gt;=High level alert &gt; Low level alarm &gt;= Low level alert</p> <p><b>Alarm thresholds are not available for SSD (Smart shock detection mode)</b></p>
Accelerometer range configuration	<p>✓ The user can change the measurement range of the accelerometer:</p> <ul style="list-style-type: none"> <li>• <b>BeanDevice® AX-3DS 24G</b>: ±6g or ±12g or ±24g</li> <li>• <b>BeanDevice® AX-3DS 8G</b> : ±2g or ±4g or ±8g</li> </ul>
Shock detection configuration	Click on modify, a new window will open.





Figure 67: Shock detection configuration window

1

Changes the accelerometer bandwidth during the sleep period of the BeanDevice®:



Depending on the sampling rate of the accelerometer during the sleep period, the BeanDevice® current consumption can vary:

<i>Accelerometer sampling rate during sleep period</i>	<i>BeanDevice® Current consumption</i>
0,5 Hz	21 $\mu$ A
1 Hz	31 $\mu$ A
2 Hz	50 $\mu$ A
5 Hz	78 $\mu$ A
10 Hz	130 $\mu$ A
50 Hz	302 $\mu$ A
100 Hz	308 $\mu$ A
400 Hz	343 $\mu$ A
1000 Hz	413 $\mu$ A

2

The user can select two events profile **Event 1** and **Event 2**.

3

#### **Event combination**

The user can use two logical combinations: **AND** and **OR** combination on the axis event selection.

4

#### **Set the shock detection threshold**

Unit value: g

The threshold resolution depends highly on the acceleration range.

On the axis event selection frame, if the high axis is selected, the threshold value will be positive.

If the Low axis is selected, the threshold value will be negative.

**Example:** For a threshold value settled at 2g, if X High Axis **OR** X Low Axis is selected.

For all the values upper than 2g on the X Axis, a shock event is detected

For all the values less than -2g on the X Axis, a shock event is detected.

5

**Axis event selection**


The user can associate a shock event with an axis: X Axis High, X Axis Low, Y Axis High, Y axis Low, Z Axis High, Z Axis Low.

The **AND/OR** combination is not available for two events on the same axis, i.e. the following combinations are not possible: X High **and/or** X Low, Y High **and/or** Y Low, Z High **and/or** Z Low.


- **TH\_VALUE** is the shock detection threshold settled by the user
- **Range\_MAX** is the maximum measurement of the wireless accelerometer

**Several configuration of shock detection are possible on the same axis:**

- The user selects **XX Axis Low**, all the shocks events are detected on the following acceleration range  $[-TH\_VALUE ; +TH\_VALUE ]$



- The user selects **XX Axis High**, **all the shocks are detected** on the following acceleration range  $[Range\_MIN ; -TH\_VAL]$  and  $[+TH\_VALUE; Range\_MAX];$

	 <ul style="list-style-type: none"> <li>The user selects a high event on the axis (+TH_VALUE), a shock is detected if the threshold value +TH_VALUE is reached:</li> </ul>
<p>6</p>	<p><b>Hysteresis</b></p> <p>The user can fix an hysteresis on threshold value Choose closely the value of the hysteresis. The resolution depends on the accelerometer bandwidth during sleep or deep sleep.</p>
<p>7</p>	<p><b>VALIDATE</b></p> <p>Click here to validate your new configuration</p>
<p>8</p>	<p><b>RESET</b></p> <p>Click to restore a default configuration</p>
<p>9</p>	<p><b>CANCEL</b></p> <p>Click here to cancel your configuration</p>



Depending on your sensor resolution, the displayed threshold value can differ from the reference value.

#### 7.4.2.6 Tab : Sensor calibration



***WARNING:*** These calibration coefficients should be accessible to an advanced user. A wrong calibration will result in false measurements.

These coefficients are used to calibrate the *internal accelerometer/inclinometer* sensors:

- **AX-3D sensor calibration tab description**

***Figure 68: AX-3D Sensor calibration tab***

- **AX-3D-SR sensor calibration tab description**

***Figure 69: AX-3D-SR sensor calibration 1.2g measurement range***

**Figure 70: AX-3D-SR sensor calibration 2.4g measurement range**

The BeanScope® provides a calibration interface for each measurement channel:

- **Ratio:** multiplier coefficient
- **Offset:** adder/subtracted coefficient. its unit is the sensor unit

$$\text{Calibrated value} = (\text{Ratio} \times \text{Non\_Calibrated\_Value}) + \text{Offset}$$

Enter the calibration coefficients and then click on validate.



*The calibrations coefficients are backed up on the BeanDevice® flash memory, and cannot be lost if the BeanDevice® is switched off*

#### 7.4.2.7 Tab: Log configuration



*This tab should not be confused with the Datalogger feature available on the BeanDevice®:*

**Figure 71: Log configuration tab**

By default, Log file name is built with the measurement channel & BeanDevice® MAC Address:

< **Sensor Channel Number** > < **MAC\_ID** >



- ✓ **Log enabled:** If checked, Log is enabled on the BeanScape®
- ✓ **Log filename auto.:** If checked, Log file name is named automatically

Click on **validate** in order to validate all your modifications.

For users who want to rename the log file, two solutions are provided:

<b>Solution 1</b>	<b>Add automatically the channel "Label" in your log file name:</b> <Label><Sensor channel Number> <MAC_ID>
<b>Solution 2</b>	<b>The log file name can be fully customized:</b> Uncheck the case « Log filename auto" and add your own label




*The file name will be changed only if the separated files generation option was selected.*

#### 7.4.2.8 Right Click functionalities

Graphic BeanScape® offers access to quick functionalities in relation to Sensor channels. By using the mouse, Right Click on the channel under the BeanDevice® profile then you can quickly:

- **Change State to: off**
- **Change Sensor Label**
- **Disable Log**




**Figure 72: Right Click on the Sensor's Channel**

### 7.4.3 Graphical display

By selecting the suitable sensor's channel, user will get this view on his BeanScope® software.



**Figure 73: Overview: Channel acquisition graph visualization of the AX-3D**



**Figure 74: Real-time graph of the temperature channel on the AX-3D-SR**



To have a wide display view of the graph, it is recommended to click on the Minus symbol icon on the top left of the sensor's channel configuration area to hide it.




Figure 75: Sensor profile ON/OFF display button




Figure 76: Wide view of the graph

The chart is composed of two parts:

- **Part 1:** This is a preview window, allowing you to observe sensors acquisitions.
- **Part 2:** A strip on the side composed of different frames allows customizing the graph.

The graph has two axes:



**Axe-X:** Timeline


**Axes-Y:** received sensor acquisitions

The BeanDevice® data acquisition mode and the last data acquisition can be visualized directly from the graph.



**Figure 77: Example: Graph visualization**


#### 7.4.3.1 Frame: Display



**Figure 78: Graph measure mode: Frame Display**

#### 7.4.3.2 Frame: Marks

From this frame you can select the display mode of action of the chart. Three types of symbols are available:



**Circle:** Brings up a point on each bar graph

**Square:** brings up a square on each measure of the graph


**None:** No logs is displayed on the graph



**Figure 79: Graph measure mode: Frame Marks**

### 7.4.3.3 Frame : Scale

From this frame, the scaling of the graphics can be customized to suit your needs.




#### **Checkbox "Zoom X and Y Zoom"**

These boxes are useful for performing a graph zoom from the mouse wheel, there are four cases:

- **Case 1**: Case "Zoom X" ticked. The graph zoom will only affect the X axis.
- **Case 2**: Case "Zoom Y" ticked. The graph zoom will only affect the Y axis.
- **Case 3**: Case "Zoom XY" ticked." Zoom will affect both X and Y axes
- **Case 4**: Case "Zoom X", "Zoom XY" and "Zoom Y" not ticked. The zoom function from the mouse wheel is disabled.

## 7.5 DATALOGGER CONFIGURATION




*Figure 80: BeanDevice® Datalogger tab*



Please read the technical note [TN\\_RF\\_007 – “BeanDevice® datalogger User Guide”](#)

## 7.6 OPTIONS FOR LOG FILE GENERATION & FOLDER ORGANIZATION


### 7.6.1 Log file system overview



Default log directory is **c:/log\_beanscape**

Each Beandevic comes with a dedicated log folder containing:


- ✓ log files linked to data acquisition
- ✓ log file linked to diagnostic



### 7.6.2 Log file directory

By default, the Log file directory is: **C:\log\_beanscape**

Click on the tab Tools then Options to configure advanced settings in **BeanScape®**:




**Figure 81: BeanScape® configuration menu**



This window lets you configure the logs, and the data cache.

- ✓ A second window is displayed:



*Figure 82: BeanScape® configuration window*

- ✓ Clicking the button  reverts back to its original configuration.



### 7.6.3 Log folder

By Default, log files linked to the **BeanDevice®** are stored in the log folder (located in C:/log\_beanscape directory):

**“Folder MAC\_ID”**

Only the last 4 Char of BeanDevice® MAC ID are displayed.

User can change log folder name by clicking on “Custom display” tab located on the **BeanDevice®** profile:

Datalogger	System config.	Power mode managt	Online Data Analysis
Custom display	Notes	Data Acq. config.	Sensor Config

Location :	<input type="text" value="Device Location"/>
Label:	<input type="text" value="MAC_ID : 0 x 00158D00000E1049"/>
Log folder:	<input type="text" value="Folder 1049"/>

*Figure 83: BeanDevice® Custom Display tab*


Enter your own log folder name, then click on validate.

The following example shows the log folder changed to “Factory2”:

Location :	<input type="text" value="Device Location"/>
Label:	<input type="text" value="MAC_ID : 0 x 00158D00000E1049"/>
Log folder:	<input type="text" value="Factory2"/>

*Figure 84: BeanDevice® custom display settings*

### 7.6.4 Log file size configuration




**Figure 85: Logfile settings**

- ✓ **LOG directory:** Enter here the path/folder where you would want to save the LOG files.
- ✓ **Main log filename:** Here you may enter the desired name in order to save the LOG file.
- ✓ **Main log max. size (KB):** Maximum file size in Kilobytes (KB) for your principal LOG file
- ✓ **Sensor Log Enabled:** Check this box if you want to enable the sensor(s) data acquisition in your LOG file
- ✓ **Sensor log max. size (KB) :** Maximum size in Kilobytes (KB) of sensor log files (**except** for streaming & streaming data acquisition mode)
- ✓ **Network log info. enabled :** Check this box if you want to enable network information in your LOG file
- ✓ **Network info log max. size (KB) :** Maximum size in Kilobytes for your network information LOG file
- ✓ **Streaming log max. size :** Maximum size in Kilobytes (KB) of sensor log files (**only** for streaming & streaming data acquisition mode)
- ✓ **Precision:** change the device precision for measurements and calibration process.


### 7.6.5 All sensor channels in one log file

By default, 1 log file is linked to 1 sensor channel. The user can select a log file linked to all the sensor channels present on the BeanDevice®.



**Figure 86: Log file generation options**

- You should have all channels data recorded in one single file located in your C:\log\_beanscape directory



**Figure 87: Example of Log file**

### 7.6.6 Cache Data configuration (for Graph)

The screenshot shows the 'BeanScape Configuration' window with a sidebar on the left containing menu items: Log, Keep Alive App, TCP/UDP, System, Data cache (highlighted), Data Logger, Gravity, StartUp, Date and Time Format, Language, and Precision. The main area displays the following settings:

Max. points :	3000
Max. packets :	6
Max. diagnostics :	1000
Max. BGw Module status nbr. :	100
Syst. Maint. Status max nbr :	500
Max. alarms :	25
Max. streaming points :	5000

At the bottom of the window are four buttons: Reload, Apply, Save, and Reset.

*Figure 88: Data cache configuration options*

- ✓ **Maximum number of points:** Set here the maximum number of points displayed on the BeanScape® graph
- ✓ **Maximum number of packets:** Set here the maximum number of packets displayed on the BeanScape® graph
- ✓ **Max number of diagnostics:** Set here the maximum number of diagnostics displayed on the BeanScape® graph
- ✓ **Max number of alarms:** Set here the maximum number of alarms displayed on the BeanScape® graph
- ✓ **Maximum streaming points:** Set here the maximum number of points displayed in Streaming/Streaming on the BeanScape® graph



*Please note that the values backed up by the BeanScape® may affect the memory capacity of your computer depending upon the size of every file.*

## 7.6.7 Data acquisition Log file

### 7.6.7.1 Log filename root

For each sensor channel a log file is automatically created by the BeanScape®.


The user can easily change the log file root:



**Figure 89: Overview: Log Config tab on BeanScape®**



*This tab should not be confused with the Datalogger feature available on the BeanDevice®.*



**Figure 90: Log config tab**

By default, Log file name is built with the measurement channel & **BeanDevice®** MAC Address:

< Sensor Channel Number > <MAC\_ID>

- ✓ **Log enabled:** If checked, Log is enabled on the BeanScape®
- ✓ **Log filename auto.:** If checked, Log file name is named automatically

Click on **validate** in order to validate all your modifications.

For users who want to rename the log file, two solutions are provided:

<b>Solution 1</b>	Add automatically the channel "Label" in your log file name: <Label><Sensor channel Number> <MAC_ID>
<b>Solution 2</b>	The log file name can be fully customized: Uncheck the case « Log filename auto" and add your own label This option is working only with separated files option







### 7.6.7.2 Specific case: log filename creation in "Streaming" mode

In streaming mode, log filename is built as follow (separated channels):

**Transmit\_Streaming\_Sensor\_channel\_MAC\_ID\_DATE**

- ✓ **Sensor channel = Sensor channel**
- ✓ **MAC\_ID: BeanDevice® MAC ID**
- ✓ **DATE: date when the streaming mode starts**

#### Example:



 Transmit_Streaming_Ch_X_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-42-31.txt	24/10/2018 11:45	1 Ko
 Transmit_Streaming_Ch_Y_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-42-31.txt	24/10/2018 11:45	1 Ko
 Transmit_Streaming_Ch_Z_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-42-31.txt	24/10/2018 11:45	1 Ko
 Transmit_Streaming_Ch_X_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-45-14.txt	24/10/2018 11:47	192 Ko
 Transmit_Streaming_Ch_Y_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-45-14.txt	24/10/2018 11:47	185 Ko
 Transmit_Streaming_Ch_Z_MAC_ID__0_x_00158D00000E06A8_2018-10-24_11-45-14.txt	24/10/2018 11:47	181 Ko

In streaming mode, log filename is built as follow (all channels in one file):


**Transmit\_Streaming\_Sensor\_channel\_MAC\_ID\_DATE\_PART**

- ✓ **Sensor channel = Sensor channel**
- ✓ **MAC\_ID: BeanDevice® MAC ID**
- ✓ **DATE: date when the streaming mode starts**
- ✓ **partXXX : Log file sequence number, part000 corresponds to the first log file**

#### Example:

 Transmit_Streaming_MacId_00158D00000E06A8_24_10_2018_11_42_31_part1.txt	24/10/2018 11:44	2,064 Ko
 Transmit_Streaming_MacId_00158D00000E06A8_24_10_2018_11_42_31_part2.txt	24/10/2018 11:44	174 Ko

### 7.6.7.3 Log file analysis



```

Transmit_Streaming_Ch_Z_MAC_ID__0_x_5C313E06A9A70000_12_11_2020_4_25_01_PM.txt - Notepad
File Edit Format View Help
-----
BeanDevice : AX 3D

Range for accelerometer: -2g / +2g
Mac Id : 5C313E06A9A70000
Network Id : 0121
Pan Id : FFFE
Measure mode : Streaming
Streaming Options : Continuous Monitoring
Sensor Id : 0
Sensor Label : Ch_Z
Ratio : 1
Offset : 0
Unit for accelerometer : g

DATE_FORMAT : M/d/yyyy h:mm:ss tt.fff
Date : 12/11/2020 4:25:01 PM.110
Sampling rate : 10
-----
TimeStamp;Measure

0;0.783
1;0.782
2;0.781
3;0.782
4;0.784
5;0.783
6;0.783
7;0.784

```

**Figure 91: Log file example (Streaming mode)**

The date which is displayed in the log file corresponds to the date when the streaming mode starts.

**Measure index** allows the user to use a timestamp, the time value between the Index N and N+1 corresponds to the period rate.

## 7.6.8 Log file related to Wireless Network diagnostic

### 7.6.8.1 Log filename organization

Wireless Diagnostic log filename is built as follow:

**MAC\_ID\_WirelessNetwkInfo**

- ✓ **MAC\_ID:** *BeanDevice® MAC ID*
- ✓ **DATE:** *date when the streaming mode starts*

7.6.8.2 Log file analysis

Log file related to wireless network diagnostic provides the following information:

- **Date** : diagnostic date
- **LQI TX**: Link quality indicator on the BeanDevice® side
- **LQI RX**: Link quality indicator on the BeanGateway® side
- **Local PER TX**: Local Packet Error Rate on the BeanDevice® side
- **Local PER Rx**: Local Packet Error Rate on the BeanGateway® side
- **Global PER**: N.A.
- **Battery voltage**: internal battery voltage
- **Battery level**: battery level of charge
- **Internal temperature**: Local temperature of the BeanDevice®

```

00158D0000E1049_WirelessNetwkInfo.txt - Notepad
File Edit Format View Help
-----
BeanComponent Wireless Network Information
DATE_FORMAT : M/d/yyyy h:mm:ss tt
Date : 12/14/2020 9:06:01 AM
PAN_ID : 391A
MAC_ID : 00158D0000E1049
-----

Date ; LQI Tx ; LQI Rx ; Local PER Tx ; Local PER Rx ; Battery Voltage ; Battery Level ; Internal Temperature ; DisableDischarge ;

12/14/2020 9:05:58 AM;132;0;3.57;0;4.226;97.91;17.000;N;N;N;N;N;0.00
12/14/2020 9:06:48 AM;180;0;1.86;0;4.226;97.91;17.500;N;N;N;N;N;0.00
12/14/2020 9:07:38 AM;90;0;1.26;0;4.226;97.91;18.000;N;N;N;N;N;0.00
12/14/2020 9:08:28 AM;96;0;1.91;0;4.226;97.91;18.125;N;N;N;N;N;0.00
12/14/2020 9:09:18 AM;174;0;2.3;0;4.226;97.91;18.500;N;N;N;N;N;0.00

```

**Figure 92: Wireless Network Info log file**

If the BeanDevice® is configured with the streaming data acquisition mode, the following diagnostic information are not refreshed:

- **Battery voltage**
- **Battery level**
- **Internal temperature**



00158D0000E1049\_WirelessNetwkInfo.txt - Notepad

File Edit Format View Help

-----  
 BeanComponent Wireless Network Information

DATE\_FORMAT : M/d/yyyy h:mm:ss tt

Date : 12/14/2020 9:06:01 AM

PAN\_ID : 391A


MAC\_ID : 00158D0000E1049  
 -----

Date ; LQI Tx ; LQI Rx ; Local PER Tx ; Local PER Rx ; Battery Voltage ; Battery Level ; Internal Temperature ; DisableDischarge ;


```
12/14/2020 9:05:58 AM;132;0;3.57;0;4.226;97.91;17.000;N;N;N;N;N;0.00
12/14/2020 9:06:48 AM;180;0;1.86;0;4.226;97.91;17.500;N;N;N;N;N;0.00
12/14/2020 9:07:38 AM;90;0;1.26;0;4.226;97.91;18.000;N;N;N;N;N;0.00
12/14/2020 9:08:28 AM;96;0;1.91;0;4.226;97.91;18.125;N;N;N;N;N;0.00
12/14/2020 9:09:18 AM;174;0;2.3;0;4.226;97.91;18.500;N;N;N;N;N;0.00
```

### 7.6.8.3 How to open a measurement file with excel


#### Step 1 : Open Excel



#### Step 2: Go on « Data » Tab, then select “From Text”




#### Step 3 : Choose your log file




**Step 4 :** Text import wizard will open, select « Delimited » for Characters such as commas or tabs separate each field.


On “Start import at row” field: Select the number of lines that you want to suppress from the header:




Select semicolon




Select Text



Click on OK




Click on format cells:



[See "Exporting a log file to Excel" YouTube video](#)

#### 7.6.8.4 Calibration Settings log file

Once you connect the BeanDevice® to the BeanGateway® for the first time, all the calibration values will be backed up in the Calibration settings log file inside the BeanDevice folder.



```
Calibration-setting_MAC_ID_0_x_00158D00000E1049.txt - Notepad
File Edit Format View Help
----- Calibration Settings -----
BeanDevice : AX 3D
Mac Id : 00158D00000E1049
Network Id : 0003
Pan Id : 391A
DATE_FORMAT : M/d/yyyy h:mm:ss tt
Date : 12/14/2020 9:06:01 AM
-----
Date ; Sensor Label ; Ratio ; Offset
12/14/2020 9:06:01 AM; Ch_X; 1; 0
12/14/2020 9:06:01 AM; Ch_Y; 1; 0
12/14/2020 9:06:01 AM; Ch_Z; 1; 0
```

***Figure 93: Calibration log file***


If you change the your BeanDevice® calibration values, you can easily retrieve them from the calibration settings log file.

## 8. ALARM MANAGEMENT

### 8.1 EMAIL CONFIG

User can receive alarms notification by email. This function is only available with “**Survey**” data acquisition mode, “**Alarm**”, “**S.E.T**” mode or “**SSD**”.

From your BeanScape® software click on “**Tools**” tab then “**Alarm Management**”



*Figure 94: Alarm management menu*

A new window will pop up with **SMTP configuration** and reports management, also other system related to alarm notification (Internal temperature, Battery level, Packet Error Rate, Link Quality Indicator) are configured from this window

Check on **Enable Notification by email**:  **Enable Notification by email** and fill out the parameters described below:

Field	Description
<i>From</i>	<i>Enter the email address sending the alarm notification</i>
<i>To</i>	<i>Enter the receiver(s) address(es) for alarm notification (max. 3)</i>
<i>SMTP server</i>	<i>Enter your Outgoing SMTP server</i>
<i>Port</i>	<i>Enter your port Number for your outgoing SMTP server</i>
<i>User name</i>	<i>Enter your full email address</i>
<i>Password</i>	<i>Enter the password (case sensitive) of your email account</i>
<i>Max Email per minute</i>	<i>Maximum number of emails allowed to be sent in one minute</i>



Alarm Management

Email Config. DAQ Alarm Health Status SSD DAQ Mode Alarm DAQ Mode File Format DIN 4150-3 Config Crash report

Enable Notification by email

Note: Required Fields are marked with \*

From\*: host@host.com

To Contact 1: host@host.com

To Contact 2: host@host.com

To Contact 3: host@host.com

Smtp Server\*: smtpserver Port\*: 25

User Name\*: userName

Password\*: .....

SMTP Test

Validate

*Figure 95: Alarm management window*



Users who use the Gmail or Hotmail emails, it's recommended to use the port number 25 while setting the SMTP configuration. Otherwise, users will face issues concerning receiving the Alarm emails.




Do not use the port number 488 instead of 25 while configuring the SMTP server in order to cancel all the issues that might affect the process of receiving the Alarm Emails.



Concerning the number port of the Gmail and Hotmail SMTP, it's highly recommended to use the port number 25 for both servers. DO NOT use any other port number

## 8.2 DAQ ALARM

The **DAQ alarm** is related to the **S.E.T mode**, you can select Report format (word, PDF, png) and the specific Report/File related to the S.E.T mode to be sent via email.



*Figure 96: Frame: Email alarm for S.E.T mode*



*More details about FFT Report/ Log files can be found on the Data acquisition modes available on the BeanDevice [Technical note](#)*




[See « Alarm by email » Youtube video](#)



[See «S.E.T mode for 2.4GHz» Youtube video](#)

If a threshold is reached, it is possible to have audio alarm on your PC, it is also possible to import your own MP3 sound.



*Figure 97: Frame: Sound config*

### 8.3 SSD DAQ MODE

To enable email notification for Smart Shock Detection, navigate to [SSD DAQ Mode](#) tab check [Enable email](#), for Audio notification on PC check [Enable Notif/Sound](#)

#### Alarm Management

The screenshot shows the 'Alarm Management' interface with the 'SSD DAQ Mode' tab active. The 'Alert for SSD' section contains two checked checkboxes: 'Enable email' and 'Enable Notif/Sound'. The 'Voice / Sound Configuration' section features a dropdown menu currently displaying 'Bip', with a list of options including 'Bip', 'Voice', and 'MP3' visible below it.

*Figure 98: Email alarm for Shock detection*

To Test your Configuration, you can send a test email by clicking on SMTP Test, if everything is ok, you will receive a validation email then Validate and close the window.

The screenshot shows a dark blue interface with two buttons: 'SMTP Test' on the left and 'Validate' on the right.

*Figure 99: Alarm Mailing SMTP Test*

### 8.4 ALARM DAQ MODE

To enable email notification for Alarm mode, navigate to [Alarm DAQ Mode](#) tab check [Enable email](#), for Audio notification on PC check [Enable Notif/Sound](#)

#### Alarm Management

The screenshot shows the 'Alarm Management' interface with the 'Alarm DAQ Mode' tab active. The 'Email alarm for Alarm mode' section contains two checked checkboxes: 'Enable email' and 'Enable Notif/Sound'. The 'Voice / Sound Configuration' section features a dropdown menu currently displaying 'Bip', with a list of options including 'Bip', 'Voice', and 'MP3' visible below it.

*Figure 100: Email alarm for Alarm mode*



To Test your Configuration, you can send a test email by clicking on SMTP Test, if everything is ok, you will receive a validation email then Validate and close the window.



**Figure 101: Alarm Mailing SMTP Test**

## 8.5 SYSTEM ALARM

Same as the DAQ Alarm tab, the **System Alarm tab** contains SMTP configuration in order to receive notification on system status:



**Figure 102: BeanDevice® Health Status management**

- **Internal temperature:** email notification if the internal temperature reached the pre-defined levels.
- **Battery level:** email notification if the battery level reached the pre-defined minimum and maximum voltages.
- **Packer error rate (PER):** email notification if the PER reaches the pre-defined levels
- **Link quality indicator (LQI):** email notification when the LQI reaches the pre-defined levels

Check Send System Log file to receive all the related information within a log file.

**Figure 103: System Alarm Settings**

From System Alarm, user can receive Alert for Datalogger by enabling Notification or Emails, also receiving Alert for Diagnostic.

**Figure 104: Enable/Disable Notif/mail for Diagnostic and Datalogger**

## 8.6 FILE FORMAT

In this area, user can choose the report format and apply a custom document header setting as uploading a logo and other textual information related to monitoring site:

**Figure 105: File Format settings**

- **Logo:** Choose a picture to define it as a logo
- **User Name:** Use a specific User name
- **Monitoring Site:** Name you Monitoring Site
- **Location:** Your Monitoring Site location

Document Header

Logo:

User Name:

Monitoring Site:

Location:

*Figure 106: Alarm Note settings*

## 8.7 DIN 4150-30 CONFIGURATION

Din Configuration tab is used to select the Building type and the pipe material that should be displayed on the DIN Report and the Velocity Log file.

You can select 3 Building types from the list: **Commercial**, **Dwellings** and **Non\_Classified**.

For the Pipe material, the list contains: **Steel**, **Clay Concrete** and **Masonry Plastic**.

Alarm Management

Email Config. DAQ Alarm Health Status SSD DAQ Mode Alarm DAQ Mode File Format **DIN 4150-3 Config** Crash report

DIN Config

Building type: Commercial

Pipe material: Steel

Apply Save Reset

Building type: Commercial  
Dwellings  
Non\_Classified

Pipe material: Steel  
Clay, Concrete  
Masonry, Plastic

*Figure 107: DIN 4150-3 Configuration*

Ch\_Z – Max Frequency: 0 hz , VPPV = 119.329442495219 mm/s , Max Amplitude = 0.688049814453125 g

	Ch_X	Ch_Y	Ch_Z
Building Type	Commercial	Commercial	Commercial
Pipeline Material	Steel	Steel	Steel
Velocity Average(mm/s)	0.0031145223880597	0.00540280099502487	-0.00366334328358209

**Figure 108: Building type & Pipeline Material on the DIN Report**

```
=====> NO acceleration event occurred - MONIT
-----
----- DIN Report -----
Building type = Dwellings
Pipeline Material = Masonry,Plastic
Velocity Average (mm/s) = -0.0007515524999999
```

**Figure 109: Building type & Pipeline Material on the Velocity Log file**

## 8.8 CRASH REPORT

If the software crashes down, the user can send us a detailed report within all the information related to this crash.

Alarm Management

Email Config. DAQ Alarm Health Status SSD DAQ Mode Alarm DAQ Mode File Format DIN 4150-3 Config Crash report

Send crash report to BeanScope Tech Team
 

Note: Required Fields are marked with \*

Company Name\*:


User Name:

To (for test purpos:

**Figure 110: Crash Report settings**

## 9. TOOLS TAB

Many features are available in the tools tab, so user has access to several options and configurations related to BeanScope® & BeanDevice® management.




**Figure 111: Tools tab main menu**

### 9.1 BEANSCAPE® CONFIGURATION

BeanScope® menu window contains several configuration options related to the system configuration, Log file management and many other options.

#### 9.1.1 Log file configuration

Here the user can manage the log file size, log file name, log file generation option and so on.



**Figure 112: Log file configuration**

### 9.1.2 Keep Alive App



*Figure 113: Keep Alive app*


Three parameters related to keepalive are available:

- **Keep alive timeout** is the duration between two keep alive transmissions in idle condition. TCP keepalive period is required to be configurable and by default is set to no less than 2 hours.
- **Keep alive interval** is the duration between two successive keep alive retransmissions, if acknowledgement to the previous keep alive transmission is not received.
- **Max retry** is the number of retransmissions to be carried out before declaring that remote end is not available.

Keepalive packet contains null data. In a TCP/IP over Ethernet network, a keepalive frame is of 60 bytes, while acknowledge to this also null data frame and is of 54 bytes.


### 9.1.3 BeanGateway® Configuration via TCP/UDP

User can change the TCP/UDP ports and UDP server. By default, the TCP port is set to 5313, UDP port 53130 and the UDP server is 127.0.0.1



*Figure 114: TCP/UDP configuration*


### 9.1.4 System Configuration



**Figure 115: System Config**

- ✓ **System clock transmission enabled:** Check this box to enable the system clock transmission.
- ✓ **Clock transmission interval:** Choose the clock transmission interval in seconds.
- ✓ **Alarm automatic display:** Check this box if you want to see an alarm window displayed automatically when a window alarm threshold is exceeded.
- ✓ **Alarm → Sound Effect:** Check this box if you want to hear a sound effect when a threshold is exceeded.

### 9.1.5 Data cache configuration




**Figure 116: Data Cache configuration**

- **Maximum number of points:** Set here the maximum number of points displayed on the BeanScape® graph
- **Maximum number of packets:** Set here the maximum number of packets displayed on the BeanScape® graph
- **Max number of diagnostics:** Set here the maximum number of diagnostics displayed on the BeanScape® graph
- **Max BGw Module status number:** Set here the maximum number of modules displayed on the BeanGateway® Status graph on BeanScape® graph

- **System Maint Status max number:** Set here the maximum number of points displayed on the BeanGateway® Status graph on BeanScape® graph
- **Max. alarms:** Set here the maximum alarms number
- **Max. Streaming points:** Set here the maximum streaming points number.


### 9.1.6 Data Logger configuration



*Figure 117: Data logger configuration*

Check the data logger downloader check box to enable the automatic downloading process once, you start the connection.

### 9.1.7 Startup




*Figure 118: BeanScape® startup*

Check the AutoStart check box to enable auto launch BeanScape® software once you start your PC.




### 9.1.8 Date & Time format



*Figure 119: Date & time settings*

Select the suitable date and time format from the scroll down menu then validate.


### 9.1.9 Language



*Figure 120: BeanScape® language*


BeanScape® software support several languages, select your suitable one from the scroll down list.

### 9.1.10 Precision



You can change the precision based on your BeanDevice platform. The maximum number of digits is 6.

## 9.2 ALARM WINDOW



**Figure 121: Alarm Window**

All the Alarm events will be displayed on the alarm window with the corresponding date and time and on which sensor the alarm was occurred.




Figure 122: Alarm window display

## 9.3 IMPORT/EXPORT USER SETTINGS

### 9.3.1 Custom User Configuration

#### 9.3.1.1 Export Function

Click on the tab **Tools** then **“Export/Import user settings”**





Figure 123: Import/Export feature

A new window will appear, which contains the **Custom User Configuration** and the **BeanScape Configuration**,


- **Custom User Configuration** represent the settings that have relationship with the BeanGateway and the BeanDevices®.
- **BeanScape Configuration** is related to BeanScape settings.

Under Custom User Configuration click on **Export**:



*Figure 124: Custom user configuration section*

User configuration is exported in XML format:



*Figure 125: user export settings*

```


C:\Users\GraphicDesigner\Desktop\BeanUserCustomDB.xml - Sublime Text (UNREGISTERED)
File Edit Selection Find View Goto Tools Project Preferences Help
BeanUserCustomDB.xml x
1 <?xml version="1.0" standalone="yes"?>
2 <BeanScape_User_Settings xmlns="BeanUserCustomDB">
3   <Site>
4     <PAN_ID>070D</PAN_ID>
5     <MAC_ID>00158D00000E070D</MAC_ID>
6     <SITE_LBL>PAN_ID : 0 x 070D</SITE_LBL>
7     <SITE_REF>SITE_REF</SITE_REF>
8     <SITE_TYPE>SITE_TYPE</SITE_TYPE>
9     <SITE_COMMENTS />
10  </Site>
11  <Platform>
12    <PAN_ID>070D</PAN_ID>
13    <MAC_ID>00158D00000E0CE6</MAC_ID>
14    <PLATFORM_LBL>MAC_ID : 0 x 00158D00000E0CE6</PLATFORM_LBL>
15    <PLATFORM_REF>PLATFORM_REF</PLATFORM_REF>
16    <PLATFORM_TYPE>PLATFORM_TYPE</PLATFORM_TYPE>
17    <PLATFORM_FOLDER_NAME>Folder 0CE6</PLATFORM_FOLDER_NAME>
18    <FFT_REALTIME>>false</FFT_REALTIME>
19    <FFT_SHIFT>>false</FFT_SHIFT>
20    <FFT_AUTOREPORT>>false</FFT_AUTOREPORT>
21    <FFT_LOGFILE>>false</FFT_LOGFILE>
22    <FFT_VECTOR>128</FFT_VECTOR>
23    <FFT_VECTOR_MANUAL>>false</FFT_VECTOR_MANUAL>
24    <FFT_WINDOW_TYPE>0</FFT_WINDOW_TYPE>
25    <FFT_ALGORITHM>0</FFT_ALGORITHM>
26    <ZERO_PADDING>>true</ZERO_PADDING>
27    <MANUAL_FFT>>false</MANUAL_FFT>
28    <Waveform_Report>>false</Waveform_Report>
29    <Waveform_LogByEmail>>false</Waveform_LogByEmail>
30    <Set_ThresholdType>0</Set_ThresholdType>
31    <IIRFILTER>>false</IIRFILTER>
32    <VELOCITY_REALTIME>>false</VELOCITY_REALTIME>
33    <VELOCITY_DIN_REPORT>>false</VELOCITY_DIN_REPORT>
34    <VELOCITY_LOGFILE>>false</VELOCITY_LOGFILE>
35    <PPV_LOGFILE>>false</PPV_LOGFILE>

```

*Figure 126: Custom DB example*


### 9.3.1.2 Import Function

Click on **Replace** to import user configuration, by choosing replace function the old Custom\_DB will be replaced with the new one.



*Figure 127: Custom user configuration window*

By choosing **Merge** function the old Custom\_DB will be merged with the new one.



*Figure 128: Custom user configuration (merge)*

Click on **Clear** to clear the Custom\_DB.




*Don't try to change manually the XML file, there is a high risk to corrupt it.*

## 9.3.2 BeanScape® Configuration


### 9.3.2.1 Export Function

Click on **Export** to export BeanScape configuration



*Figure 129: Export window for BeanScape Config*


BeanScape configuration is exported in XML format:



*Figure 130: BeanScope Config exportation*

### 9.3.2.2 Import Function

Click on **Import** to import BeanScope configuration




*Figure 131: Import function for BeanScope Config*

Click on **Reset** to reset the BeanScope configuration.

## 9.4 NOTIFICATION MANAGEMENT

Several notification options are available, linked to the BeanDevice® status information and BeanScope® software. Click on Tools Tab and navigate to Notification Management option, new window will pop up.




**Figure 132: Notification Management Window**

By enabling the notification option, user have the possibility to choose a displayed notification message on the screen of his PC and a received Log file containing the notification details.

## 9.5 OFFLINE GRAPH


Offline Graph gives the ability to read previous measurements files, proceeding by browsing the files and then clicking on view.

Under the Tool menu on the BeanScope® software, select Offline Graph option, a new window will pop up, and will be ready to be used to display graphs from the saved measurements.




**Figure 133: Offline graph menu on BeanScope®**






**Figure 134: Offline graph window**

- Chose Grid if you want to see the graphs displayed on a grid
- Chose overlaid if you want to see the graphs displayed overlaid (pick Time for temporal x axis or frequency for frequential x axis)



**Figure 135: Grid display of graphs**



**Figure 136: Overlaid (frequency)display of FFT graphs**

## 9.6 DATE CONVERSION

Data downloaded from the data logger are organized in a system well optimized to minimize non-important data and leave maximum storage space for measurement values, hence using indexation to refer to measurement timing.

To make these files more readable we use the Data Conversion tool.

The figure shows two side-by-side screenshots of a data conversion tool. The left window, titled 'Transmit\_Streaming\_Ch\_Z\_MAC\_ID\_\_0\_x\_00158D00000CE454\_2', displays the 'Original file' content. The right window, titled 'DataConversion\_MAC\_ID\_0\_x\_00158D00000CE454\_CH\_22', displays the 'Converted file' content. Both windows show sensor metadata and a table of measurements.

**Original file (Left Window):**

```

BeanSensor AX-3D
Mac Id : 00158D00000CE454
Network Id : 0003
Pan Id : 3905
Sensor Id : 2
Sensor Label : ch_z

Ratio : 1
Offset : 0
Unit : g

Date : 10/07/2017 10:32:47

Data acquisition cycle : 10
Data acquisition duration : NA
Sampling rate : 100
Cut off frequency : 1000

-----
Measure Index; Measure value
0; -0.03017
1; -0.02981
2; -0.02855
3; -0.03047
4; -0.03084
5; -0.02892
6; -0.0301
7; -0.02936
8; -0.03003
9; -0.02944
10; -0.02892
11; -0.02885
12; -0.02892
13; -0.02944
14; -0.0301
15; -0.02907
16; -0.03032
17; -0.02981
18; -0.02988
19; -0.0304
20; -0.02973
21; -0.02855
  
```

**Converted file (Right Window):**

```

BeanSensor AX-3D
Mac Id : 00158D00000CE454
Network Id : 0003
Pan Id : 3905
Sensor Id : 2
Sensor Label : ch_z
Ratio : 1
Offset : 0
Unit : g
Date : 10/07/2017 10:32:47
Data acquisition cycle : 10
Data acquisition duration : NA
Sampling rate : 100
Cut off frequency : 1000

-----
Date; Measure
10/07/2017 10:32:47.000 ; -0.03017
10/07/2017 10:32:47.010 ; -0.02981
10/07/2017 10:32:47.020 ; -0.02855
10/07/2017 10:32:47.030 ; -0.03047
10/07/2017 10:32:47.040 ; -0.03084
10/07/2017 10:32:47.050 ; -0.02892
10/07/2017 10:32:47.060 ; -0.0301
10/07/2017 10:32:47.070 ; -0.02936
10/07/2017 10:32:47.080 ; -0.03003
10/07/2017 10:32:47.090 ; -0.02944
10/07/2017 10:32:47.100 ; -0.02892
10/07/2017 10:32:47.110 ; -0.02885
10/07/2017 10:32:47.120 ; -0.02892
10/07/2017 10:32:47.130 ; -0.02944
10/07/2017 10:32:47.140 ; -0.0301
10/07/2017 10:32:47.150 ; -0.02907
10/07/2017 10:32:47.160 ; -0.03032
10/07/2017 10:32:47.170 ; -0.02981
10/07/2017 10:32:47.180 ; -0.02988
10/07/2017 10:32:47.190 ; -0.0304
10/07/2017 10:32:47.200 ; -0.02973
10/07/2017 10:32:47.210 ; -0.02855
10/07/2017 10:32:47.220 ; -0.03054
10/07/2017 10:32:47.230 ; -0.0287
10/07/2017 10:32:47.240 ; -0.02899
10/07/2017 10:32:47.250 ; -0.02833
  
```

Figure 137: Data conversion example

Under the Tool menu on the BeanScape® software, select Data Conversion, a new window will pop up, where downloaded data can be converted.




Figure 138: Data Conversion menu on BeanScape®

A new window will open:




Figure 139: Data Conversion window






Figure 140: Data Conversion main options

- Click on browse and import streaming file containing the logged measurement.



**Figure 141: Importing files into Data Conversion tool**

- Overview of the selected files



**Figure 142: Overview of the selected files on Data Conversion window**

- Select the converted file to view or go to your log directory and you will find all the converted files in a new generated folder named **Converted File Folder**




Figure 143: Overview: Converted File Folder

### 9.7 ADVANCED SETTINGS

Navigate to **Tools** and click on Advanced settings.




Figure 144: Advanced settings


A new window will pop up in which user can find several settings



Figure 145: Advanced settings


### 9.7.1 Firewall

Click on **Add** button in order to add BeanScape on firewall, with that user will be sure that the firewall will not interrupt the connection between BeanScape software and the BeanGateway.



*Figure 146: Add BeanScape to Firewall*


Right after clicking on Add a notification message will be displayed on the screen saying that BeanScape was added to firewall successfully.



*Figure 147: Notification message*


### 9.7.2 SQL Server Report

Click on Check to check if the SQL Server was installed on your PC.




*Figure 148: SQL Server installation*

If the SQL Server is installed a pop-up notification will be displayed on the PC screen saying that the SQL Server is already installed.



*Figure 149: installation notification for SQL Server Report*


If it is not the case just click on Install button to install it.



*Figure 150: SQL Server Report Installation*


### 9.7.3 MATLAB Function

Click on Check to check if the SQL Server was installed on your PC.




*Figure 151: Check MATLAB extension*

If the MATLAB extension was already installed a pop-up notification will be displayed on the PC screen saying that is installed.



*Figure 152: Notification message*


Otherwise Click on Download button to download the extension then install it on your PC.



*Figure 153: Download MATLAB extension*


## 9.8 BEANSCAPE® CLIENT MANAGEMENT

This option is available only on BeanScape® Multiview version



*Figure 154: Client management*

Based on Client/Server paradigm, this option allows user to switch between client and server mode by entering a right serial key, and it gives the possibility also to give the client the rights to manage the system.




*Figure 155: Client/Server Management*




## 9.9 FTP CONFIGURATION

The user has the ability to send all his measurement data log files to the FTP Server through the FTP feature.



**Figure 156: FTP Configuration**

Check FTP enable check box then enter the right FTP Server setting using the following window



**Figure 157: FTP configuration window**

You should connect to your FTP server before setting up the FTP configuration on the BeanScape software.

FTP Settings

Use IP address

FTP Server\*: server

Port\*: 21

User Name\*: UserName

Password\*: ●●●●●●

Check Current config. Check New config.


State: Validate

[Show details](#)

**Figure 158: FTP Server settings**


- **FTP Server:** Enter your FTP Server DNS or IP address by checking use IP address checkbox
- **User Name:** Enter your FTP user name
- **Password:** Enter your right FTP password
- **Port:** By default, the FTP port is 21, you can change it also
- **Check New Configuration:** click on check new configuration to make sure the settings are correct.
- **Validate:** click on validate to save the setting and proceed
- **State:** display if the connection status successfully established or failed.

If the connection was failed please click the Show details link to see the cause of the issue.




**Figure 159: Failure details**

Then check the type of files which you want to send to you FTP server, and click on Validate



**Figure 160: the available type of files**

The files will be stored on your FTP server every 1 min.



***Figure 161: Files stored on the FTP server***

## 10. VIEW TAB

BeanScope® 2.4GHz software comes with two view options, a Standard view and an Expert view.




Figure 162: View tab

### 10.1 STANDARD VIEW

Once you open BeanScope® software and start the server, the standard view is selected as default view.

The standard view is just a simplified dashboard displaying the needed information that makes the system easy to use.




Figure 163: Standard View dashboard




**By connecting the BeanGateway® directly to the PC, the Expert view should be the selected view.**

## 10.1.1 Dashboard Management


### 10.1.1.1 BeanGateway® Dashboard

The BeanGateway® is identified by its PAN ID and is located on the lower left window.



**Figure 164: BeanGateway® PAN ID**

✓ You will see the following window:



**Figure 165: BeanGateway® profile**

- **Identity Frame**

The Identity configuration screen features a blue header with the word "Identity". Below it, there are two input fields: "Mac Id:" with the value "00158D00000E077D" and "Site ID:" with the value "Site : 0 x 077D".

**BeanDevice MAC Address:** is a unique identifier can be used as a network address for most network technologies including Ethernet & WIFI

**BeanDevice Site ID:** By default the MAC address is assigned as a device Label. This Label is editable by the user

- **Version Frame**

The Version configuration screen features a blue header with the word "Version". Below it, there are two input fields: "Hard. vers." with the value "V3R4" and "Soft. vers." with the value "V6R1".

**Hardware version:** BeanDevice hardware version

**Software version:** BeanDevice embedded software version

- **Labelling**

The Site Labelling configuration screen has a blue header with tabs for "Site Labelling", "Notes", "Multicasting", and "Modbus". The "Site Labelling" tab is active. It contains a "Label" field with the value "Site : 0 x 077D" and a "Validate" button below it.


- **Notes**

The Notes configuration screen has a blue header with tabs for "Site Labelling", "Notes", and "Multicasting". The "Notes" tab is active. It features a large empty text area for notes and a "Validate" button at the bottom.

- **Multicasting**


The Multicasting configuration screen has a blue header with tabs for "Site Labelling", "Notes", and "Multicasting". The "Multicasting" tab is active. It is divided into two main sections: "Multicast Group Mgmt" on the left and "Configuration manager" on the right. The "Multicast Group Mgmt" section includes a "Multicast Group view" area with a list of groups, an "Add BeanDevice" button, and a dropdown menu with "Add BeanDevice", "Add all", and "Remove" options. The "Configuration manager" section includes various settings: "Data Acq. mode" (dropdown), "Data Acq. cycle" (time input), "Sampling Rate" (input with "Hz" unit), "Data Acq. duration" (time input), "Start data acq." (time input), "Pre-Trigger duration" (time input), and "Data acquisition mode options" (radio buttons for "Tx Only", "Log Only", and "Tx & Log"). There are also "Start" and "Stop" buttons.

- **Modbus (if the BeanGateway® comes with a Modbus module)**



10.1.1.2 BeanDevice® Dashboard


- **Identity**



- **Version**




- **Network Diagnostic**





• **Power supply diagnostic**



- Latest diagnostic information date
- BeanDevice Internal temperature
- BeanDevice Internal temperature
- Color LED indicator: indicates the BeanDevice power mode status
- Battery voltage: indicates the battery voltage value
- Battery level: indicates the Battery voltage level


• **System**



- Diagnostic cycle display
- Listening ratio display for battery saver mode with network listening


• **Sensor info**

➤ For the AX3D and AX3D Xrange




- BeanDevice measurement range
- Cut-off frequency

➤ For the AX3DS



➤ For the Hi-Inc & Hi-Inc Xrange



- BeanDevice Measurement range
- BeanDevice sensitivity
- Cut-off frequency

➤ For the Hi-Inc-SR


- Custom display

- Note


### 10.1.1.3 Sensor Profile

- Custom display

- **Notes**




- **Log config**



## 10.2 EXPERT VIEW


The expert view contains more technical features for expert using.

To change the view simply go to **View** tab then **select Expert view**.



*Figure 166: Expert View*

You need to enter the right serial key in order to have access to the expert view



*Figure 167: Serial Key*

Once you choose the Expert view you notice that the dashboard display looks quite different and that there are more information and features were added to the chart.





Figure 168: Expert view dashboard


The PAN ID, Net ID, PER level, the system information and much more options are accessible from only the expert view.

### 10.2.1 BeanGateway® profile


- Identity



- Radio config



- Power supply diagnostic




Power Supply Diagnostic

Diag. Date: 7/16/2021 12:54:10 PM


Internal Temp.: 43.125 °C

Power supply: Mains

Battery Voltage: 4.196 V

Battery level: Good 

- **Auto reboot status**




Auto-Reboot Status

Disabled Reboot Cycle NA dd:hh

Auto Reboot Remaining time NA minutes

- **System**




System

Diagnostic cycle : NA d.hh:mm:ss

Beep sound funct.: Disabled

Network Status : Enabled

- **Additional module**



Additional Module

Module : Ethernet Modbus

Soft. Vers : V5R1

- **Radio Config**

Site Labelling | Notes | **Radio Config** | System Config | Multicasting | Modbus | Upload device profile

**PanId Configuration**  
 New Pan Id (Hex.):

**Radio channel configuration**  
 Channel List:

**Wireless Sensor Network diag.tool**  
 Energy Scan:

**Authorized RF Channels config.**  
 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26

**Network Configuration**  
 Max. nodes:   
 Max. routes:   
 Max. network depth:

- **System Config**

Site Labelling | Notes | Radio Config | **System Config** | Multicasting | Modbus | Upload device profile

**Diagnostic cycle configuration**  
 Enable:  Diagnostic cycle:  min

**Delete Device**  
 Device List:

**Profile Erasure/Default config.**  
 Network profile deletion:

**Auto-Reboot**  
 Enable:  Auto-Reboot:  hours

**Beep sound config.**  
 Beep sound:

- **Upload device profile**

Site Labelling | Notes | Radio Config | System Config | Multicasting | Modbus | **Upload device profile**

**BeanDevice**

Network Id:

MacId:

Invalid files

## 10.2.2 Data Acquisition configuration

- **Data Acq Config tab**

The screenshot shows the 'Data Acq. config.' tab with the following elements:

- Navigation tabs: Custum display, Notes, **Data Acq. config.**, Sensor Config
- Section: Data acquisition mode configuration
  - Data Acq. mode: LowDutyCycle (dropdown menu)
  - Data Acq. cycle: [ ] [ddd, hh:mm:ss] (input field)
  - Start (green button)
  - Stop (red button)
- Section: Data acquisition mode options
  - Tx Only
  - Log Only
  - Tx & Log

- **Sensor Config tab**

### For the AX3D & AX3D Xrange

The screenshot shows the 'Sensor Config' tab with the following elements:

- Navigation tabs: Custum display, Notes, Data Acq. config., **Sensor Config**
- Input field: AAF- Cutoff frequency(Hz) [ ]
- Validate (button)

- **Datalogger tab**

The screenshot shows the 'Datalogger' tab with the following elements:

- Navigation tabs: **Datalogger**, System config., Power mode managt, Online Data Analysis
- Section: DataLogger status
  - DataLogger status: Ready
  - Download progress: [ ] NA
  - Download status: NA
- Section: DataLogger manager
  - Stop (button)
  - Erase (button)

- **System config tab**

The screenshot shows the 'System config.' tab with the following elements:

- Navigation tabs: Datalogger, **System config.**, Power mode managt, Online Data Analysis
- Section: Diagnostic Cycle
  - Ratio: [ ] [ ] 00 h 00 mm 01 s
  - Validate (button)
- Section: Restart device
  - Restart (button)

- **Power management tab**

The screenshot shows the 'Power Mode config.' tab with the following settings:

- Battery Saver :** Enabled (dropdown menu)
- BeanDevice Listening Ratio :** 5 (spinner control)
- Listening Cycle :** 00 h 00 mm 05 s
- Buttons:** 'Validate' (under Listening Cycle), 'Delete pending OTAC frame', and 'Validate' (under Delete pending OTAC frame).

- **Online Data Analysis**

The screenshot shows the 'Online Data Analysis' tab with the following configurations:

- Online FFT Configuration:**
  - Enable Online FFT
  - Automatic FFT Report(S.E.T)
  - Enable FFT Log file
- Online Velocity configuration:**
  - Enable Online Velocity
  - Automatic DIN Report(S.E.T)
  - Enable Velocity Log file
  - Enable PPV Log file
- Number of Points (Streaming):**
  - Manual (SR/0.1)
  - Current Points Number: SR/0.1
- Online waveform configuration:**
  - Unit of acceleration: [dropdown menu]

### 10.2.3 Sensor Profile

- **Alarm levels config**

The screenshot shows the 'Alarm level Config' tab with the following settings:

- Alarm DAQ mode (g):** Alert < Action < Alarm
- Alarm:** [input field]
- Action:** [input field]
- Alert:** [input field]
- Buttons:** 'Validate' (next to Alert input)



- **Sensor calibration**

Sensor Config

Sensor labelling Notes Alarm level Config **Sensor calibration** Log config.

Current Ratio: 1

Current Offset: 0


Ratio:

Offset:

Validate


### 10.2.4 Tools tab

More options are available on the expert view




*Figure 169: Tools options list on the expert view*


- **BeanScape® configuration**




- **Import/Export user settings**




- **Alarm Management Toolbox**




- **Notification Management**




- **Offline Graph**




- **Advanced Settings**



- **BeanScape Client Management**



- OPC Management




- FTP Configuration



## 10.2.5 Advanced Functions


This option is related to the BeanDevice®



- Enable logging on PC: to generate a log file which contains all the data and will be backed up on your PC
- Disable logging on PC: there is no log file containing the data stored on your PC
- Reset measure memory cache for all sensors: to Reset the cache
- BeanDevice® health status



- Multigraph display



## 11. ONLINE AND OFFLINE DATA ANALYSIS TOOL



Online and offline analysis tool is only available on BeanDevice® AX-3D and BeanDevice® AX-3D Xrange

### 11.1 OFFLINE DATA ANALYSIS TOOL

#### 11.1.1 FFT (Fast Fourier Transform) waveform analysis module


The Fast Fourier Transform (FFT) resolves a time waveform into its sinusoidal components. The FFT takes a block of time-domain data and returns the frequency spectrum of the data. The FFT is a digital implementation of the Fourier transform. Thus, the FFT does not yield a continuous spectrum. Instead, the FFT returns a discrete spectrum, in which the frequency content of the waveform is resolved into a finite number of frequency lines, or bins.



*FFT (Fast Fourier transform) module is only compatible with “Streaming” and “S.E.T” measurement modes.*


##### 11.1.1.1 FFT generation

The BeanScope® Software includes an FFT module used for spectrum analysis. Under the menu Off.Data Analysis displayed on the BeanScope® top menu, select FFT to have access to FFT spectrum analysis module.



**Figure 170: FFT offline data analysis on BeanScope® top menu**

A new pop-up window will appear, where the user is invited to browse Tx files to be treated and graphically displayed.



**Figure 171: FFT tool window**




Figure 172: FFT tool options

To import the files containing the logged measurement, the user should click on Browse, then import the files from log\_beanscape folder, where Tx files are saved.

The FFT tool will generate as a result:

- Power spectral density and a new window displays

1: Click on Browse to choose files




Figure 173: Browsing TX files on FFT tool



2: Overview of the selected files




Figure 174: Overview: FFT window

3:Loading




Figure 175: FFT generation

4: FFT report generated with the following results:

- a. Frequency
- b. Amplitude





Figure 176: FFT generated View

**5:** FFT LOG files generated


FFT LOG files will be generated in a folder located in log\_beanscape repertory called FFT FOLDER. In this folder, BeanScope® will create separate folders for each BeanDevice®.



**Figure 177: Generated FFT Log files**

**6:** The graphs will be displayed automatically when VPPV Report is generated via a pop-up window, that can be formatted to select the number of graphs to display simultaneously in this window.

An easy navigation bar on the top of the window, allow to the user to navigate between the graphs and select the page size.



**Figure 178: Graph display (Offline Data Analysis)**

**7:** Users can manually select and launch graph by double click or selecting file and click on “Show selected graph” button.




Figure 179: Selecting a graph to display

8: The selected graph is displayed





Figure 180: Selected graph display

**10:** Make sure that the time range is within your measurements, otherwise the files will be considered as invalid.



**Figure 181: FFT invalid files**

#### 11.1.1.2 FFT shift


FFT shift allows sorting the FFT output by moving the zero-frequency component to the center of the array. It is useful for visualizing a Fourier transform with the zero-frequency component in the middle of the spectrum.

FFT shift option is activated when the checkbox “FFT shift” is checked.

Click on browse and import file containing the logged measurement, the result will be:


- Power spectral density and a new window displays (with zero-frequency at the center)

**1:** To use FFT Shift: check FFT Shift, select files and click the “View” button:



**Figure 182: FFT Shift activation**

## 2: FFT Spectrum with FFT Shift option enabled



*Figure 183: Gird of FFT Shift spectra*




[FFT and FFT shift video](#)

### 11.1.2 Particle Velocity


According to the DIN4150-3, the BeanScope® software Particle Velocity option acts as follow:

- 1-Display Particle velocity which is calculated from the acceleration.
- 2-Implement an analysis report.

**The first step:** Under Off.Data Analysis menu on the Beanscape® top menu, select Particle Velocity



**Figure 184: DIN on BeanScope® top menu**



**Figure 185: Particle Velocity window**

**The second step** is to browse and import the file containing the logged measurement. The result will be:

- Velocity display window
- DIN report generated
- Velocity files created


### 3: Velocity Advanced Configuration.

The screenshot shows the Velocity Advanced Configuration interface. At the top, three radio buttons are visible: "By FFT", "By Filter", and "By Zero Crossing". The "By Zero Crossing" option is selected and highlighted with a yellow box. Below these are three main configuration panels:


- FFT Configuration:** Includes an "Auto" toggle, "Window Type" (Rectangular), "Algorithm" (Estimate), and "Zero Padding" (checked). A "Current FFT Configuration" section offers "Use All Measurement data" (selected) and "Adjust number of FFT points" (Streaming mode).
- Filter Configuration:** Includes an "Auto" toggle, "Filters Profile" dropdown, and icons for validation, deletion, and refresh. It is divided into:
  - Response Type:** Highpass (selected) and Bandpass.
  - Design Method:** IIR Chebyshev\_type\_1 (selected) and FIR Equiripple.
  - Filter Order:** Minimum Order (selected) and Specify Order.
  - Frequency Specification:** Units (Hz), Fs, Fstop, and Fpass.
  - Magnitude Specification:** Units (dB), Astop, and Apass.
  - Filter Name:** A text input field with a save icon.
- Filter Specification:** A graph showing Magnitude (dB) vs. frequency f (Hz). It indicates passband edges (F<sub>stop</sub>, F<sub>pass</sub>) and stopband attenuation (A<sub>stop</sub>, A<sub>pass</sub>).

On the right side, the "Current Velocity Configuration" section shows the "Mode" set to "Zero Crossing". A "Validate" button is located at the bottom right of the interface.


By default, the Velocity is configured “By Zero Crossing”, to edit the Velocity settings user must select “By FFT” or “By Filter”.




- **By FFT:** By selecting this option, the user will setup the Velocity basing on customized FFT settings.
  - o Auto: If Auto is selected, The Velocity calculation will activate FFT Auto mode Settings




- Manual: Once switched to Manual, the user must configure the FFT settings manually (Window Type, Algorithm & Zero Padding).



- FFT Points:



By default, the Number of Points is configured to be set automatically as Sampling Rate / 0.1 (SR/0.1). By moving to the Manual settings, user must choose a value between 128 and 32768.







***It is important to notice that larger Number of Points provide higher spectral resolution but take longer to compute.***

The frequency resolution of each spectral line is equal to the Sampling Rate divided by the Number of Points. For instance, for example, if the Number of Points is 4096 and the Sampling Rate is 2000, the resolution of each spectral line will be:

$$2000/4096 = 0.48828125$$



***The Number of Points should be equal or higher than the Sampling Rate (Acquisition time at least = 1 second)***




***It is important to notice that larger Number of Points provide higher spectral resolution but take longer to compute.***

- **By Filter:** By selecting this option, the user will setup the Velocity basing on the Software Filter.
  - o Auto: If Auto is selected, Velocity Automatic filter will be configured

- Manual: Once switched to Manual, the user must configure manually the Filter settings.

- ❖ Response Type: User should specify if the Response is **Highpass** or **Bandpass**





- ❖ Design Method: User should Select the nature of the Filter between **IIR** or **FIR**  
From the List of every filter, user have to specify the method of the Filter:  
IIR: Chebyshev\_type\_I, Chebyshev\_type\_II or Butterworth  
FIR: Equiripple, Generalized\_Equiripple or Kaiser\_Window




**The Frequency Specification and The Magnitude Specification will be modified according the selected Design Method**

- ❖ Filter Order: If the user is using IIR Design Method, Minimum Order will be selected automatically.  
If the FIR Design Method is selected, user must Specify Order.
- ❖ Frequency Specification: Is a customizable frame according to the Design Method.
- ❖ Magnitude Specification: Is a customizable frame according to the Design Method.
- ❖ Filter Profile: User can save a specific Configuration and re-use it later.



- ❖ Filter Specification: Is a Graphical Display of the Filter Specification depends on the user settings.



4: Click on browse button to choose TX Files.

The screenshot shows the 'Particle Velocity' software interface. In the 'Select Log Files' section, the 'Browse' button is highlighted with an orange callout box containing the text 'Click on Browse to select Tx Files'. An orange arrow points from this callout to the 'Browse' button. Below this, a file explorer window is open, showing a list of files. Another orange callout box contains the text 'Select files then click on open', with an orange arrow pointing to the 'Open' button in the file explorer window.

Figure 186: Browsing TX files into Particle Velocity tool

5: Loading.




Figure 187: Particle Velocity result generation

6: The Particle Velocity Window will be displayed and will display:


- Velocity Graph
- Particle Velocity Graph
- PPV Values
- Zero Crossing frequency values
- Peak Acceleration and Displacement values



Figure 188: Particle Velocity Display Window

**6: The VPPV and DIN Report:**

VPPV & DIN Report will be generated by clicking on the VPPV View and DIN-4150-3 Report buttons



*Figure 189: VPPV & DIN buttons*

PPV

1 of 1

100%

Find | Next

**BeanAir** **VPPV REPORT** 6/27/2019 11:11:15

File Name	VPPV (mm/s)	Time PPV	ZC Freq(hz)	Peak Acc	Peak Disp(mm)
Transmit_S.E.T_Ch_X_MAC_ID___0_x_F4B85E00A14B0000_6_26_2019_3_00_48_PM	0.5144	6/26/2019 3:00:51 PM	7.52	0.3531	2.0762
Transmit_S.E.T_Ch_X_MAC_ID___0_x_F4B85E00A14B0000_6_26_2019_3_00_53_PM	0.0041	6/26/2019 3:00:53 PM	5.01	0.0024	0.0227

*Figure 190: VPPV Report*

DIN Report

1 of 1

100%

Find | Next

**DIN 4150-3 REPORT** 6/27/2019 11:11:56 AM

File Name	Building type	Pipe Material	Velocity Average(mm/s)	Sampling Rate(hz)	Analyze duration	LTVEE	LTEBP	Real Frequency(hz)	PCPV(mm/s)	STEBP	STVEE
Transmit_S.E.T_Ch_X_MAC_ID___0_x_F4B85E00A14B0000_6_26_2019_3_00_48_PM	Commercial	Steel	0.00270607272727273	200	00:00:05.5000000	OK	OK	7.52	0.51444	OK	OK
Transmit_S.E.T_Ch_X_MAC_ID___0_x_F4B85E00A14B0000_6_26_2019_3_00_53_PM	Commercial	Steel	-6.64363636363636E-05	200	00:00:05.5000000	OK	OK	5.01	0.0027	OK	OK

Keyword	Meaning
LTVEE	Long Term Vibration Evaluation Effect
LTEBP	Long Term Effect on Buried Pipe work
STEBP	Short Term Effect on Buried Pipe work
STVEE	Short Term Effect Evaluation
PCPV	Peak Component Particle Velocity

DIN 4150-3 REPORT

1

*Figure 191: DIN Report*

INFORMATION	DETAILS
Building type	User configurable
Pipeline Material	User Configurable
Velocity Average	Get the average of the signal after transforming the acceleration signal into velocity signal
Sampling Rate	In Hz
Analyse duration	BeanScape property
Long term vibration evaluation effect	1-Find the maximum velocity values over the Time 2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150. 3-Display if the result is OK or not (guideline respected or not)
Long term Effect on buried pipework	1-Find the maximum velocity values over the Time 2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150. 3-Display if the result is OK or not (guideline respected or not)
Real Frequency	Get the signal frequency (FFT + windowing)
Maximum velocity (mm/s)	BeanScape Property
Short term Effect on buried pipework	1-Find the maximum velocity values over the Time 2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150. 3-Display if the result is OK or not (guideline respected or not)
Short term vibration effect evaluation	1-find the maximum velocity value over the time. 2-Determine the significant frequency (use the FFT + windowing). 3-compare the maximum velocity to the guideline value described on the Norm DIN 4150 5-Display if the result is OK or not (guideline respected or not)



*Signal windowing is used in this analysis. Windowing is a technique used to cut out a section of your data to measure, in order to minimize distortions that cause spectral leakage of the FFT.*



[DIN 4150-3 Interpretation video](#)

## 11.2 ONLINE DATA ANALYSIS TOOL

### 11.2.1 Online FFT

The FFT (Fast Fourier transform) operates by decomposing an N point time domain signal into N time domain signals each composed of a single point.


The second step is to calculate the N frequency spectra corresponding to these N time domain signals.

Lastly, the N spectra are synthesized into a single frequency spectrum.

When using FFT in SET mode, for best performance FFT points are automatically calculated on the number of data acquisition (sampling rate x data acquisition duration).



Real time observation of FFT available for BeanDevice AX-3D only with Streaming and S.E.T acquisition modes and is enabled from the Online Data Analysis tab in the Configuration panel.



*Figure 192: Online FFT Configuration frame*




1: Check **Enable Online FFT** to view the display of FFT graph in the sensor profile




**Figure 193: FFT Spectrum**

2: Check **Enable FFT Log file** to generate log files in the log\_beanscape directory.



**Figure 194: Online FFT Configuration frame**


The log files will be generated in a folder called “FFT” under the BeanDevice® repertory.



**Figure 195: FFT log files folder**




**3: Enabling Automatic Report:** This functionality is available only in S.E.T mode. To activate automatic reports generation, check the option on Online FFT configuration frame



**Figure 196:Enabling Automatic FFT Report**

The Reports will be generated in your log\_beanscape directory, under “Report Folder” repertory.



**Figure 197: Report Folder**



*For further information about the configuration of Online FFT please refer to section [7.3.4](#) of this user manual*

After enabling Real time FFT and setting SMTP configuration ([more information on section 8](#)), this is an example of an FFT report emailed to concerned recipients.



FFT Report

[Logo] 1

This email is sent by the BeanScope® software – Acceleration event occurred on “Ch\_Z Axis” at Time : 11:04:59.150 , Level : Action

Date : 2020-12-11 11:04:59.150  
 Measure Duration : 15 sec  
 Sampling Rate : 100 (hz)  
 Pre-Trigger Duration : 100 (ms)  
 IIRFilter : Disabled  
 Axis where trigger occurred : Ch\_Z

2

Beandevic® Type : AX 3D  
 MAC ID : 00158D00000E1049  
 Label : MAC\_ID : 0 x 00158D00000E1049  
 Range(g) : -2 / +2  
 Thresholds type for SET mode : Acceleration

4

Related notes to monitoring site

User Name :  
 Location :  
 Monitoring sites :

3

Sensor Information

	Ch X	Ch Y	Ch Z
Offset Zeroing value	NA	NA	NA
Threshold Alarm	1.052 g	1.052 g	1.052 g
Threshold Action	0.747 g	0.747 g	0.747 g
Threshold-Alert	0.441 g	0.441 g	0.441 g


5

FFT Configuration

Mode : AUTO  
 Zero Padding : Enabled

Window Type : Rectangular  
 Algorithm : Estimate

6



7

Figure 198: FFT Report (S.E.T mode)

1	Logo of your company, you can upload it from the alarm management configuration window. Tools→Alarm management
2	General information about the Measurement, Date, duration sampling rate ,pre-trigger duration, IIR filter status and triggered axis
3	Information related to monitoring site: user, location and monitoring sites (can be configured from the Alarm tool window). This field can be configured be from the alarm management configuration window Tools→Alarm management
4	BeanDevice® Information: Type, MAC ID and label, measurement range, and Alarm Type : Acceleration or Velocity
5	Alarm thresholds value on each Axis, the three levels of alarms are displayed Action-Alert-Alarm
6	FFT Report with Max Frequency for each Axis, VPPV (Vector Peak Particle Velocity) value and Max amplitude
7	Graph Area – 3 Axis are displayed on the same graph




*For further information about managing your notification and reports email please refer to section [8: Alarm management.](#)*




- **FFT Advanced Configuration**

The FFT configuration allows the user to activate the FFT Shift and to go for manual settings related to FFT.



- Auto/Manual



- Window type:

Rectangular
Hamming
Hann
Blackman
Blackman Harris
Gaussian
Kaiser
Taylor
Triangular
Flattop
Bartlett
Bartlett-Hann

When the number of periods in the acquisition is not an integer, the endpoints are discontinuous. These artificial discontinuities show up in the FFT as high-frequency components as not present in the original signal. These frequencies can be much higher than the Nyquist frequency and are aliased between 0 and half of your sampling rate. This phenomenon is known as spectral leakage.

You can minimize these effects by using a technique called windowing.

Windowing reduces the amplitude of the discontinuities at the boundaries of each finite sequence acquired by the digitizer. Windowing consists of multiplying the time record by a finite-length window with an amplitude that varies smoothly and gradually toward zero at the edges. This makes the endpoints of the waveform meet and, therefore, results in a continuous waveform without sharp transitions. This technique is also referred to as applying a window.

There are several different types of window functions that you can apply depending on the signal. To understand how a given window affects the frequency spectrum, you need to understand more about the frequency characteristics of windows.

Selecting a window function is not a simple task. Each window function has its own characteristics and suitability for different applications. To choose a window function, you must estimate the frequency content of the signal.

- If the signal contains strong interfering frequency components distant from the frequency of interest, choose a smoothing window with a high side lobe roll-off rate.
- If the signal contains strong interfering signals near the frequency of interest, choose a window function with a low maximum side lobe level.
- If the frequency of interest contains two or more signals very near to each other, spectral resolution is important. In this case, it is best to choose a smoothing window with a very narrow main lobe.
- If the amplitude accuracy of a single frequency component is more important than the exact location of the component in a given frequency bin, choose a window with a wide main lobe.
- If the signal spectrum is rather flat or broadband in frequency content, use the uniform window, or no window.


In general, the Hanning (Hann) window is satisfactory in 95 percent of cases. It has good frequency resolution and reduced spectral leakage. If you do not know the nature of the signal but you want to apply a smoothing window, start with the Hann window.

- Algorithm

<b>Estimate</b>	Determine a best-guess transform algorithm based on the size of problem.
<b>Measure</b>	Find a better algorithm by computing multiple transforms and measuring the run times.
<b>Patient</b>	Run a wider range of testing compared to 'measure', resulting in a better transform algorithm, but at the expense of higher computational cost to determine the parameters.
<b>Hybrid</b>	Use a combination of 'measure' for transforms with dimension length (number of points) 8192 or smaller and 'estimate' for transforms with dimension length (number of points) larger than 8192.

- Zero Padding: The use of zero padding enables you to estimate the amplitudes of frequencies correctly.
- FFT Shift: Check to enable real time FFT Shift processing for BeanDevice AX-3D on streaming mode and the FFT spectrum will appear shifted below the Streaming graph in the sensor profile.

#### FFT Configuration



**Figure 199: FFT Shift Spectrum**

### 11.2.2 Online Velocity



In order to use Real time PPV, you should use high sampling rate to provide good PPV values.



You need to sample at 200Hz at least to provide good PPV values.




By using SET mode, you need to choose the highest sampling rate which is 200Hz and don't forget to enter a DAQ duration higher than 10s.



For Streaming mode, choose at least 500Hz and above with a minimum DAQ duration of 10s, to provide good PPV measurement.



Real time observation of velocity available for BeanDevice AX-3D only with Streaming and S.E.T acquisition modes and is enabled from the signal processing tab in the Configuration panel.



**Figure 200: Online Velocity configuration tab**



- **Enable online Velocity:** check to enable real time Velocity processing, PPV and PVS, the velocity graph will be displayed.

On the Graph side a real time DIN 4150 graph will be displayed on the right side of the screen.

Under the DIN 4150 Graph, the PPV and the PVS values will be displayed in real time.

On the PPV frame, BeanScape will display PPV in mm/s, ZC Frequency in Hz, Peak Acceleration in g and Peak Displacement in mm.



**It is important to notice that the PVS calculation required 3 active channels to be generated.**

**PPV:** is a measurement of maximum ground particle movement speed, it is in millimeters per second (mm/sec), PPV is a "vector" quantity (i.e. it has both a value and an associated direction).

**Peak Vector Sum (PVS):** is simply the square root of the sum of the squares of the individual PPV values. PVS is a "scalar" quantity, i.e. one with only a value, which is always larger than the individual PPV vector values.

Scientific studies have shown that the PPV correlates best with damage potential of all the tested characterizations of ground movement (e.g. acceleration, displacement, or strain). Most, though not all, ground vibration standards are quoted in PPV values, although the "acceptable" values of PPV differ with the standard applied and with the frequency of the vibration components.



**Figure 201: Velocity Graph**





Figure 202: Velocity and FFT Graph, PPV and PVS




Figure 203: DIN 4150 Real Time Graph, PPV & PVS

- **Automatic DIN Report (S.E.T):** check to enable DIN4150-3 report automatic generation when threshold is reached, or an acquisition cycle is reached on the S.E.T acquisition mode.

An automatic Report will be sent to the email addresses configured on Alarm Management Option.

<b>BeanAir</b>		06-Feb-19 12:07:37
BeanDevice MAC_ID : F4B85E00A14B0000		Sensor Label : Ch_Z

### DIN 4150-3 REPORT


Building Type	Commercial
Pipeline Material	Steel
Velocity Average(mm/s)	0.0177327272727272
Sampling Rate(hz)	100
Analyze Duration(hh:mm:ss)	00:00:01.1000000
LTVEE	OK
LTEBP	OK
Velocity Frequency(hz)	0
PCPV(mm/s)	2.4892
STEBP	OK
STVEE	NOK

KeyWord	Meaning
LTVEE	Long Term Vibration Evaluation Effect
LTEBP	Long Term Effect on Buired Pipework
STEBP	Short Term Effect on Buired Pipework
STVEE	Short Term Effect Evaluation
PCPV	Peak Component Particle Velocity

*Figure 204: DIN 4150-3 Report email*


INFORMATION	DETAILS
Building type	User configurable
Pipeline Material	User Configurable
Velocity Average	Get the average of the signal after transforming the acceleration signal into velocity signal
Sampling Rate	In Hz
Analyse duration	BeanScape property
Long term vibration evaluation effect	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Long term Effect on buried pipework	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Velocity Frequency	Get the signal frequency (FFT + windowing)
Maximum velocity (mm/s)	BeanScape Property
Short term Effect on buried pipework	<ol style="list-style-type: none"> <li>1-Find the maximum velocity values over the Time</li> <li>2- Compare the maximum velocity to the guideline value described on the Norm DIN 4150.</li> <li>3-Display if the result is OK or not (guideline respected or not)</li> </ol>
Short term vibration effect evaluation	<ol style="list-style-type: none"> <li>1-find the maximum velocity value over the time.</li> <li>2-Determine the significant frequency (use the FFT + windowing).</li> <li>3-compare the maximum velocity to the guideline value described on the Norm DIN 4150</li> <li>5-Display if the result is OK or not (guideline respected or not)</li> </ol>

- **Enable Velocity Log file:** check to enable Velocity data to be stored in the log folder.




**Figure 205: Velocity Log Folder/Files**

- **Enable PPV Log file**



**Figure 206: PPV Log Folder/Files**

## Velocity Advanced Configuration




**Figure 207: Velocity Advanced Configuration**

By default, the Velocity is configured “By Zero Crossing”, to edit the Velocity settings user must select “By FFT” or “By Filter”.




- **By FFT:** By selecting this option, the user will setup the Velocity basing on customized FFT settings.
  - Auto: If Auto is selected, The Velocity calculation will activate FFT Auto mode Settings




- Manual: Once switched to Manual, the user must configure the FFT settings manually (Window Type, Algorithm & Zero Padding).

By clicking on Import the Configuration will import the FFT current settings, already configured on the FFT frame.




**To save all settings Press Validate. The new settings should be displayed on the Left side of the Window.**




- **By Filter:** By selecting this option, the user will setup the Velocity basing on the Software Filter.



**The Software filter is available for Streaming and S.E.T Mode.**



- Auto: If Auto is selected, Velocity Automatic filter will be configured




- Manual: Once switched to Manual, the user must configure manually the Filter settings.
  - ❖ **Response Type:** User should specify if the Response is **Highpass** or **Bandpass**
  - ❖ **Design Method:** User should Select the nature of the Filter between **IIR** or **FIR**  
 From the List of every filter, user have to specify the method of the Filter:  
 IIR: Chebyshev\_type\_I, Chebyshev\_type\_II or Butterworth  
 FIR: Equiripple, Generalized\_Equiripple or Kaiser\_Window




**The Frequency Specification and The Magnitude Specification will be modified according the selected Design Method**




- ❖ **Filter Order:** If the user is using IIR Design Method, Minimum Order will be selected automatically. If the FIR Design Method is selected, user must Specify Order.
- ❖ **Frequency Specification:** Is a customizable frame according to the Design Method.
- ❖ **Magnitude Specification:** Is a customizable frame according to the Design Method.
- ❖ **Filter Profile:** User can save a specific Configuration and re-use it later.

Filter name :  




The screenshot shows the 'By Filter' control panel. At the top, there are 'Import Filter' and 'Export Filter' buttons. Below them is a 'Streaming Mode' selector with 'SET Mode' selected. A 'Manual' toggle is on the left. The 'Filters Profile' dropdown is highlighted with a callout 'Saved filters list'. To its right is a checkmark icon labeled 'Validate the chosen filter', a trash can icon labeled 'Delete the selected filter', and a circular arrow icon labeled 'Delete all saved filters'.

- ❖ **Filter Specification:** Is a Graphical Display of the Filter Specification depends on the user settings.




**To save all settings Press Validate. The new settings should be displayed on the Left side of the Window.**




### 11.2.3 IIR Software Filter


**Enable IIR Filter:** Check to enable IIR filter



### 11.2.4 Number of Points (Streaming)




By default, the Number of Points is configured to be set automatically as Sampling Rate / 0.1 (SR/0.1). By moving to the Manual settings, user must choose a value between 128 and 32768.



***It is important to notice that larger Number of Points provide higher spectral resolution but take longer to compute.***



FFT Spectral Resolution Converter is simulation tool which will estimate the FFT Spectral Resolution regarding the Sampling Rate and the Number of Points.



The frequency resolution of each spectral line is equal to the Sampling Rate divided by the Number of Points. For instance, for example, if the Number of Points is 4096 and the Sampling Rate is 2000, the resolution of each spectral line will be:

$$2000/4096 = 0.48828125$$




***The Number of Points should be equal or higher than the Sampling Rate (Acquisition time at least = 1 second)***



***It is important to notice that larger Number of Points provide higher spectral resolution but take longer to compute.***

### 11.2.5 Online Waveform Configuration

---




- **Automatic Wave Report (S.E.T):** Check to enable waveform reports, this is only available for S.E.T mode
- **Enable Wave Log file:** check to enable logging wave form for real-time data (only S.E.T mode)

### 11.2.6 Unit of acceleration

---

Select which unit to be used for acceleration measurement.


- G
- mm/s<sup>2</sup>



### 11.2.7 S.E.T threshold

---

In many cases the threshold is needed to be set in mm/s and not in g or mm/s<sup>2</sup>, you need to configure your S.E.T threshold parameters before starting. To configure the threshold to be set in mm/s, you need to go to Online Data Analysis and change S.E.T threshold from acceleration to Velocity.



## 12. APPENDICES

---

### 12.1 APPENDICE 1: INSTALLATION PROCEDURES

---

#### 12.1.1 Sealing

---

The product BeanDevice® comes with an *IP67* rating. So, do not install the BeanDevice® in a marine environment with high turbulence.

Do not install the BeanDevice® up front to prevent the accumulation and infiltration of water from the front of the case.

If the BeanDevice® is used in a cold environment, it will be better to integrate it inside a plastic casing.

#### 12.1.2 Coexistence With other Frequencies at 2.4 GHz

---

The BeanDevice® is sensitive to noise 2.4GHz (Wi-Fi as a source for example), but many protections are already in place, particularly in the IEEE 802.15.4®.

It should however be careful when installing the product, check all the possibilities of radio channels on the frequency range 2.4-2.5GHz. The operation of the product will be improved.



*For further information, read the application note: [AN RF 004 – “Coexistence of Beanair WSN at 2.4GHz”](#)*

#### 12.1.3 Temperature & Humidity

---

The BeanDevice® SmartSensor series comes with an operating temperature of -20°C to +65°C.

BeanDevice® products can operate in an area with 90% humidity.

However, the wireless range can be reduced in the presence of water. Avoid mounting the BeanDevice® in an enclosure surrounded by water, or near bushy plants (plants are composed of 90% water), ...

#### 12.1.4 Reflections, Obstructions and Multipath

---



*For further information, read the application note: [AN RF 007 :“ Beanair WSN Deployment”](#)*

#### 12.1.5 shock & Vibration resistance

---

Shock resistance on BeanDevice® products are:

<i>Shock resistance</i>
50g during 50 ms

*Do not force connections.*

#### 12.1.6 Antenna

---

Check the LQI (Link Quality Indicator) of your BeanDevice® for being sure that your antenna is right oriented.




*For further information, read the application note: [AN RF 007 :“ Beanair WSN Deployment”](#)*

## 12.2 APPENDICE 2: SENSOR CHARACTERISTICS

### 12.2.1 BeanDevice® AX-3D & AX-3D Xrange

#### 12.2.1.1 Sensor architecture

## BEANDEVICE® AX-3D



*Figure 208: Sensor design*

#### 12.2.1.2 MEMS Accelerometer

The BeanDevice® AX-3D integrates a tri-axis, silicon micromachined accelerometer with a full-scale output range of  $\pm 2g$ ,  $\pm 10g$ .


Acceleration sensing is based on the principle of a differential capacitance arising from acceleration-induced motion of the sense element, which further utilizes common mode cancellation to decrease errors from process variation, temperature, and environmental stress. The sense element is hermetically sealed at the wafer level by bonding a second silicon lid wafer to the device using a glass frit.

### 12.2.1.3 5<sup>th</sup> order Anti-aliasing filter


BeanDevice® AX-3D & HI-INC products integrates a high-performance 5th order Butterworth filter.

### 12.2.1.4 Why using an anti-aliasing filter?

When selecting an analog filter, the goal is to provide a cutoff frequency that removes unwanted signals from the ADC input or at least attenuates them to the point that they will not adversely affect the circuit. An anti-aliasing filter is a low-pass filter that accomplishes this. How does one select the right filter? The key parameters that need observation are the amount of attenuation (or ripple) in the passband, the desired filter rolloff in the stopband, the steepness in the transition region and the phase relationship of the different frequencies as they pass through the filter.



Once the signal frequencies of interest are known, use a simple filter program to determine the filter topology needed to meet the passband, stopband, and transition region requirements. Of the four basic filter types, each has its own advantages







The Butterworth filter used on the BeanDevice® SmartSensor product lines, has the flattest passband region, meaning it has the least attenuation over the desired frequency range. The Bessel filter has a more gradual roll-off but its key advantage is that it has a linear phase response, meaning each frequency component is delayed by an equal amount of time as it passes through the filter. A linear phase response is often specified as a constant group delay, since group delay is defined as the derivative of the phase response with respect to frequency. The Chebyshev filter has a steeper rolloff but more ripple in the passband. The Elliptic filter has the steepest rolloff. For a simple anti-aliasing filter, often times a simple single-pole passive RC filter is acceptable. In other cases an active filter works well. One advantage of an active filter is that for multi-order filters, the operation of the filter is less sensitive to the values of the external components, in particular, the 'Q' value of the filter.



#### 12.2.1.5 Anti-aliasing filter features

<i>specifications</i>	<i>Typical</i>
<i>Type of Lowpass filter</i>	<i>5-th Butterworth response</i>
<i>Total harmonic distortion plus Noise (THD + N)</i>	<i>-81 dB</i>
<i>Typical Harmonic Distortion</i>	<i>-86,4 dB</i>
<i>Cutoff frequency (or corner frequency)</i>	<i>Configurable from the BeanScope® :</i> <i>AX-3D : 0 à 2 KHz</i> <i>AX-HD : 0 à 2 KHz</i> <i>HI-INC : 0 à 60 Hz</i>

**[Table 4: Frequency & Phase response curve cutoff frequency 1 KHz](#)**



**Total Harmonic Distortion plus Noise vs Input signal amplitude**



**5th-order Ladder Filter network**

#### 12.2.1.6 Analog Digital Converter


The Analog-to-Digital (16-bits) converter is based on a true SAR (Successive Approximation Register) architecture with no missing codes.

The ADC integrates an internal temperature sensor, which is useful for performing a system calibration.

The internal reference is temperature-compensated to within 10 mV. The reference is trimmed to provide a typical drift of  $\pm 10$  ppm/ $^{\circ}\text{C}$ .


## 12.2.2 BeanDevice® HI-INC & HI-INC Xrange

### 12.2.2.1 Sensor architecture



*Figure 209: Inclinometer Block Diagram (BeanDevice® HI-INC  $\pm 30^\circ$  and  $\pm 15^\circ$  versions)*

### 12.2.3 Inclinometer Block Diagram (BeanDevice® version)



*Figure 210: Inclinometer Block Diagram (BeanDevice® version)*

### 12.2.4 MEMS Inclinometer & differential output

The BeanDevice® HI-INC integrates a 3D-MEMS-based single axis inclinometer that uses the differential measurement principle. The high calibration accuracy combines extremely low temperature dependency, high resolution and low noise together with a robust sensing element design, to make the BeanDevice® HI-INC an ideal choice for high accuracy leveling instruments.

The inclinometer used on the BeanDevice® HI-INC  $\pm 15^\circ$  and  $\pm 30^\circ$  provides a differential output: the measuring axes of the sensing elements are mutually opposite in direction, thus providing two inclination signals which can be differentiated externally by our wireless processor.

The differential measurement principle removes all common mode measurement errors. Most of the error sources have similar effects on both sensing elements. These errors are removed from measurement result during signal differentiation. The differential measurement principle gives very efficient noise reduction, improved long term stability and extremely low temperature dependency.

### 12.2.5 5<sup>th</sup> order Anti-aliasing filter

---

Same specifications as BeanDevice® AX-3D

### 12.2.6 Analog to digital converter

---

Same specifications as BeanDevice® AX-3D

### 12.2.7 Accuracy considerations

---

**Main error components are:**

#### ■ Zero Point Error

In most cases the most significant error component is the zero point error. In the range -25 ... +85°C it is  $\pm 0.057^\circ$  (6 $\sigma$  limit) and the temperature dependence is typically  $\pm 0.002^\circ/\text{C}$ . The room temperature variation can be reduced by calibration at the instrument level and the effects of the temperature dependence dealt with by using temperature compensation.

#### ■ Error Caused by the SIN Function:

When used as an inclinometer, the output of the accelerometer is proportional to  $1g \cdot \sin(\text{Phi} + \text{Phi}0)$ , where Phi is the inclination angle and Phi0 the internal mounting error. The internal mounting error is a maximum of  $\pm 2.9^\circ$ , corresponding to  $\pm 50\text{mg}$ . This error is of importance when using large inclination angle amplitudes and is seen as an addendum to the non-linearity (Typically  $\pm 5\text{mg}$  in  $\pm 0.5g$  and  $\pm 10\text{mg}$  in  $\pm 1g$ ).

#### ■ Cross-axis Sensitivity

The cross-axis sensitivity (4%) shows how much perpendicular acceleration or inclination is coupled to the signal.

#### ■ Rectification of Vibration

The effect of high frequency vibration is strongly suppressed by the over-damped sensing element (upper cut-off freq.  $f_{-3\text{dB}} = 0 \dots 10\text{Hz}$ ). In an extreme case, high amplitude vibrations ( $>5g$ ) may cause a measurable zero point shift.

### 12.2.8 Offset & temperature dependencies

---


To achieve the best possible accuracy, an internal temperature sensor is used for sensitivity temperature dependency compensation. By using an additional 3rd order polynome compensation curve based on average sensitivity temperature dependency curve and temperature measurement information, it is possible to reduce sensitivity temperature dependency from:

- ✓ 0.013%/°C down to 0.005%/°C for the BeanDevice® HI-INC  $\pm 15^\circ$  and  $\pm 30^\circ$  versions
- ✓ 0.014%/°C down to 0.008%/°C for the BeanDevice® HI-INC  $\pm 90^\circ$


Typical offset and sensitivity temperature dependencies of the inclinometer sensor are presented in following diagrams. These results represent the typical performance of inclinometer sensor components. The mean value

and 3 sigma limit (mean  $\pm 3 \times$  standard deviation) and specification limits are presented in following diagrams. The 3 sigma limits represents 99.73% of the inclinometer sensor population.

### *Temperature dependency of the inclinometer sensor offset (differential output)*




### *Temperature dependency of the sensor sensitivity [%] (differential output)*



## 12.2.9 BeanDevice® AX-3DS

### 12.2.9.1 Mems Sensor architecture

## BEANDEVICE® AX-3DS



**Figure 211: BeanDevice® AX-3DS mems Sensor architecture**

### 12.2.9.2 Shock detection trigger

The shock detection trigger allows the BeanDevice® AX-3DS to wake up when a threshold is reached. The threshold value can be modified from the BeanScape®.

This feature is used for “*Smart shock detection*” data acquisition mode.

### 12.2.9.3 BeanDevice® current consumption in sleeping mode with SSD activated (Smart shock detection)

When SSD is activated, the BeanDevice will wake up if a shock is detected. During the sleeping mode of the BeanDevice®, the sensor will continue to track a shock event.

Depending on the sampling rate of the accelerometer during sleeping, the BeanDevice® current consumption can change:

<i>Accelerometer sampling rate during sleeping</i>	<i>BeanDevice® AX3DS Current consumption</i>
0,5 Hz	21 $\mu$ A
1 Hz	31 $\mu$ A
2 Hz	50 $\mu$ A



5 Hz	78 $\mu$ A
10 Hz	130 $\mu$ A
50 Hz	302 $\mu$ A
100 Hz	308 $\mu$ A
400 Hz	343 $\mu$ A
1000 Hz	413 $\mu$ A


***Table 5 : BeanDevice® AX-3DS power consumption for a given sampling rate***




For further information about the SSD (Smart Shock Detection) measurement mode, read the technical note [TN RF 008 – “Data acquisition modes available on the BeanDevice®”](#)

## 12.2.10 Sensor position inside the casing

### 12.2.10.1 BeanDevice® AX-3D



**Position of the  
MEMS  
Accelerometer**



***Figure 212: Overview: MEMS Accelerometer in BeanDevice® AX-3D***

## **12.3 APPENDICE 3: MAINTENANCE & SUPERVISION (FOR EXPERIENCED USER)**

This section allows to an experienced user to configure correctly the Wireless Sensor Networks.

### **12.3.1 Extending battery life**

The battery autonomy depends on several parameters:

- ✓ The environment where the BeanDevice® is deployed
- ✓ Data acquisition mode which is configured

The table below presents the BeanDevice® current consumption during radio TX or during sleep phase:

<b><i>BeanDevice® version</i></b>	<b><i>Current consumption during radio TX at 25°C, powered by a battery of 3.6V</i></b>	<b><i>Current consumption in sleep phase at 25°C, powered by a battery of 3.6V</i></b>
<b><i>BeanDevice® AX-3D &amp; BeanDevice® AX-3D XRange</i></b>	<b>60-61 mA</b>	<b>&lt; 30 uA</b>

<i>BeanDevice® HI-INC</i> <i>BeanDevice® HI-INC XRange</i> <i>BeanDevice® INC</i>	70-73 mA	<30uA
<i>BeanDevice® AX-3DS</i> <i>BeanDevice® AX-3DS XRange</i>	50-55 mA	<30uA



For further information, please read the technical note ["TN\\_RF\\_002 V1.0 - Current consumption in active & sleeping mode"](#)


The following table gives you a list of recommendations in order to extend the battery autonomy of your BeanDevice®:

Influence factors on battery lifetime	Observations	Recommendations
<b><i>Sleeping power mode on your BeanDevice®</i></b>	Sleeping power mode can be configured on the BeanDevice® from the BeanScape®	By activating this power mode on your BeanDevice®, you will increase the battery autonomy of your BeanDevice®. By activating sleeping power mode, the BeanDevice® current consumption can decrease from 30 mA to 10-45 micro-amperes.  <b><i>For further information, please read the technical note <a href="#">TN_RF_010 – « BeanDevice® Power Management »</a></i></b>
<b><i>Sampling rate in streaming mode</i></b>	Power consumption will grow with the sampling rate.	Choose the right sampling rate on your BeanScape® interface.
<b><i>Packet Error Rate (PER)</i></b>	A high packet error rate can cause a higher retransmission data and this increase the current consumption.	Try to replace your BeanDevice® in an area where the radio link is much better (see Link Quality Indicator value).

### 12.3.2 Over-the-air Configuration (OTAC) parameters backed up on Flash

The BeanDevice® integrates an internal flash memory used for backing up OTAC (Over-the-air configuration) parameters.

This memory is organized into several levels:



12.3.2.1 Level 1: End-user OTAC parameters

The following table presents all the defaults configuration parameters:

Parameter	BeanDevice® version		
	AX3D & AX-3D Xrange	HI-INC & HI-INC XRange	AX-3DS & AX-3DS XRange
Power Mode	Active	Active	Active
Data Acquisition duty cycle	10s	10s	10s
Acquisition duration time	OK	OK	OK
Sampling rate	OK	OK	OK
Data Acquisition mode	LowDutyCycle	LowDutyCycle	LowDutyCycle
Alarms Threshold	H1 :2 ou10 H2 :2 ou 10 S2 :-2 ou -10 S1 :-2 ou -10	H1 :20 H2 :20 S2 :0 S1 :0	H1 :20 H2 :20 S2 :0 S1 :0
Anti-aliasing Filter cut-off frequency	100 Hz	10 Hz	10 Hz

**Table 6: End-user OTAC parameters**

To restore these defaults parameters, you must perform a *Network context deletion*.

The “Network” non-contact button is outside the product. Hold the magnet on the button network ("Network") for more than 2 seconds.



**Figure 213: Network reed non-contact button**



**Level 2, 3 & 4 of Configuration parameters are not affected by network context deletion (by hardware or software)**

### 12.3.2.2 Level 2: Sensor calibration parameters

The table below presents the sensor calibration parameters depending on BeanDevice® version:


Parameter	BeanDevice® Version		
	AX3D & AX-3D Xrange	HI-INC & HI-INC XRange	AX-3DS & AX-3DS XRange
Sensor gain	OK	OK	OK
Sensor offset	OK	OK	OK

Network diagnostic from your BeanScape® software


The BeanScape® provides network diagnostic information which is described in this chapter.

### 12.3.2.3 Displaying Network information

1. Launch your BeanScape® application
2. Select your BeanDevice® profile, a new tab "Advanced func." will appear in your BeanScape® toolbar;
3. Click on this tab, and then click on "BeanDevice® health status (history)".



**Figure 214: BeanDevice® health status option**

**A new window occurs:**

**Figure 215: BeanDevice® health status window**

#### 12.3.2.4 Packet Error Rate

**Packet error rate (PER)** is the number packet errors divided by the total number of transferred packets during a studied time interval. PER is a unit less performance measure, often expressed as a percentage number.

PER is only available with IEEE 802.15.4 Network; it represents the ratio of “lost data/data send” between the BeanDevice® and the BeanGateway®.

#### 12.3.2.5 LQI (Link Quality Indicator)

LQI (Link Quality Indicator) represents the radio signal quality in your Environment. It is possible that LQI is low due to EMC interference or metal presence in the environment.

**If you encounter such problems, several solutions are proposed to increase your LQI:**

- ✓ Try to configure your receiver antenna and your transmitter antenna on the same antenna pattern (cf. the Beam with of your antenna)
- ✓ Use a high gain antenna (in outdoor use only) for a better RF Link Budget
- ✓ Fix your BeanDevice & BeanGateway on a top of a mast or a building.



**For further information, read the application note on “How to extend your wireless range?”**



### 12.3.2.6 Internal temperature monitoring

An internal temperature sensor is used for onboard & battery temperature monitoring

### 12.3.2.7 Battery charge monitoring


Battery charge is based on current accumulation. The BeanDevice® integrates a current accumulator circuit which facilitates remaining capacity estimation by tracking the net current flow into and out of the battery. Current flow into the battery increments the current accumulator while current flow out of the battery decrements it.

Voltage measurement corresponds to battery voltage.

## 12.3.3 Scrolling menu « BeanDevice »

The BeanDevice® scrolling menu provides access to additional features: like the multi-graph mode (display of multiple windows on a graph measuring the same screen), deleting graphs displayed and the activation / deactivation of logging measurements.

To access to this scrolling menu, click on the sensor attached to your BeanDevice®. You will then see the BeanDevice® scrolling menu appearing.



*Figure 216: BeanDevice® Scrolling menu*




By clicking on the scrolling menu « BeanSensor », you can access to the following features :

### 12.3.3.1 Disable/Enable log

All the data received on the BeanScape® are stored in a log file in CSV format.

This feature allows you to Enable / Disable data logging on your log file.



*Figure 217: BeanSensor: Enable/Disable Log*




*For further information about CSV log file, please read the BeanScape® user manual.*

### 12.3.3.2 Buffer reset


This function clears the graphical display concerning recorded measurements of your sensor. The data stored in a log are not affected by this function.

By clicking on « Buffer reset », a second window appears asking you to confirm your choice:

- Yes, you accept to delete the whole measure data of this BeanSensor;
- No, don't delete the whole measure data of this BeanSensor;




**Figure 218: BeanSensor: Buffer Reset option**



**Figure 219: Buffer Reset**

### 12.3.3.3 Open the graph in a new window

By clicking on "Open the graph in a new window", you can open a graph corresponding to your sensor.



**Figure 220: BeanSensor: Open the graph in a new window**

You can easily open several graphs in a window.



**Figure 221: Graphs opened in separated windows**



**The multi-graph mode requires a lot of resources on your computer, it is recommended to install the BeanScope® software on a powerful computer.**

## 12.4 APPENDICE 4: TROUBESHOOTING

### ✓ Why the Red LED is flashing?

Each time a packet is lost by the BeanDevice®, Nwk/Activity led will blink in red. Try to decrease the wireless range between the BeanGateway® and the BeanDevice®.

### ✓ Why the BeanDevice® LEDs are not activated?

If there is no wireless network activity, the led will be inactive. Make sure you have powered your BeanDevice® with a charged battery.

### ✓ What should I do if interference is present on the radio channel?

Please turn off your BeanDevice®, and then choose an appropriate channel. The channel selection is done from the BeanGateway®.

For further information, please Read BeanGateway User's Manual BeanGateway®.

### ✓ Why the BeanDevice® does not provide the right measurement value?

- Check if your sensor channel is activated on your BeanScope® interface (ON Position)?;
- Check if your BeanDevice® is powered up;

- Check your LQI quality, if your LQI is under 50-60. You must change your antenna position, or your product position;
- Check your data acquisition mode, maybe you have specified a data acquisition which is too long;
- If you use a BeanDevice® AN-XX :
  - Check your sensor power supply, maybe you need to increase/decrease your power supply;
  - Check your sensor preprocess time. Maybe your sensor preprocess time is too short?
  - Check the wiring code of your sensor plug;

#### ■ ***Why the BeanDevice® doesn't respond when I try to configure it (Over-the-air-configuration)?***

- ✓ If your BeanDevice® operates with sleep phase, the RF Hardware operates also with a sleep phase. Therefore an Over-the-air-configuration will not be possible.
- ✓ Check the LQI (Link Quality Indicator) value, if this value is under 80, the over-the-air configuration will not be easy. Try to decrease the wireless range between the BeanDevice® and the BeanGateway®.
- ✓ If your BeanDevice® works in streaming mode, in order to keep a full synchronization of the data acquisition, any over-the-air-configuration is authorized.

#### ■ ***Why do I have too much noise on my sensor signal?***

- ✓ If you use a BeanDevice® AX3D/HI-INC/AX-3DS: don't forget to configure the cutoff frequency of your anti-aliasing filter
- ✓ If you use a BeanDevice® AN-mV: use a shielded cable.

#### ■ ***Why I see 1g on the axis pointing to the ground?***

- ✓ Accelerometers are devices that measure acceleration, which is the rate of change of the velocity of an object. They measure in meters per second squared (m/s<sup>2</sup>) or in G-forces (g). A single G-force for us here on planet Earth is equivalent to 9.8 m/s<sup>2</sup> = 1g.
- ✓ The gravitational force has three vector components, in X, Y & Z directions, the accelerometer should read 1g on the Z axis (Z axis is pointed to the ground), it's usual to view 1g on this axis as it's the gravity. Our sensors are MEMS based and are working between DC to 800Hz . It's a normal behavior.

## 12.5 APPENDIX 5: SENSOR CALIBRATION

---

### 12.5.1 Factory Calibration procedure

---

#### 12.5.1.1 BeanDevice® HI-INC/INC & HI-INC Xrange (Wireless Inclinometer)

The calibration procedure is based on a side-by-side comparison with a reference tiltmeter (Level development, Ref: SOLAR-2-05-1-RS232, accuracy  $\pm 0.01^\circ$  on the FS). For a better measurement stability, the two tiltmeters are mounted on a sinus table (Mecamag, ref: 1005/02/175100S, accuracy  $\pm 5$  seconds, planity  $\pm 0.005/100\text{mm}$ ).

#### 12.5.1.2 BeanDevice® AX-3D/AX-3DS & AX-3D Xrange (Wireless Accelerometer)

A static calibration method is used to calibrate the sensor.

### 12.5.2 Re-calibration

---

Depending on the operating environmental conditions, the following table summarize how often user should recalibrate its sensor:

<i>BeanDevice® version</i>	<i>Operating temperature &lt; 40°C</i>	<i>Operating temperature &gt; 40°C</i>
<b>BeanDevice® AX-3D &amp; BeanDevice® AX-3D Xrange</b>	<b>6 years</b>	<b>3 years</b>
<b>BeanDevice® AX-3DS</b>	<b>3 years</b>	<b>2 years</b>
<b>BeanDevice HI-INC, BeanDevice® HI-INC Xrange and BeanDevice® INC</b>	<b>6 years</b>	<b>3 years</b>



[Click here for more information about calibration settings](#)


## 12.6 FIREWALL EXCEPTION FOR BEANSCAPE®

---

By default, firewall blocks all unknown network traffic coming in to the network. To permit traffic through the firewall we create exceptions (or rules) that allow certain traffic on the network. In our case the rules are defined by the software which is BeanScape.


Usually when launching BeanScape for the first time your Windows OS will ask you to add an exception and to allow the software to use your network resources, however in case this doesn't occur or rejected, manually adding BeanScape to exceptions list is possible through these following steps:

1. Use your Search bar at the windows launcher and look for “Allow an app through Windows Firewall”



***Figure 222 :Windows search for firewall screenshot***


2. Look for BeanScape in the list and check its box, check Private if you are only willing to use BeanScape in your LAN or Public for allowing remote access from outside the LAN. Validate and your BeanScape will be allowed in your network.



**Figure 223: allowed apps window**

If you are not familiar to configure a firewall exception, you can directly from BeanScape® add this rule automatically.

On the BeanScape® menu select Tools, then Advanced Settings then click on validate to add BeanScape® to the Firewall.



**Figure 224: Firewall auto exception**